



Manuals.plus /

› Gourmia /

› Gourmia 4-Qt Digital Air Fryer with Guided Cooking, Easy Clean, Stainless Steel SS 4 QT User Manual

Gourmia GAF476

Gourmia 4-Qt Digital Air Fryer User Manual

Model: GAF476 | Brand: Gourmia

INTRODUCTION

The Gourmia 4-Qt Digital Air Fryer with Guided Cooking, Easy Clean, Stainless Steel, model GAF476, is designed to provide a healthier and more convenient way to prepare your favorite fried foods. Utilizing Fry Force 360° Technology, this appliance circulates hot air to cook food evenly, achieving crispy results with significantly less oil. Its intuitive digital controls and pre-set functions simplify the cooking process, making it an essential addition to any modern kitchen.



Image: Front view of the Gourmia 4-Qt Digital Air Fryer, showcasing its stainless steel finish and digital control panel with temperature and time settings, along with various cooking presets.

SETUP

Before first use, ensure all packaging materials are removed. Place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Wash the removable basket and crisper tray with warm, soapy water, rinse thoroughly, and dry completely. Wipe the exterior of the appliance with a damp cloth. It is recommended to run the air fryer empty for about 10 minutes on a high setting during the first use to eliminate any manufacturing odors. Ensure adequate ventilation during this initial run.

Gourmia®

THE #1 BESTSELLING AIR FRYER BRAND IN THE US



Based on NPD data of air fryer units sold in the US year to date 2022
Copyright 2022. The NPD Group, Inc. All Rights Reserved.

Image: The air fryer with its basket partially removed, revealing the non-stick interior and the crisper tray, highlighting its easy-to-clean design.

OPERATING INSTRUCTIONS

The Gourmia Digital Air Fryer features an intuitive touch control panel for easy operation. Follow these steps for general use:

- 1. Power On:** Plug the air fryer into a power outlet. The power button will illuminate. Press the power button to turn the unit on.
- 2. Select Preset:** Choose from 12 1-Touch Digital Presets for common foods like French Fries, Wings, Fish, Bacon, Seafood, Vegetables, Bake, Roast, Broil, Dehydrate, Toaster, Reheat, and Keep Warm. Simply tap the desired preset icon.
- 3. Adjust Temperature and Time:** If not using a preset, or to customize a preset, use the "Temp/Time" buttons and the "+" and "-" icons to adjust the cooking temperature (90°F to 400°F) and time as needed.
- 4. Preheat (Optional):** The air fryer can preheat automatically. You can turn this feature off if desired.

5. **Turn Reminder (Optional):** Activate the "Turn Reminder" feature to be prompted to shake or flip food halfway through cooking for even results.
6. **Start Cooking:** Press the "Start" button to begin the cooking cycle.
7. **Pause/Cancel:** Press "Stop/Cancel" to pause or end the cooking cycle.



- Includes a **4-quart** nonstick and dishwasher safe basket, crisper tray, user manual and recipe book.
- **Gourmia's 4-Quart Air Fryer** is big enough to accommodate a full meal and compact enough to blend seamlessly with the countertop, giving you the best of both worlds.

Image: Close-up of the air fryer's digital control panel, showing the various cooking presets and the temperature/time adjustment buttons.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your Gourmia Air Fryer. Always unplug the appliance and allow it to cool completely before cleaning.

- **Basket and Crisper Tray:** The 4-quart non-stick basket and crisper tray are dishwasher safe for quick and easy cleanup. For manual cleaning, wash with warm, soapy water and a non-abrasive sponge.
- **Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.
- **Heating Element:** After each use, ensure to clean the heating element to prolong its working life.

COOK FAST

Up to **30% faster** than traditional ovens.



CLEAN FASTER

Dishwasher safe - no mess or stress!

Image: A hand placing the crisper tray into a dishwasher, illustrating the convenience of its dishwasher-safe design.

TROUBLESHOOTING

If you encounter any issues with your Gourmia Air Fryer, please refer to the following general troubleshooting tips:

- **Appliance Not Turning On:** Ensure the power cord is securely plugged into a working electrical outlet.
- **Food Not Cooking Evenly:** Ensure not to overcrowd the basket. Use the "Turn Reminder" feature or manually shake/flip food halfway through cooking.
- **White Smoke from Appliance:** This may occur during initial use or if there is residual oil/grease from previous cooking. Ensure the basket and crisper tray are clean.
- **Food Not Crispy:** Ensure the temperature and time settings are appropriate for the food type. A light coating of oil can sometimes enhance crispiness.

For more detailed troubleshooting or persistent issues, please consult the full user manual or contact Gourmia customer support.

SPECIFICATIONS

Feature	Detail
Brand	Gourmia
Model Name	GAF476
Capacity	4 Liters (4-Qt)
Color	Stainless Steel
Product Dimensions	13.3"D x 10.8"W x 12.5"H
Item Weight	12 Pounds
Output Wattage	1500 Watts
Voltage	120 Volts
Control Method	Touch
Special Feature	Automatic Shut-Off
Nonstick Coating	Yes
Dishwasher Safe Parts	Yes (Basket, Crisper Tray)
Min Temperature Setting	90 Degrees Fahrenheit
Max Temperature Setting	400 Degrees Fahrenheit
Air Frying Technology	Fry Force 360° Technology
UPC	810002862298

WARRANTY AND SUPPORT

All Gourmia Appliances include a 1 Year Comprehensive International Warranty for your peace of mind. For customer support, product registration, or to access the full user manual, please visit the official Gourmia website or refer to the contact information provided in your product packaging.

You can also download the official User Manual (PDF) [here](#).

