

Cuifati CUIFATImipqrgdwyu

Cuifati 30A MPPT Solar Controller User Manual

Model: CUIFATImipqrgdwyu

[Overview](#) [Specifications](#) [Setup](#) [Introduction](#) [Product](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Cuifati 30A MPPT Solar Controller. Please read these instructions carefully before installation and use to ensure optimal performance and longevity of the product.

The Cuifati 30A MPPT Solar Controller is designed to manage the power flow from your solar panels to your battery bank, ensuring efficient charging and protecting your batteries from overcharge and over-discharge. It features an intelligent regulator compatible with 12V, 24V, 36V, and 48V systems, a built-in USB port for device charging, and an LCD digital panel for easy monitoring and parameter configuration.

2. PRODUCT OVERVIEW

2.1 Key Features

- Wide Compatibility:** Supports 12V, 24V, 36V, and 48V battery systems.
- Integrated USB Output:** Two 5V/2A USB ports for charging mobile devices.
- Intelligent Protection:** Features protection against overcurrent, short-circuit, inverse polarity, low voltage, and overcharge.
- LCD Display:** Provides real-time status and data, allowing for convenient mode switching and parameter configuration.
- Automatic System Management:** Manages solar panel and battery operations automatically with a built-in industrial microcontroller.

2.2 Components

The solar controller unit includes the main control module with an LCD screen, USB ports, and terminal connections for solar panels, battery, and load. The device is housed in an engineering plastic casing designed for durability.



Figure 1: Front view of the Cuiyadi 30A MPPT Solar Controller, showing the LCD display, USB ports, and connection terminals.



Figure 2: Front and bottom view of the solar controller, highlighting the heat sink fins for efficient cooling.

3. SPECIFICATIONS

| Parameter | Value |
|---------------------------|--------------------------------|
| Item Type | Solar Controller |
| Material | Engineering plastic |
| Rated Current | 30A |
| Rated Working Voltage | 12V/24V/36V/48V (Auto-sensing) |
| Solar Panel Input Voltage | $\leq 100V$ |
| Static Loss | $\leq 30mA$ |
| Loop Pressure Drop | $\leq 0.3V$ |

| Parameter | Value |
|---------------------|----------------------------|
| USB Output | 5V/2A x 2 |
| Working Temperature | -20~ +55°C |
| Protection Level | IP32 |
| Relative Humidity | ≤95%, no condensation |
| Terminal Size | 6AWG/16mm ² |
| Package Dimensions | 8.66 x 4.57 x 2.24 inches |
| Item Weight | 1.1 pounds (0.5 Kilograms) |

4. SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your solar charging system. Please follow these steps carefully:

4.1 Safety Precautions

- Ensure all connections are secure and correct to prevent damage to the controller or other components.
- Always connect the battery first, then the solar panel, and finally the load. Disconnect in the reverse order.
- Install the controller in a well-ventilated area, away from direct sunlight, high temperatures, and moisture.
- Use appropriate wire gauges for all connections to minimize power loss and prevent overheating.

4.2 Connection Steps

1. **Connect the Battery:** Connect the positive and negative terminals of your battery to the corresponding battery terminals on the solar controller. Ensure correct polarity. The LCD display should light up.
2. **Connect the Solar Panel:** Connect the positive and negative terminals of your solar panel(s) to the corresponding solar panel terminals on the controller. Ensure correct polarity.
3. **Connect the Load (Optional):** If you are connecting a DC load directly to the controller, connect its positive and negative terminals to the load terminals on the controller.



Figure 3: Close-up view of the controller's connection terminals for solar panels, battery, and load.

5. OPERATING INSTRUCTIONS

The Cuifati solar controller features an intuitive LCD display and control buttons for easy operation and monitoring.

5.1 LCD Display and Buttons

The LCD screen displays various system parameters such as battery voltage, charging current, discharge current, and operating modes. The controller typically has three buttons: a 'Mode' button, a '+' button, and a '-' button.



| Mode | Operating |
|--------------------|--|
| Browse mode | Short press "+" or "-" |
| Load switch | When the load is set to 24-hour mode, short press "+" on the main interface Do not switch the load manually in other load working modes |
| Set mode | In the settable interface, long press "+" to enter the parameter setting, short press "+" or "-" to set the parameter, and finally long press "+" to confirm and save the parameter setting. (Long press "one" to not save the parameters and restore to the last parameter setting) |
| Reset | Long press "+" in the ambient temperature interface |

Figure 4: The controller's LCD display and control buttons, along with a guide to basic operations.

5.2 Basic Operations

| Mode | Operating Instruction |
|--------------------|---|
| Browse Mode | Short press the "+" or "-" button to cycle through display parameters. |
| Load Switch | When the load is set to 24-hour mode, short press "+" on the main interface to toggle the load. Do not manually switch the load in other working modes. |
| Set Mode | In the settable interface, long press "+" to enter parameter setting. Short press "+" or "-" to adjust the parameter. Long press "+" again to confirm and save the parameter setting. (Long pressing "-" will not save parameters and restore to the last setting). |
| Reset | Long press "+" in the ambient temperature interface to reset the controller. |

5.3 USB Charging

The two 5V/2A USB ports can be used to charge compatible electronic devices such as mobile phones, tablets, and PCs. Simply connect your device using a standard USB cable.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your solar controller.

- **Cleanliness:** Keep the controller clean and free from dust and debris. Use a dry cloth to wipe the surface.
- **Connections:** Periodically check all wire connections to ensure they are tight and free from corrosion. Loose connections can lead to power loss or overheating.
- **Ventilation:** Ensure the installation area remains well-ventilated to prevent overheating of the controller.
- **Environmental Check:** Verify that the controller is not exposed to excessive moisture, extreme temperatures, or direct sunlight, which can degrade its performance and lifespan.

7. TROUBLESHOOTING

If you encounter issues with your Cuifati solar controller, refer to the following common problems and solutions:

7.1 No Display on LCD Screen

- **Check Battery Connection:** Ensure the battery is correctly connected to the controller with the correct polarity. The controller draws power from the battery to operate its display.
- **Battery Voltage:** Verify that the battery voltage is within the operating range (12V-48V). If the battery is completely discharged, the controller may not power on.

7.2 Battery Not Charging

- **Solar Panel Connection:** Check if the solar panels are correctly connected to the controller with the correct polarity.
- **Solar Panel Output:** Ensure the solar panels are receiving sufficient sunlight and are producing voltage. Use a multimeter to check the open-circuit voltage of the solar panels.
- **Controller Settings:** Verify that the battery type and charging parameters are correctly set in the controller's settings.

7.3 Load Not Working

- **Load Connection:** Ensure the load is correctly connected to the controller's load terminals.
- **Load Switch Setting:** Check the load switch setting on the controller. If it's in a timed mode, ensure the current time is within the active period.
- **Battery Voltage:** If the battery voltage is too low, the controller may cut off the load to protect the battery.
- **Overload Protection:** The controller has overload protection. Ensure the load current does not exceed the controller's rated load current.

8. WARRANTY AND SUPPORT

The Cuifati 30A MPPT Solar Controller comes with a 12-month warranty. For any issues or support inquiries, please contact Cuifati customer service via email. Please have your product model number (CUIFATImipqrgdwyu) and purchase details ready when contacting support.

Optional protection plans are available for extended coverage:

- 3-Year Protection Plan
- 4-Year Protection Plan

For details on these plans, please refer to your purchase documentation or contact your retailer.