Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- → Signify /
- > Philips LED Slim Flood Light PTF150-NW-G1-Y-FL-8-BZ User Manual

Signify PTF150-NW-G1-Y-FL-8-BZ

Philips LED Slim Flood Light PTF150-NW-G1-Y-FL-8-BZ User Manual

Model: PTF150-NW-G1-Y-FL-8-BZ

1. Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your Philips LED Slim Flood Light, model PTF150-NW-G1-Y-FL-8-BZ. Please read this manual thoroughly before installation and retain it for future reference.

The Philips LED Slim Flood Light is designed for outdoor applications such as sign lighting, building facades, security lighting, and general area illumination. Its robust construction and efficient LED technology ensure reliable performance.

2. SAFETY INFORMATION

WARNING: Risk of electric shock. Installation should be performed by a qualified electrician or trained personnel in accordance with all applicable electrical codes.

- Disconnect power at the circuit breaker or fuse box before installation or servicing.
- Ensure the supply voltage is compatible with the fixture's requirements (120V AC).
- Do not operate the fixture with damaged wiring or components.
- Avoid direct eye exposure to the light source when illuminated.
- The fixture's housing acts as a heat sink and may become hot during operation. Allow adequate cooling time before handling.
- Ensure all connections are secure and properly sealed, especially the IP66 liquid-tight connector for the power cord, to maintain water resistance.
- Do not modify the fixture. Any modifications may void the warranty and create safety hazards.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Philips LED Slim Flood Light (1 unit)
- Integrated Yoke Mount (pre-attached)
- Power Cord (3-foot, STW 16 gauge)
- IP66 Liquid Tight Connector (pre-attached to cord exit)



Image 1: Philips LED Slim Flood Light. This image shows the front view of the flood light with its integrated yoke mount and power cord connection point.

4. SPECIFICATIONS

Specification	Detail
Model Number	PTF150-NW-G1-Y-FL-8-BZ
Brand	Signify (Philips)
Wattage	150 Watts
Lumen Output	18600 Lumens
Color Temperature	4000K Cool White
Efficiency	124 lumens per watt

Voltage	120 Volts (AC)	
Mounting Type	Yoke Mount (Surface Mount)	
Finish	Bronze	
Material	Die-cast aluminum housing, tempered glass lens	
Ingress Protection (IP) Rating	IP65 (fixture), IP66 (connector)	
Item Weight	4 Pounds	
Dimensions (Approx.)	16.93" H x 11.41" W x 2.36" D (430mm H x 289.8mm W x 59.9mm D)	

5. SETUP AND INSTALLATION

The Philips LED Slim Flood Light is designed for surface mounting using its integrated yoke. Follow these steps for proper installation:

- Preparation: Ensure power is disconnected at the main circuit breaker. Gather necessary tools (drill, screwdriver, wire strippers, electrical tape, mounting hardware suitable for your surface).
- 2. **Mounting Location:** Select a sturdy surface (wall, pole, ground) capable of supporting the fixture's weight and providing adequate clearance for light distribution.
- Marking and Drilling: Use the yoke mount as a template to mark the drilling points on the
 mounting surface. Drill appropriate pilot holes for your chosen mounting hardware. Refer to
 the dimension diagram for precise measurements.
- 4. Secure the Fixture: Attach the yoke mount securely to the prepared surface using appropriate screws or bolts (not included). Ensure the fixture is stable and cannot vibrate loose. The yoke includes a bolt to lock in the aiming angle after adjustment.

5. Electrical Connection:

- The fixture comes with a 3-foot watertight STW 16 gauge cord exiting the housing via an IP66 liquid-tight connector.
- Connect the fixture's power cord to your main power supply wiring. This connection
 must be made by a qualified electrician and comply with all local and national electrical
 codes.
- Ensure all wire connections are properly insulated and protected from moisture.
- 6. **Aiming Adjustment:** Loosen the bolt on the yoke mount, adjust the flood light to the desired aiming angle, and then securely tighten the bolt to lock the position.
- 7. **Restore Power:** Once installation is complete and all connections are secure, restore power at the circuit breaker.




Image 2: Philips LED Slim Flood Light Dimension Diagram. This diagram provides detailed measurements for the flood light, including height, width, depth, and mounting hole spacing, crucial for accurate installation.

6. OPERATING INSTRUCTIONS

The Philips LED Slim Flood Light operates upon receiving power. There are no user-adjustable controls on the fixture itself.

- Power On/Off: Control the light by switching the connected power circuit on or off. This can be done via a wall switch, timer, or photocell (not included).
- Automatic Operation: For automated operation, connect the flood light to an external timer, motion sensor, or photocell switch (purchased separately) according to their respective installation instructions.

7. MAINTENANCE

The Philips LED Slim Flood Light is designed for minimal maintenance. Regular inspection and

cleaning will ensure optimal performance and longevity.

- Cleaning: Periodically clean the lens and housing with a soft, damp cloth to remove dirt, dust, and debris. Do not use abrasive cleaners or solvents, as these can damage the finish or lens. Ensure power is off before cleaning.
- **Inspection:** Annually inspect the fixture for any signs of damage, loose connections, or wear on the power cord. Address any issues promptly.
- **Component Replacement:** The LED light source is integrated and not user-replaceable. If the fixture malfunctions, contact customer support.

8. TROUBLESHOOTING

If your Philips LED Slim Flood Light is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wiring connection. Faulty circuit breaker/fuse.	Check power supply. Verify all wiring connections are secure (consult a qualified electrician). Reset circuit breaker or replace fuse.
Light flickers or is dim.	Inconsistent power supply. Loose wiring. Fixture damage.	Ensure stable power. Check wiring connections. If damage is suspected, discontinue use and contact support.
Water inside the fixture.	Improperly sealed connections. Damaged housing/lens.	Immediately disconnect power. Inspect and re-seal all connections, especially the IP66 connector. If housing or lens is damaged, the IP rating may be compromised; contact support.

If troubleshooting steps do not resolve the issue, contact customer support.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official Signify (Philips) website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Manufacturer: Signify

Model Number: PTF150-NW-G1-Y-FL-8-BZ

Contact Information: Please visit the official Signify website for the most up-to-date contact

details and support resources.

Related Documents - PTF150-NW-G1-Y-FL-8-BZ



Interact Pro: Easy, Effective, Smart Lighting System for Businesses

Discover Interact Pro, the wireless smart lighting system by Signify, offering energy efficiency, convenience, and advanced features for offices, industry, and schools. Learn about system setup, benefits, hardware, and applications.




Signify MultiOne Mobile User Manual v1.7: Driver Configuration and NFC Scanner Guide

Comprehensive user manual for the Signify MultiOne Mobile app. Learn to configure Philips and Advance lighting drivers using NFC and Bluetooth, manage features like ALO, AOC, DynaDimmer, and DALI, and utilize the external NFC scanner for efficient driver management and cloning.



Signify North America Corporation Limited Warranty for Lighting Components

This document outlines the limited warranty provided by Signify North America Corporation for its branded lighting components, including lamps, drivers, ballasts, and modules. It details the warranty periods, conditions, exclusions, and remedies for product defects.



Philips PV Vertical Panel 200Wp Installation Guide | Signify

This guide provides detailed instructions for the installation of the Philips PV Vertical Panel 200Wp by Signify. Learn about mounting, connections, dimensions, and safety precautions for a secure and efficient setup.



NatureConnect Link Installation and Commissioning Manual | Signify

This manual provides detailed instructions for the installation and commissioning of the Signify NatureConnect Link natural lighting system. It covers connecting components, configuring scenes, integrating sensors, and troubleshooting common issues for creating biophilic indoor environments.



Signify Interact Intelligent Buildings Limited Warranty

This document outlines the limited warranty provided by Signify North America Corporation for Interact control products used in intelligent buildings. It details the warranty period, coverage, exclusions, and conditions for repair or replacement.

Documents - Signify - PTF150-NW-G1-Y-FL-8-BZ



[pdf] Guide

Cut Sheet Philips Lighting PTF150 NW G1 Y FL 8 BZ LED Slim Floodlight 150W 120 277V PLATT ELECTRIC SUPPLY 12 i 6283901C 57ED 4391 8128 A5798659D10E rexel cdn products ||| s Floodlights Slim flood The Philips LED Slim flood is your best value for discreet and modern desi ... ring Codes PTF10-NW-G1-K-FL-8-BZ PTF30-NW-G1-K-FL-8-BZ PTF50-NW-G1-K-FL-8-BZ PTF100-NW-G1-Y-FL-8-BZ PTF200-NW-G1-Y-FL-8-BZ PTF200-NW-G1-Y-



[pdf] Catalog

Catalog Page Philips Lighting PTF150 NW G1 Y FL 8 BZ LED Slim Floodlight 150W 120 277V PLATT ELECTRIC SUPPLY 11 i 9F5F7B1C B757 4D65 8295 FF426C1393DA rexel cdn products ||| Floodlights Slim flood Illuminate with style The Philips LED Slim flood is your best value for discreet and modern design on your floodlighting projects. Versatile and stylish with six different sizes to choose from, Slim flood provides application flexibility for ground, wall, or pole mount install...

lang:en score:27 filesize: 496.69 K page_count: 2 document date: 2019-04-17



[pdf] Guide Catalog

Luminaire service guide assets usesi 7 Service Guide nI door Outdoor A star H T24 DLC or LTG beside a catalog number indicates item is an Energy Star Title 24 complient qualified Light To Go stock Pictures are representative of product USESI 820377 media catalogs |||

Luminaire service guide U.S. Stock and Quick Ship 10 Day product portfolio for indoor and outdoor lu ... 352025999 PTF10-NW-G1-K-FL-8-BZ PTF30-NW-G1-K-FL-8-BZ PTF50-NW-G1-K-FL-8-BZ PTF100-NW-G1-Y-FL-8-BZ PTF100-NW-G1-Y-FL-8-BZ PTF200-NW-G1-Y-FL-8-BZ TF10-NW-G1-K-FL-8-BZ TF30-NW-G1-K-FL-8-BZ TF50-NW-G1-K...

lang:en score:20 filesize: 3.34 M page_count: 116 document date: 2019-06-26






[pdf] Accessories Catalog

Real professionals choose Lighttogo 20190722 lighttogo product range booklet assets signify is content PhilipsLighting Assets philips lighting united states |||

Lighttogo Luminaires Real professionals choose Lighttogo s philips.com/Lighttogo Things just got e ... talog Code PTF10-NW-G1-K-FL-8-BZ PTF30-NW-G1-K-FL-8-BZ PTF50-NW-G1-K-FL-8-BZ PTF100-NW-G1-Y-FL-8-BZ **PTF150-NW-G1-Y-FL-8-BZ** PTF200-NW-G1-Y-FL-8-BZ Watts 10W 30W 50W 100W 150W 200W Color Temp Lumens ...

lang:en score:19 filesize: 7.23 M page count: 68 document date: 2019-07-15

[pdf] Accessories Catalog



Lighttogo Luminaires Real professionals choose Lighttogo s philips.com/Lighttogo Things just got e ... talog Code PTF10-NW-G1-K-FL-8-BZ PTF30-NW-G1-K-FL-8-BZ PTF50-NW-G1-K-FL-8-BZ PTF100-NW-G1-Y-FL-8-BZ **PTF150-NW-G1-Y-FL-8-BZ** PTF200-NW-G1-Y-FL-8-BZ Watts 10W 30W 50W 100W 150W 200W Color Temp

lang:en score:16 filesize: 7.54 M page_count: 64 document date: 2019-04-15

