

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [HP](#) /
- > [HP 15.6 inch HD Touchscreen Laptop \(Intel i5-1155G7\) User Manual](#)

HP HP 15.6" HD Touchscreen Laptop

HP 15.6 inch HD Touchscreen Laptop User Manual

Model: HP 15.6" HD Touchscreen Laptop (Intel i5-1155G7)

INTRODUCTION

Welcome to the user manual for your new HP 15.6 inch HD Touchscreen Laptop. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your laptop.



Image: The HP 15.6 inch HD Touchscreen Laptop displayed open, showcasing the Windows 11 operating system

SETUP

1. Unboxing and Initial Inspection

Carefully remove your laptop and its accessories from the packaging. Verify that all components are present and undamaged. The box should contain:

- HP 15.6 inch HD Touchscreen Laptop
- Power Adapter and Cable
- Quick Start Guide (if included)

2. Connecting the Power Adapter

Before first use, connect the power adapter to the laptop's power port and then plug it into a wall outlet. Allow the battery to charge fully before disconnecting the power adapter.



Image: Left side of the laptop, highlighting the power input and two USB 3.0 Type-A ports.

3. Initial Power On and Windows Setup

Open the laptop lid and press the power button. Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes selecting your region, connecting to a Wi-Fi network, and creating a user account.

4. Connecting Peripherals

You can connect various peripherals to your laptop using the available ports:

- **USB 3.0 Type-A Ports (x2):** For connecting USB devices like mice, keyboards, or external hard drives.
- **USB 3.0 Type-C Port (x1):** For connecting compatible USB-C devices.
- **HDMI Port (x1):** For connecting to an external display or projector.
- **Headphone/Microphone Combo Jack (x1):** For connecting headphones or a headset.
- **Multi-format SD Media Card Reader (x1):** For reading SD memory cards.



Image: Right side of the laptop, displaying the SD card reader, headphone/microphone combo jack, USB 3.0 Type-C port, and HDMI port.

OPERATING YOUR LAPTOP

1. Basic Navigation

Your HP laptop features both a precision touchpad and a responsive HD touchscreen for navigation.

- **Touchpad:** Use multi-touch gestures for scrolling, zooming, and switching applications.
- **Touchscreen:** Interact directly with the display for intuitive control, tapping, swiping, and pinching.

2. Keyboard Functions

The full-size keyboard includes a numeric keypad for efficient data entry. Function keys (F1-F12) provide quick access to system settings such as volume control, screen brightness, and Wi-Fi toggle. Refer to the icons on the function keys for their specific actions.

3. Connecting to Wi-Fi

To connect to a wireless network:

1. Click the Wi-Fi icon in the taskbar.
2. Select your desired network from the list.
3. Enter the network password if prompted.
4. Click **Connect**.

4. Using the Webcam

The integrated 720p HD webcam is located at the top center of the display. It can be used for video calls, online meetings, and capturing photos or videos. Ensure proper lighting for best results.



Image: The laptop screen showing the webcam at the top, ready for use in video conferencing or other applications.

MAINTENANCE

1. Cleaning Your Laptop

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Keyboard and Chassis:** Use a soft cloth to wipe surfaces. For dust, use compressed air. Avoid harsh chemicals.

2. Software Updates

Regularly update your Windows 11 operating system and drivers to ensure security, stability, and optimal performance. Go to **Settings > Windows Update** to check for and install updates.

3. Battery Care

To maximize battery life:

- Avoid extreme temperatures.
- Do not leave the laptop plugged in at 100% charge for extended periods.
- Calibrate the battery periodically by fully discharging and recharging it.

4. Storage Management

Periodically clean up unnecessary files and applications to free up storage space on your 256GB PCIe NVMe M.2 SSD. Use Windows' built-in Disk Cleanup tool or third-party utilities.

TROUBLESHOOTING

1. Laptop Not Turning On

- Ensure the power adapter is securely connected and the outlet is working.
- Check if the battery is charged.
- Perform a hard reset by holding the power button for 15 seconds.

2. Wi-Fi Connection Issues

- Restart your router and modem.
- Ensure Wi-Fi is enabled on your laptop (check function keys or Windows settings).
- Forget the network and reconnect.

3. Touchscreen Unresponsive

- Restart the laptop.
- Check for updated display drivers in Device Manager.
- Ensure the screen is clean and free of debris.

4. Slow Performance

- Close unnecessary applications running in the background.
- Check for malware or viruses.
- Ensure sufficient free storage space.
- Install all pending Windows updates.

SPECIFICATIONS

Feature	Detail
Brand	HP
Model Name	HP
Standing Screen Display Size	15.6 Inches

Feature	Detail
Screen Resolution	1366 x 768 pixels
Max Screen Resolution	1366x768 Pixels
Processor	Intel Core i5-1155G7 (2.5 GHz up to 4.50 GHz, 4-Core)
RAM	12 GB DDR4-3200 MHz
Hard Drive	256 GB PCIe NVMe M.2 SSD
Graphics Coprocessor	Intel Iris Xe Graphics
Operating System	Windows 11 Home
Wireless Type	802.11ac
Number of USB 3.0 Ports	2
Average Battery Life	4 Hours
Item Weight	5.04 pounds
Product Dimensions	14.11 x 9.53 x 0.71 inches
Color	Natural Silver
Rear Webcam Resolution	720 Pixels

WARRANTY AND SUPPORT

Your HP laptop comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official HP support website. For technical assistance, driver downloads, or service requests, please visit [HP Support](#).