

[Manuals.plus](#) /

› [Ultima Cosa](#) /

› Ultima Cosa 3.2QT Air Fryer User Manual

Ultima Cosa Presto Luxe 3.2QT 1500W

Ultima Cosa 3.2QT Air Fryer User Manual

Model: Presto Luxe 3.2QT 1500W

INTRODUCTION

Thank you for choosing the Ultima Cosa 3.2QT Air Fryer. This appliance is designed to provide a healthier alternative to traditional frying, allowing you to enjoy your favorite foods with significantly less oil. This manual provides essential information on how to safely and effectively operate, maintain, and troubleshoot your new air fryer.



Image: Front view of the Ultima Cosa 3.2QT Air Fryer, showcasing its sleek black design and compact form factor.



Image: A visual comparison demonstrating the difference between air-fried and deep-fried french fries, highlighting the healthier aspect of air frying.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

PRODUCT OVERVIEW

Components

The Ultima Cosa Air Fryer consists of the main unit, a removable frying basket, and a crisper plate.



Image: The Ultima Cosa Air Fryer with its frying basket pulled out, revealing the interior space for food preparation.

Control Panel

The air fryer features an intuitive one-touch digital display on the top surface for easy operation.



Image: A top-down view of the air fryer's digital control panel, showing the temperature display and various touch icons for functions and presets.

- **Temperature Display:** Shows the current or set temperature.
- **Time Display:** Shows the remaining or set cooking time.
- **Preset Icons:** Dedicated icons for 7 common cooking functions (Fries, Steak, Chicken, Fish, Vegetables, Bacon, Shrimp).
- **Preheat Button:** Initiates the preheating cycle.
- **Keep Warm Button:** Activates the keep warm function.
- **Temperature/Time Adjustment Buttons:** Plus (+) and Minus (-) buttons to adjust temperature and time.
- **Power Button:** Turns the unit on/off and starts/pauses cooking.

SETUP

Before First Use

1. Unpack the air fryer and remove all packaging materials, including any stickers or labels.
2. Wipe the exterior of the air fryer with a damp cloth.
3. Remove the frying basket and crisper plate. Wash them thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
4. Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.
5. Ensure the power cord is not tangled and is positioned safely.

OPERATING INSTRUCTIONS

Basic Operation

1. Plug the air fryer into a grounded electrical outlet. The display will illuminate.
2. Pull out the frying basket. Place the crisper plate inside the basket.
3. Place your food onto the crisper plate in the basket. Do not overfill the basket to ensure even cooking.
4. Slide the frying basket back into the air fryer until it clicks into place.
5. Press the Power button to turn on the air fryer.
6. Adjust the temperature using the (+) and (-) buttons. The temperature range is 180°F to 400°F (80°C to 220°C).
7. Adjust the cooking time using the (+) and (-) buttons.
8. Press the Power button again to start cooking.
9. During cooking, you can pull out the basket to shake or flip food. The air fryer will pause automatically and resume when the basket is reinserted.
10. Once the cooking time is complete, the air fryer will beep and turn off. Carefully remove the basket and transfer food to a serving dish.

Preheat Function

For best results, especially with certain foods, preheating is recommended. Press the "Preheat" button on the control panel. The air fryer will heat to a default temperature (e.g., 380°F/195°C) for a few minutes. Once preheated, it will indicate readiness, and you can then add your food and set the desired cooking program.

Cooking Functions (Preset Programs)

The Ultima Cosa Air Fryer comes with 7 preset smart programs for common dishes. Simply select the desired icon, and the air fryer will automatically set the optimal temperature and time. You can adjust these settings manually if needed.



Image: The Ultima Cosa Air Fryer displayed alongside icons representing its 7 preset cooking functions: Fries, Steak, Chicken, Fish, Vegetables, Bacon, and Shrimp.

- **Fries:** Ideal for crispy french fries.
- **Steak:** Optimized for cooking various cuts of steak.
- **Chicken:** Perfect for chicken pieces or a small whole chicken.
- **Fish:** Suitable for fish fillets and other seafood.
- **Vegetables:** For roasting or crisping vegetables.
- **Bacon:** For perfectly crispy bacon.
- **Shrimp:** For quick and even cooking of shrimp.



Image: A cutaway view of the Ultima Cosa Air Fryer illustrating the internal 3D heat flow technology, which ensures rapid and even cooking.

MAINTENANCE AND CLEANING

Regular cleaning of your air fryer will ensure optimal performance and extend its lifespan.

Cleaning the Air Fryer

1. Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Frying Basket and Crisper Plate:** These parts have a non-stick coating and are dishwasher safe. For manual cleaning, wash with hot water, dish soap, and a non-abrasive sponge. Do not use metal utensils or abrasive cleaning materials, as they can damage the non-stick coating.
3. **Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water or any other liquid.

4. **Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a mild dish soap solution.
5. Ensure all parts are completely dry before reassembling and storing the air fryer.



Image: Demonstrates the ease of cleaning the air fryer basket, showing it being rinsed under a tap and placed into a dishwasher.

TROUBLESHOOTING

If you encounter any issues with your Ultima Cosa Air Fryer, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; Power outlet malfunction; Basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Check if the basket is fully pushed into the main unit.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket is overcrowded; Food not shaken/flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking for even results.
White smoke coming from the appliance.	Grease residue from previous use; High fat content food.	Clean the basket and crisper plate thoroughly after each use. For high-fat foods, drain excess fat from the basket during cooking.
Food is not crispy.	Not enough oil (for certain foods); Temperature too low; Cooking time too short.	Lightly brush or spray food with oil. Increase temperature or cooking time as needed. Ensure preheating is used.

SPECIFICATIONS

Technical specifications for the Ultima Cosa 3.2QT Air Fryer.



Image: The Ultima Cosa Air Fryer with its key dimensions (height, width, depth) clearly labeled in centimeters.

Feature	Detail
Brand	Ultima Cosa
Model	Presto Luxe

Feature	Detail
Capacity	3.2 Quarts (3 Liters)
Power/Wattage	1500 Watts
Voltage	120 Volts (AC)
Temperature Range	180°F to 400°F (80°C to 220°C)
Product Dimensions	31.2D x 24.1W x 29.9H cm
Item Weight	3.8 kg
Material	Aluminum
Special Features	Programmable, One-Touch Smart Programs, Preheat & Keep Warm

WARRANTY AND SUPPORT

Ultima Cosa products are manufactured to the highest quality standards. For information regarding warranty coverage, product support, or to purchase replacement parts, please refer to the contact information provided with your product packaging or visit the official Ultima Cosa website.

Please retain your proof of purchase for warranty claims.

© 2024 Ultima Cosa. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question