

THEGA B0BQ764CXV

THEGA Mini Rice Cooker (Model B0BQ764CXV) User Manual

Your guide to safe and efficient operation

1. INTRODUCTION

Thank you for purchasing the THEGA Mini Rice Cooker, Model B0BQ764CXV. This appliance is designed for convenient and efficient cooking of rice and other dishes, suitable for individuals or small households. Please read this manual thoroughly before use to ensure proper operation, maintenance, and safety.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use the appliance for other than intended use.

3. PRODUCT OVERVIEW

3.1 Components

The THEGA Mini Rice Cooker includes the following components:

- Main Rice Cooker Unit
- Inner Pot (Ceramic Glazed Non-Stick Liner)
- Instruction Manual
- Power Cord (Detachable)

3.2 Features

- **LED Display:** Modern LED screen for easy operation and setting adjustments.
- **Multifunctional:** Capable of cooking rice, porridge, claypot rice, stewed bone soup, pastry, and vegetables.
- **Compact and Portable:** Equipped with a comfortable handle and detachable power cord, ideal for small kitchens, offices, dorms, or travel.
- **Safe and Healthy Inner Pot:** Features an upgraded nano-ceramic non-stick coating, free from lead and cadmium, ensuring healthy cooking and easy cleaning.
- **1.6L Capacity:** Suitable for 1-2 people, minimizing food waste.
- **Delay Timer:** 12-hour delay timer for scheduled cooking.
- **Automatic Keep Warm:** Automatically switches to keep warm mode after cooking is complete.
- **Durable Construction:** Features a 304 stainless steel inner cover and bottom cooling holes for efficient heat dissipation.



Image 1: Front view of the THEGA Mini Rice Cooker, showcasing its compact design and LED display panel.

1.6L Capacity

160*160*165mm



Image 2: The rice cooker with its 1.6L capacity, suitable for 1-2 servings, and dimensions of 160x160x165mm.



Image 3: The rice cooker demonstrating its multifunctional capability, being used for a hot pot meal with various ingredients.

24-Hour Long-Term Appointment



Image 4: The rice cooker highlighting its 24-hour long-term appointment (delay timer) function on the LED display.

Bottom Cooling Holes



304 Stainless Steel Inner Cover

Image 5: Close-up views showing the bottom cooling holes for heat dissipation and the 304 stainless steel inner cover for durability and hygiene.

Ceramic Glazed Liner

Non-Stick Pan, Hardness Is High



Image 6: View of the ceramic glazed non-stick inner pot, emphasizing its easy-to-clean surface and high hardness.

4. SETUP

1. **Unpack:** Carefully remove all packaging materials and components from the box.
2. **Initial Cleaning:** Before first use, wash the inner pot, lid, and any accessories with warm, soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources. Ensure adequate ventilation around the unit.
4. **Connect Power:** Insert the detachable power cord into the appliance, then plug it into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

5.1 Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. Rinse the rice under cold water until the water runs clear.
2. **Add Rice to Inner Pot:** Place the rinsed rice into the inner pot.
3. **Add Water:** Add the appropriate amount of water. A common ratio is 1 cup of rice to 1.5-2 cups of water, but this can vary based on rice type and personal preference. The markings inside the inner pot indicate water levels for different rice quantities.
4. **Place Inner Pot:** Carefully place the inner pot into the main rice cooker unit. Ensure it is seated properly.
5. **Close Lid:** Close the lid securely.
6. **Select Function:** Plug in the rice cooker. Use the button control panel to select the 'Rice' function.
7. **Start Cooking:** Press the 'Start' button. The indicator light will illuminate, and the cooking process will begin.
8. **Keep Warm:** Once cooking is complete, the rice cooker will automatically switch to 'Keep Warm' mode.

5.2 Other Functions

The THEGA Mini Rice Cooker offers various cooking modes:

- **Porridge:** For preparing various types of porridge.
- **Claypot Rice:** A specific setting for claypot-style rice dishes.
- **Stewed Bone Soup:** For slow-cooking soups.
- **Pastry:** A dedicated setting for baking small pastries.
- **Vegetables:** For steaming or cooking vegetables.

Refer to the control panel and experiment with water levels and cooking times for optimal results with different ingredients.

5.3 Delay Timer

The 12-hour delay timer allows you to set a cooking start time in advance:

1. Prepare ingredients in the inner pot as usual.
2. Select your desired cooking function.
3. Press the 'Delay Timer' button and adjust the desired delay time using the controls.
4. Press 'Start'. The timer will count down, and cooking will begin automatically after the set delay.

5.4 Keep Warm Function

After cooking is complete, the appliance automatically switches to 'Keep Warm' mode to maintain the food at an optimal serving temperature. This function can keep food warm for an extended period, ensuring hot meals are available when needed.

6. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your rice cooker.

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot:** The ceramic glazed non-stick inner pot is designed for easy cleaning. Wash it by hand with warm, soapy water and a soft sponge. Do not use abrasive cleaners or metal scouring pads, as these can damage the non-stick coating. Rinse thoroughly and dry.
3. **Lid:** Wash the lid and any removable accessories (like the inner cover) with warm, soapy water. Rinse and dry completely.
4. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid. Ensure no water enters the electrical components.

5. **Storage:** Store the rice cooker in a dry place when not in use.

7. TROUBLESHOOTING

If you encounter any issues with your THEGA Mini Rice Cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Rice cooker does not turn on.	No power supply.	Ensure the power cord is securely plugged into both the appliance and a working electrical outlet. Check the circuit breaker.
Rice is undercooked or too hard.	Insufficient water; incorrect rice-to-water ratio.	Add more water next time. Ensure the inner pot is properly seated.
Rice is overcooked or mushy.	Too much water; incorrect rice-to-water ratio.	Reduce water amount next time.
Food sticks to the inner pot.	Not enough water; cooking at too high a temperature for too long.	Ensure proper water levels. The ceramic non-stick coating should prevent sticking under normal use. Avoid using metal utensils.
Delay timer not working.	Incorrect setting; not activated.	Ensure the delay time is set correctly and the 'Start' button is pressed after setting the delay.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	THEGA
Model Name	Mini Rice Cooker
Capacity	1.6 Liters
Liner Material	Ceramic Glaze Non-Stick Liner
Lid Material	Ceramic
Special Features	Non-Stick, Portable, Timer, LED Display, Automatic Keep Warm
Product Care Instructions	Hand Wash
Item Weight	1800 Grams (3.97 pounds)
Included Components	Inner Pot, Instruction Manual
ASIN	B0BQ764CXV

Feature	Specification
Date First Available	December 15, 2022

9. WARRANTY AND SUPPORT

Specific warranty information for the THEGA Mini Rice Cooker (Model B0BQ764CXV) is not provided in this manual. For details regarding warranty coverage, please refer to the documentation included with your purchase or contact the retailer where the product was acquired.

For technical support, troubleshooting assistance beyond what is covered in this manual, or to inquire about replacement parts, please contact THEGA customer service through their official website or the contact information provided with your product packaging.

© 2023 THEGA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question