

Aideepen ESP8266 V3 ESP-12E

Aideepen ESP8266 V3 ESP-12E NodeMCU Development Board User Manual

Model: ESP8266 V3 ESP-12E

1. INTRODUCTION

The Aideepen ESP8266 V3 ESP-12E NodeMCU Development Board is a versatile Wi-Fi module designed for Internet of Things (IoT) applications. It integrates the ESP-12E module, offering full I/O port access and 802.11 wireless connectivity. This board features a built-in Micro-USB port, flash memory, and a reset switch, simplifying the programming process. It supports STA, AP, and STA+AP working modes, providing flexibility for various network configurations. Its low deep sleep current consumption makes it suitable for power-sensitive projects.




Figure 1: Top view of the ESP8266 V3 ESP-12E NodeMCU Development Board. This image shows the integrated ESP-12E module, Micro-USB port, and various pins.

2. FEATURES

- **Integrated ESP-12E Module:** Provides 802.11 b/g/n Wi-Fi connectivity.
- **Full I/O Port Support:** Access to all available input/output pins for project flexibility.
- **Micro-USB Port:** For power supply and data communication, facilitating easy programming.
- **Flash and Reset Switches:** Convenient buttons for programming and system reset.
- **Multiple Working Modes:** Supports Station (STA), Access Point (AP), and combined STA+AP modes.
- **Low Power Consumption:** Deep sleep current is approximately 10 μ A, and off current is less than 5 μ A.
- **Event-Driven API:** Accelerates IoT application development.

3. SETUP GUIDE

Follow these steps to set up your Aideepen ESP8266 V3 ESP-12E NodeMCU Development Board:

1. **Install CH340G Driver:** The board uses a CH340G USB-to-Serial chip. Before connecting the board to your computer, install the appropriate CH340G driver for your operating system. Drivers are typically available online from CH340G manufacturers or NodeMCU community resources.
2. **Connect the Board:** Use a Micro-USB cable to connect the NodeMCU board to your computer. Ensure the connection is secure.
3. **Configure IDE:** Open your preferred Integrated Development Environment (IDE), such as the Arduino IDE or VS Code with PlatformIO. Configure the IDE to recognize the ESP8266 board and select the correct COM port.
4. **Set Baud Rate:** For communication and flashing firmware, set the baud rate to 9600bps or higher, as required by your specific application or firmware.
5. **Upload Code:** You can now upload your code or firmware to the board. The built-in flash and reset switches simplify this process, often requiring no manual button presses during upload.




Figure 2: Front and back views of the NodeMCU board. The back of the board shows printed instructions for driver installation, baud rate, and Wi-Fi connection.

4. OPERATING INSTRUCTIONS

The NodeMCU ESP8266 V3 ESP-12E board is designed for flexible operation in various network

environments.

4.1. Network Modes

- **Station (STA) Mode:** In this mode, the ESP8266 connects to an existing Wi-Fi network (e.g., your home router) as a client device. It can then access the internet or communicate with other devices on that network.
- **Access Point (AP) Mode:** In AP mode, the ESP8266 creates its own Wi-Fi network, allowing other devices (like smartphones or computers) to connect directly to it. This is useful for direct device-to-device communication without an intermediary router.
- **STA+AP Mode:** This mode combines both Station and Access Point functionalities, allowing the ESP8266 to connect to an existing network while simultaneously hosting its own network.

4.2. Programming and Development

The board is compatible with various programming environments, including the Arduino IDE (with ESP8266 board support package) and NodeMCU Lua firmware. Developers can write code in C++ (Arduino) or Lua to control the board's functionalities, interact with sensors, and manage network communications.

Your browser does not support the video tag.

Video 1: An overview of the ESP8266 V3 ESP-12E NodeMCU Development Board. This video demonstrates the physical aspects and potential uses of the board.

5. PINOUT DIAGRAM

Understanding the pinout is essential for connecting peripherals and utilizing the full capabilities of the NodeMCU board. The board features 30 pins arranged in two rows.

PIN DEFINITION




Figure 3: Detailed pinout diagram of the ESP8266 V3 ESP-12E NodeMCU Development Board. This diagram labels each pin with its function, including GPIOs, power, and communication interfaces.

Key pin functions include:

- **GPIO (General Purpose Input/Output) Pins:** D0-D8, SDD0-SDD3, SDCMD, SDCLK, MOSI, MISO, SCLK, CS. These pins can be configured as inputs or outputs for connecting sensors, actuators, and other components.
- **Power Pins:** 3V3 (3.3V output), Vin (5V input via USB or external supply), GND (Ground).
- **Communication Pins:** RX (Receive), TX (Transmit) for serial communication.
- **Special Function Pins:** A0 (Analog Input), RST (Reset), EN (Enable), FLASH (Flash button), WAKE (Wake-up pin).

Important Note: The I/O pins operate at 3.3V. Applying 5V directly to these pins without a level shifter can damage the board.

6. SPECIFICATIONS

Feature	Specification
Model Name	ESP8266 V3 ESP-12E
Brand	Aideepen

Feature	Specification
Wireless Type	802.11b/g/n
Operating System	NodeMCU
CPU Manufacturer	Espressif
Connectivity Technology	WLAN, Wi-Fi
Item Weight	1.76 ounces (approx. 50g)
Package Dimensions	8.35 x 5.98 x 1.34 inches
Deep Sleep Current	10 μ A
Off Current	Less than 5 μ A

7. TROUBLESHOOTING

- **Board Not Detected by Computer:**
 - Ensure the CH340G driver is correctly installed.
 - Try a different Micro-USB cable; some cables are for charging only.
 - Test with a different USB port on your computer.
- **Code Upload Fails:**
 - Verify that the correct board type (ESP8266 NodeMCU 1.0 or similar) and COM port are selected in your IDE.
 - Check that the baud rate is set correctly (e.g., 115200 for uploads).
 - Ensure no other application is using the serial port.
- **Wi-Fi Connection Issues:**
 - Double-check Wi-Fi SSID and password in your code.
 - Ensure the Wi-Fi network is 2.4GHz, as ESP8266 does not support 5GHz.
 - Check signal strength and proximity to the access point.
- **Unexpected Behavior/Crashes:**
 - Review your code for errors, especially memory management.
 - Ensure adequate power supply. Insufficient power can cause instability.
 - Avoid applying 5V directly to 3.3V I/O pins without proper level shifting.

8. MAINTENANCE

To ensure the longevity and reliable operation of your NodeMCU Development Board, observe the following maintenance guidelines:

- **Handle with Care:** Avoid dropping the board or subjecting it to physical shock.
- **Static Discharge Protection:** Always handle the board in an anti-static environment or take precautions to prevent electrostatic discharge (ESD), which can damage electronic components.
- **Keep Dry:** Protect the board from moisture and humidity. Store it in a dry place.

- **Cleanliness:** Keep the board free from dust and debris. Use a soft, dry brush or compressed air for cleaning if necessary. Avoid using liquids.
- **Proper Power Supply:** Always use a stable and appropriate power supply (5V via Micro-USB or Vin pin). Over-voltage can cause irreversible damage.
- **Temperature Control:** Operate the board within its specified temperature range. Avoid extreme heat or cold.

9. WARRANTY AND SUPPORT

Aideepen provides customer support and warranty services for this product.

- **After-Sales Service:** You are entitled to 7*24 hours after-sales service and professional product usage guidance.
- **Warranty Period:** Each product purchased from Aideepen includes a 24-month service period.
- **Replacements:** A new replacement can be obtained if there is any quality issue with your item during the warranty period.
- **Contact Support:** For any issues or inquiries, please refer to the contact information provided with your purchase or visit the official Aideepen store page.