

[manuals.plus](#) /› [Jocel](#) /› [Jocel JFR011756 5-Liter 1450W Air Fryer User Manual](#)

Jocel JFR011756

Jocel JFR011756 5-Liter 1450W Air Fryer User Manual

Model: JFR011756

[Components](#) [Setup](#) [Operation](#) [Maintenance](#) [Safety Instructions](#) [Product Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Jocel JFR011756 Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, providing a healthier alternative to traditional frying. Please read this manual carefully before using the appliance to ensure safe and efficient operation. Keep this manual for future reference.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the basket is properly inserted and locked before operation.

- A short power-supply cord is provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.

3. PRODUCT COMPONENTS

Familiarize yourself with the main parts of your Jocel Air Fryer:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Digital display with touch controls for temperature, time, and pre-set functions.
- **Frying Basket:** Removable basket for holding food.
- **Handle:** For safely pulling out and inserting the frying basket.
- **Air Inlet/Outlet:** For proper air circulation during cooking.



Image 1: Front view of the Jocel JFR011756 Air Fryer showing the digital control panel and a hand interacting with it. The display shows '200' degrees Celsius.

4. SETUP AND FIRST USE

1. **Unpack:** Remove all packaging materials, stickers, and labels from the appliance.
2. **Clean:** Wash the frying basket and any removable parts with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance, and 10 cm (4 inches) above it, for proper ventilation.
4. **Pre-heat (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C

(350°F) to eliminate any manufacturing odors. A slight smell or smoke may occur, which is normal.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. **Prepare Food:** Place the food you wish to air fry into the frying basket. Do not overfill the basket to allow for proper air circulation.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks securely into place.
3. **Power On:** Plug the power cord into a grounded wall outlet. The control panel will illuminate.
4. **Set Temperature and Time:**
 - Use the temperature control buttons (usually '+' and '-') to set the desired cooking temperature.
 - Use the timer control buttons (usually '+' and '-') to set the desired cooking time.
5. **Start Cooking:** Press the Start/Pause button to begin the cooking process. The air fryer will start heating.
6. **Shake/Flip (Optional):** For even cooking, especially with smaller items like fries or nuggets, pull out the basket halfway through the cooking time and shake or flip the food. Reinsert the basket to resume cooking.
7. **Finish Cooking:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and transfer the cooked food to a plate.
8. **Power Off:** Unplug the appliance from the wall outlet after use.

5.2 Pre-set Functions

The Jocel JFR011756 Air Fryer features several pre-set cooking programs for common foods. These programs automatically set the optimal temperature and time. Refer to the control panel icons for specific functions (e.g., fries, chicken, fish, steak, cake, shrimp, vegetables).

- To use a pre-set function, simply press the corresponding icon on the control panel.
- You can usually adjust the time and temperature of a pre-set program manually after selecting it, if desired.



Image 2: The air fryer basket pulled out, containing a golden-brown roasted chicken, demonstrating cooking capacity.



Image 3: The air fryer basket pulled out, filled with crispy golden french fries, illustrating a common use.



Image 4: The air fryer basket pulled out, containing several cooked fish sticks or croquettes, showing versatility.

6. CLEANING AND MAINTENANCE

Clean the air fryer after every use.

- 1. Unplug and Cool:** Always unplug the appliance and allow it to cool down completely before cleaning.
- 2. Clean Basket:** Remove the frying basket. Wash it with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak the basket in hot water for about 10 minutes. The basket may also be dishwasher safe (check product markings).
- 3. Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or steel wool.
- 4. Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
- 5. Heating Element:** If necessary, gently clean the heating element with a cleaning brush to remove any food residue.
- 6. Storage:** Ensure all parts are dry before storing the appliance in a cool, dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken/flipped.	Do not overfill the basket. Shake or flip food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use. Fatty food being cooked.	Clean the basket and interior thoroughly after each use. For fatty foods, add a little water to the bottom of the outer pan to prevent smoke.
Food is not crispy.	Too much moisture in food. Not enough oil (if applicable). Temperature too low or time too short.	Pat food dry before air frying. Lightly spray or brush with oil. Increase temperature or cooking time.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Jocel
Model Number	JFR011756
Capacity	5 Liters
Power	1450 Watts
Material	Metal
Color	Black
Control Method	Touch
Special Feature	Child Lock
Product Dimensions (L x W x H)	33.5 x 27.5 x 30.4 cm (approx. 13.2 x 10.8 x 12 inches)
Item Weight	5 Kilograms (approx. 11 lbs)

9. WARRANTY AND SUPPORT

Jocel products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or contact Jocel customer support directly. For technical assistance, spare parts, or service inquiries, please visit the official Jocel website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.