

Seiko QHE198K

Seiko QHE198K Black Round Alarm Clock Instruction Manual

Model: QHE198K

INTRODUCTION

Thank you for choosing the Seiko QHE198K Black Round Alarm Clock. This manual provides detailed instructions for the proper setup, operation, and maintenance of your new clock. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

Please observe the following safety precautions to ensure safe and optimal use of your clock:

- Do not expose the clock to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping the clock or subjecting it to strong impacts.
- Keep the clock away from strong magnetic fields.
- Use only the specified battery type. Ensure correct polarity when inserting batteries.
- Remove depleted batteries promptly to prevent leakage and damage.
- Do not mix old and new batteries, or different types of batteries.
- Keep batteries out of reach of children.
- Do not attempt to disassemble or modify the clock.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Seiko QHE198K Black Round Alarm Clock
- Batteries (typically 1x AA, included)
- Instruction Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your Seiko QHE198K alarm clock.



Image: Front view of the Seiko QHE198K Black Round Alarm Clock, showing the analog dial with hour, minute, and continuous second hands, and the alarm setting hand. The clock features a black casing and a clear display.

Key Components:

- **Time Setting Knob:** Located on the back, used to adjust the current time.
- **Alarm Setting Knob:** Located on the back, used to set the desired alarm time.
- **Alarm ON/OFF Switch:** Located on the back or side, to activate or deactivate the alarm.
- **Snooze/Light Button:** Located on the top, press for temporary dial illumination and to activate snooze when the alarm sounds.
- **Battery Compartment:** Located on the back, for battery installation.

SETUP

1. Battery Installation

1. Open the battery compartment cover located on the back of the clock.
2. Insert the required batteries (typically 1x AA battery) according to the polarity indicators (+ and -).
3. Close the battery compartment cover securely.

2. Setting the Current Time

1. Locate the **Time Setting Knob** on the back of the clock.
2. Rotate the knob in either direction to move the hour and minute hands until the correct current time is displayed.

OPERATING INSTRUCTIONS

1. Setting the Alarm Time

1. Locate the **Alarm Setting Knob** on the back of the clock.
2. Rotate this knob to move the alarm hand to your desired alarm time.
3. Ensure the **Alarm ON/OFF Switch** is in the "ON" position to activate the alarm.

2. Using the Snooze Function

1. When the alarm sounds, press the large **Snooze/Light Button** on the top of the clock.
2. The alarm will temporarily stop and sound again after a few minutes (typically 5-10 minutes).
3. To turn off the alarm completely, move the **Alarm ON/OFF Switch** to the "OFF" position.

3. Dial Illumination

1. To illuminate the clock dial in low light conditions, press and hold the **Snooze/Light Button** on the top of the clock.
2. The light will remain on as long as the button is pressed. Release the button to turn off the light.

MAINTENANCE

Cleaning

- Wipe the clock's surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish.

Battery Replacement

- When the clock's display becomes dim, the alarm weakens, or the clock stops functioning, it is time to replace the batteries.
- Follow the battery installation steps outlined in the "Setup" section.
- Dispose of used batteries according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not working / Hands not moving	Dead or incorrectly inserted batteries.	Check battery polarity or replace with new batteries.

Problem	Possible Cause	Solution
Alarm does not sound	Alarm switch is OFF; alarm time not set correctly; low battery.	Ensure alarm switch is ON. Verify alarm hand position. Replace batteries.
Dial illumination is dim or not working	Low battery power.	Replace batteries.
Clock runs too fast or too slow	Extremely low battery power; exposure to extreme temperatures.	Replace batteries. Ensure clock is in a stable environment. If problem persists, contact support.

SPECIFICATIONS

Feature	Detail
Brand	Seiko
Model Number	QHE198K
Colour	Black
Display Type	Analog
Special Features	Alarm, Snooze, Dial Illumination, Continuous Second Hand
Product Dimensions (W x H x D)	11.3 cm x 9.9 cm x 4.5 cm (approx. 4.45" x 3.9" x 1.8")
Item Weight	0.16 Kilograms
Power Source	Battery Powered
Material Type	Plastic
Mounting Type	Tabletop
Watch Movement	Quartz

WARRANTY AND SUPPORT

Seiko products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or visit the official Seiko website. If you encounter any issues or require further assistance, please contact Seiko customer support through their official website or the retailer where you purchased the product. Please have your model number (QHE198K) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question