

[Manuals.plus](#) /

› [uxcell](#) /

› uxcell B102 Fader Variable Resistor Instruction Manual

## uxcell B102

# uxcell B102 Fader Variable Resistor Instruction Manual

Model: B102 | 1K Ohm Linear Single Slide Potentiometer

## INTRODUCTION

The uxcell B102 Fader Variable Resistor is a linear slide potentiometer designed for precise control in various electronic applications. This component provides a linearly changing resistance as its fader is moved, making it ideal for smooth adjustments. It is commonly used for dimming, tuning, and adjusting parameters such as volume, tone, and balance in devices like audio mixers, electronic organs, and guitars.




Image: Top-down view of the uxcell B102 Fader Variable Resistor, showing the slide mechanism and overall form factor.

## SETUP AND INSTALLATION

The uxcell B102 slide potentiometer is an electronic component intended for integration into custom circuits or as a replacement part. Proper installation requires soldering skills and adherence to circuit design specifications.

1. **Preparation:** Ensure your circuit board is clean and prepared for component installation. Identify the correct mounting points for the potentiometer's pins.
2. **Orientation:** Carefully align the potentiometer with the designated pads on the circuit board. The pins must match the corresponding holes or pads.
3. **Soldering:** Solder each pin securely to the circuit board. Use appropriate soldering techniques to ensure strong electrical and mechanical connections, avoiding cold joints or solder bridges.
4. **Verification:** After soldering, visually inspect all connections. Use a multimeter to check for continuity and ensure there are no short circuits between adjacent pins.



Image: Bottom view of the uxcell B102 Fader Variable Resistor, illustrating the pin configuration for circuit board mounting.

## OPERATING INSTRUCTIONS

Once installed, the uxcell B102 potentiometer functions as a variable resistor within your electronic circuit. Its operation is straightforward:

- **Sliding the Fader:** To adjust the resistance, gently slide the black fader knob along its track. Moving the fader from one end to the other will cause the resistance to change linearly.
- **Parameter Control:** The specific effect of the fader movement depends on how it is integrated into your circuit. For example, in an audio circuit, sliding the fader might increase or decrease volume; in a lighting circuit, it could adjust brightness.
- **Linear Response:** Due to its linear characteristic, the change in resistance is proportional to the distance the fader is moved, providing smooth and predictable control.




Image: Side view of the uxcell B102 Fader Variable Resistor, showing the fader knob and the track it slides along.

## MAINTENANCE

To ensure the longevity and optimal performance of your uxcell B102 Fader Variable Resistor, follow these maintenance guidelines:

- **Keep Clean:** Protect the potentiometer from dust, dirt, and moisture. Accumulation of debris within the slide mechanism can affect performance and lead to erratic readings. Use compressed air or a soft brush for cleaning.
- **Avoid Force:** Do not apply excessive force when sliding the fader knob. Rough handling can damage the internal resistive track or the mechanical slide mechanism.
- **Lubrication (if necessary):** If the fader movement becomes stiff over time, a very small amount of electronic-grade lubricant specifically designed for potentiometers may be applied to the slide track. Ensure the lubricant does not come into contact with the electrical resistive element.

## TROUBLESHOOTING

If you encounter issues with your uxcell B102 Fader Variable Resistor, consider the following troubleshooting steps:

- **No Response:** If the potentiometer shows no change in resistance or no effect on the circuit, check all soldered connections for integrity. Verify that the component is correctly wired into the circuit.
- **Erratic Behavior:** Inconsistent or jumpy readings may indicate dirt or corrosion on the resistive track. Try cleaning the fader mechanism as described in the Maintenance section. Damage to the resistive element can also cause this.
- **Incorrect Resistance:** Use a multimeter to measure the resistance across the appropriate pins. Ensure the measured resistance matches the specified 1K Ohm value (within tolerance). If it's significantly off, the component may be faulty.
- **Stiff Movement:** If the fader is difficult to move, refer to the lubrication advice in the Maintenance section.

## SPECIFICATIONS

| Feature              | Detail                                                                                |
|----------------------|---------------------------------------------------------------------------------------|
| Model                | B102                                                                                  |
| Resistance Value     | 1K Ohm                                                                                |
| Resistance Tolerance | +/-10%                                                                                |
| Type                 | Linear Potentiometer                                                                  |
| Connection Type      | Single, Mono                                                                          |
| Body Size (L*W*H)    | 18mm x 5mm x 5mm                                                                      |
| Shaft Size (L*W*T)   | 5mm x 3mm x 1.5mm                                                                     |
| Typical Applications | Dimming, Tuning, Volume, Tone, Balance control in mixers, electronic organs, guitars. |




Image: Detailed view of the uxcell B102 Fader Variable Resistor with key dimensions (18mm length, 5mm width, 5mm height, 3mm shaft width) labeled for reference.



Image: The uxcell B102 Fader Variable Resistor shown in a gloved hand, providing a visual reference for its compact size.

## WARRANTY INFORMATION

Specific warranty details for the uxcell B102 Fader Variable Resistor may vary depending on the retailer and region of purchase. Please refer to your point of purchase documentation or the official uxcell website for comprehensive warranty terms and conditions.

## CUSTOMER SUPPORT

For technical assistance, product inquiries, or support regarding the uxcell B102 Fader Variable Resistor, please contact uxcell customer service. You can typically find contact information on the official uxcell website or through the retailer from whom you purchased the product.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question