



Manuals.plus /

› Gaabor /

› Gaabor M4D02A 3.5L 1200W Air Fryer User Manual

## Gaabor M4D02A

# Gaabor M4D02A 3.5L 1200W Air Fryer User Manual

Model: M4D02A

## 1. INTRODUCTION

---

Thank you for choosing the Gaabor M4D02A 3.5L 1200W Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods by using 360° three-dimensional air circulation with Cyclone Air technology, reducing the need for oil. Please read this manual carefully before use to ensure safe and efficient operation.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

- Always place the air fryer on a stable, heat-resistant surface, away from walls and other appliances to allow for proper ventilation.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting. This model operates at 110V.
- Keep children and pets away from the appliance during operation.
- Do not block the air inlet or outlet vents.
- Unplug the air fryer from the outlet when not in use and before cleaning. Allow it to cool completely before handling.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Never use accessories or parts not recommended by the manufacturer.
- The appliance is for household use only. Do not use outdoors.
- Exercise extreme caution when removing the hot basket or disposing of hot grease.

## 3. PRODUCT OVERVIEW

---

The Gaabor M4D02A Air Fryer features a compact design with intuitive controls and efficient air circulation for optimal cooking results.

## Components

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Features dual analog knobs for time and temperature, and preset icons.
- **Frying Basket:** Removable basket with a non-stick coating and grate for holding food.
- **Handle:** Ergonomically designed for safe removal of the frying basket.

## Control Panel and Features

The air fryer is equipped with an inclined control panel for ease of use and dual analog knobs for precise adjustments.



Image: Gaabor M4D02A Air Fryer showing its inclined control panel for easy access.

# TECNOLOGIA GAABOR CYCLONE AIR™

## BLOQUEIO DE FRESCOR DOS ALIMENTOS COM A CIRCULAÇÃO 360°

Duto de turbina de 9 lâminas, ar quente em vez de fritar



Image: Close-up of the dual analog knobs for setting time and temperature.

The control panel includes icons for 8 common cooking presets, providing guidance for various dishes. The dual analog knobs allow for manual adjustment of cooking time and temperature to suit your specific needs.

### **Cyclone Air Technology**

This air fryer utilizes advanced Cyclone Air technology with a 9-blade turbine duct to ensure 360° three-dimensional air circulation. This rapid hot air circulation cooks food evenly and thoroughly, achieving crispy results with little to no oil.

# TECNOLOGIA GAABOR CYCLONE AIR™

## BLOQUEIO DE FRESCOR DOS ALIMENTOS COM A CIRCULAÇÃO 360°

Duto de turbina de 9 lâminas, ar quente em vez de fritar



Image: Diagram showing the 360° Cyclone Air circulation technology inside the air fryer.

## 4. SETUP

---

### Unpacking

1. Carefully remove the air fryer and all packaging materials from the box.
2. Remove any stickers or labels from the appliance.
3. Check that all components are present and undamaged.

### Before First Use

1. Clean the frying basket and grate thoroughly with hot water, dish soap, and a non-abrasive sponge.
2. Wipe the inside and outside of the appliance with a damp cloth.
3. Ensure all parts are completely dry before use.
4. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the appliance.

## 5. OPERATING INSTRUCTIONS

---

### Basic Operation

1. Plug the power cord into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place your ingredients into the frying basket. Do not exceed the MAX fill line.
4. Slide the frying basket back into the air fryer until it clicks into place.
5. Turn the temperature knob to your desired temperature.
6. Turn the timer knob to your desired cooking time. The air fryer will automatically start heating.
7. During cooking, you can pull out the basket to shake or turn food. The air fryer will automatically pause and resume once the basket is reinserted.
8. When the timer reaches zero, the air fryer will emit a sound and automatically shut off.
9. Carefully pull out the basket and transfer the cooked food to a plate.

Image: The air fryer automatically pauses operation when the basket is pulled out, enhancing safety during cooking.

### Cooking Guide (Preset Icons)

The control panel features 8 preset icons for common foods. These are general guidelines; actual cooking times and temperatures may vary based on food quantity and desired crispness.



Image: Examples of different foods that can be cooked in the air fryer with suggested temperatures and times.

## Example Cooking Settings

Food Type	Temperature	Time
Steamed Vegetables	200°C	2-5 min
Fried Chicken	200°C	10-12 min
Cakes	200°C	19-21 min
Kebabs	180°C	9-10 min

## 6. MAINTENANCE AND CLEANING

---

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

### Cleaning the Frying Basket and Grate

1. Unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the frying basket and grate.
3. Wash the basket and grate with hot water, dish soap, and a non-abrasive sponge. The non-stick coating makes cleaning easy.
4. For stubborn food residue, soak the basket and grate in hot water with dish soap for about 10 minutes.
5. Rinse thoroughly and dry completely before reassembling.

### Cleaning the Interior and Exterior

1. Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasives or metal scouring pads.
2. Clean the interior of the appliance with a damp cloth and mild detergent.
3. Ensure no water enters the heating element or fan area.
4. Dry all surfaces thoroughly.

## 7. TROUBLESHOOTING

---

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

## Troubleshooting Guide

Problem	Possible Cause	Solution
Air fryer does not turn on	Not plugged in; Power outlet malfunction; Basket not fully inserted.	Ensure the power cord is securely plugged in. Check the power outlet with another appliance. Push the frying basket completely into the appliance.
Food is not cooked evenly	Too much food in the basket; Food not shaken or turned.	Cook smaller batches. Shake or turn food halfway through the cooking process.
White smoke coming from the appliance	Grease residue from previous use; Fatty ingredients.	Clean the basket and interior thoroughly after each use. For fatty foods, drain excess oil from the basket.
Food not crispy	Temperature too low; Cooking time too short; Moisture in food.	Increase temperature or cooking time. Pat food dry before air frying.

## 8. SPECIFICATIONS

---

### Gaabor M4D02A Air Fryer Specifications

Feature	Detail
Model Number	M4D02A
Capacity	3.5 Liters
Power	1200 Watts
Voltage	110 Volts
Dimensions (D x W x H)	36 x 26 x 33.5 cm
Weight	3.54 Kilograms
Control Method	Analog Knobs
Air Frying Technology	Cyclone Air
Material	Plastic
Non-stick Coating	Yes

## 9. WARRANTY AND SUPPORT

---

### Warranty Information

All Gaabor products come with a 3-month warranty from the retailer and a 1-year manufacturer's warranty for factory defects. This warranty does not cover damage resulting from misuse, improper handling, or unauthorized repairs.

### Customer Support

For any questions, concerns, or warranty claims, please contact Gaabor customer support through the official

website or your point of purchase. Please have your model number (M4D02A) and proof of purchase ready.