

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [WulaWindy](#) /

› [WulaWindy Digital Alarm Clock User Manual \(Model: yishang\)](#)

WulaWindy yishang

WulaWindy Digital Alarm Clock User Manual

MODEL: YISHANG

Introduction

Thank you for choosing the WulaWindy Digital Alarm Clock. This device combines a large mirrored LED display with practical features such as dual USB charging ports, adjustable brightness, and a convenient snooze function. This manual provides detailed instructions to help you set up, operate, and maintain your new alarm clock.

For optimal performance, please read this manual thoroughly before use and retain it for future reference.

Product Features

- **Easy Operation:** Features only 3 buttons for straightforward setting of time, alarm, and brightness.
- **Large Mirrored LED Display:** A 6.5-inch screen with large numbers for easy readability, also functions as a mirror.
- **Adjustable Brightness:** Offers three manual brightness levels (Dim, Medium, Bright) and an automatic dimming mode for night.
- **Dual USB Charging Ports:** Two USB ports allow simultaneous charging of two devices.
- **Memory Battery Backup:** Includes a backup battery (CR2016) to retain time settings during power outages. Note: The clock requires USB power to operate.
- **Super Convenient Snooze Button:** A large, easily accessible snooze button for 5-60 minute nap intervals.

Package Contents

- WulaWindy Digital Alarm Clock
- USB Power Cable
- Detachable Stand
- CR2016 Backup Battery (pre-installed)
- User Manual

Setup

1. **Unpack the Clock:** Carefully remove the alarm clock and all accessories from the packaging.
2. **Remove Protective Films:** Peel off any protective films from the mirrored display surface.
3. **Activate Backup Battery:** Locate the battery compartment on the back of the clock. Remove the plastic insulator tab from the pre-installed CR2016 battery. This battery maintains time settings during power interruptions.
4. **Connect Power:** Plug the provided USB power cable into the input port on the side of the alarm clock. Connect the other end of the USB cable to a USB power adapter (not included) or a powered USB port. The clock display will illuminate.
5. **Attach Stand (Optional):** If using the clock on a desk or bedside table, attach the detachable stand to the bottom of the clock for stable positioning. The clock can also be wall-mounted using the keyhole slot on the back.



The alarm clock features dual USB charging ports for convenience, along with instructions to remove protective films and battery insulator tab before use.

Operating Instructions

Button Overview

The alarm clock features three main control buttons on the side and a large snooze button on top:

- **MODE Button (M):** Used to switch between time, alarm, and brightness settings.
- **UP Button (+):** Used to increase values or navigate options.
- **DOWN Button (-):** Used to decrease values or navigate options.
- **SNOOZE Button:** Located on top, used to activate snooze or adjust display color (if applicable).



Detailed diagram showing the location and function of the control buttons (Mode, Up, Down) and USB ports.

Setting the Time

1. Press the **MODE (M)** button once to enter time setting mode. The hour digits will flash.
2. Use the **UP (+)** or **DOWN (-)** buttons to adjust the hour.
3. Press the **MODE (M)** button again to set the minutes. The minute digits will flash.
4. Use the **UP (+)** or **DOWN (-)** buttons to adjust the minutes.
5. Press the **MODE (M)** button a third time to confirm the time and exit time setting mode.
6. To switch between 12-hour and 24-hour format, press and hold the **MODE (M)** button while in normal time display mode.

Setting the Alarm

1. Press the **MODE (M)** button twice to enter alarm setting mode. The alarm hour digits will flash, and an 'AL' indicator will appear.
2. Use the **UP (+)** or **DOWN (-)** buttons to adjust the alarm hour.
3. Press the **MODE (M)** button again to set the alarm minutes. The alarm minute digits will flash.
4. Use the **UP (+)** or **DOWN (-)** buttons to adjust the alarm minutes.
5. Press the **MODE (M)** button a third time to confirm the alarm time.
6. To activate or deactivate the alarm, press the **DOWN (-)** button while in normal time display mode. An alarm icon will appear on the display when the alarm is active.

Brightness Adjustment

The clock offers both manual and automatic brightness control:

- **Manual Brightness:** In normal time display mode, press the **UP (+)** button to cycle through three brightness levels: Dim, Medium, and Bright.
- **Automatic Dimming:** The clock can automatically adjust its brightness based on ambient light. To enable this, ensure the light sensor (located on the side) is unobstructed. The display will automatically dim at night.



Illustration of the three adjustable brightness levels (Dim, Medium, Bright) and automatic dimming feature.

Snooze Function

When the alarm sounds, press the large **SNOOZE** button on top of the clock to activate the snooze function. The alarm will pause and sound again after the set snooze interval (default is 5 minutes, adjustable up to 60 minutes). To turn off the alarm completely, press any other button on the side of the clock.



The large snooze button located on top of the clock for easy access.

USB Charging Ports

The alarm clock is equipped with two USB charging ports on its side. These ports can be used to charge your mobile devices, smartwatches, or other USB-powered gadgets while the alarm clock is plugged into a power source.



The alarm clock features dual USB charging ports for convenience.

Product Overview Video

Your browser does not support the video tag.

Official product video demonstrating the WulaWindy Digital Alarm Clock's features, including its large display, automatic dimming, snooze function, and dual USB charging ports.

Maintenance

- **Cleaning:** Wipe the display and body of the clock with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Battery Replacement:** The CR2016 backup battery should last for several years. If the clock loses time settings during a power outage, replace the battery. To replace, open the battery compartment on the back, remove the old battery, and insert a new CR2016 battery with the positive (+) side facing up.
- **Storage:** If storing the clock for an extended period, disconnect it from power and remove the backup battery.

Troubleshooting

Problem	Solution
Clock display is off.	Ensure the USB power cable is securely connected to both the clock and a working power source. The clock requires continuous USB power to display time.
Time settings are lost after power outage.	The CR2016 backup battery may be depleted. Replace the battery as described in the Maintenance section.
Alarm does not sound.	Ensure the alarm is activated (alarm icon visible on display). Verify the alarm time is set correctly.
Display is too dim or too bright.	Press the UP (+) button to cycle through manual brightness levels. If using auto-dimming, ensure the light sensor on the side is not obstructed.
USB charging ports are not working.	Ensure the alarm clock is powered via its USB cable. The charging ports only function when the clock is receiving power.

Specifications

Feature	Detail
Brand	WulaWindy
Model Number	yishang
Display Type	Digital LED, Mirrored Surface
Product Dimensions	6.7"W x 3.7"H
Power Source	Corded Electric (USB), Battery Powered (for memory backup)
Backup Battery	1 x CR2016 (included)
Special Features	Alarm, Snooze, Dual USB Charging, Adjustable Brightness, Auto-Dimming
Mounting Type	Desk Clock, Wall Mount
Material	Acrylonitrile Butadiene Styrene
Item Weight	6.7 ounces

Warranty and Support

WulaWindy products are designed for quality and reliability. For any questions, technical support, or warranty claims, please refer to the contact information provided with your purchase or visit the official WulaWindy store on Amazon.

We are committed to ensuring 100% user satisfaction.