

[Manuals.plus](#) /

› [DWT](#) /

› DWT Inverter Welding Machine MMA-400SV 300 Amp 220/380V User Manual

DWT MMA-400SV

DWT Inverter Welding Machine MMA-400SV User Manual

Model: MMA-400SV

1. IMPORTANT SAFETY INFORMATION

Before operating this DWT Inverter Welding Machine, it is crucial to read and understand all instructions and safety warnings provided in this manual. Failure to follow these guidelines may result in serious injury or equipment damage.

- Always read and follow the manufacturer's instructions for the welding machine and all accessories.
- Observe all applicable safety practices and consult Material Safety Data Sheets (MSDS) for welding materials.
- Only qualified personnel should install, operate, or service this equipment.




Image: Packaging box of the DWT MMA-400SV Inverter Welding Machine, displaying various safety warnings and pictograms. These warnings include precautions against electric shock, welding fumes, arc rays, fire hazards, noise, falling objects, and magnetic fields. Always refer to the full safety manual for detailed instructions.

Safety Pictograms Explained:

- **Electric Shock:** Risk of severe electric shock. Ensure proper grounding and insulation.
- **Welding Fumes:** Inhale welding fumes can be hazardous. Work in a well-ventilated area or use fume extraction.
- **Arc Rays:** Arc rays can burn eyes and skin. Use appropriate welding helmet and protective clothing.

- **Fire Hazard:** Welding can cause fire or explosions. Keep flammable materials away from the welding area.
- **Noise:** High noise levels can damage hearing. Wear hearing protection.
- **Falling Objects:** Be aware of falling objects in the work area.
- **Magnetic Fields:** Magnetic fields can affect pacemakers. Consult a doctor before welding.
- **Hot Parts:** Welding equipment can become very hot. Avoid contact with hot parts.

2. SETUP AND INSTALLATION

Proper setup is essential for safe and efficient operation of your DWT MMA-400SV welding machine.

2.1 Unpacking and Inspection

- Carefully remove the welding machine and all accessories from the packaging.
- Inspect the machine for any signs of damage that may have occurred during shipping. If damage is found, do not operate the machine and contact your supplier immediately.
- Ensure all components listed in the packing list are present.

2.2 Power Connection

The DWT MMA-400SV welding machine operates on a dual voltage input. Ensure your power supply matches the machine's requirements.

- **Input Voltage:** 220V / 380V AC
- **Frequency:** 50/60 Hz
- Connect the power cable to a suitable, grounded power outlet. Use an appropriate plug for your region and voltage.
- Ensure the power circuit can handle the machine's maximum current draw (up to 300 Amps).

2.3 Welding Cable Connections

- Connect the electrode holder cable to the positive (+) terminal on the front panel.
- Connect the earth clamp cable to the negative (-) terminal on the front panel.
- Ensure all connections are tight and secure to prevent arcing and overheating.

3. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your DWT MMA-400SV welding machine.

3.1 Powering On

- Ensure all connections are secure and the work area is safe.
- Turn on the main power switch, usually located on the rear panel of the machine.
- The digital display on the front panel should illuminate, indicating the machine is ready.

3.2 Setting Welding Parameters

Adjust the welding current (amperage) based on the type and thickness of the material being welded and the electrode size.

- Use the control knob on the front panel to set the desired amperage. The display will show the current setting.
- **Amperage Range:** 35 - 250 Amps
- **Output Voltage Range:** 21.4 - 30 Volts
- Refer to electrode manufacturer guidelines for recommended current settings.

3.3 Welding Process (MMA/Stick Welding)

- Securely clamp the earth clamp to the workpiece, ensuring good electrical contact.
- Insert the appropriate electrode into the electrode holder.
- Position yourself comfortably and safely, wearing all necessary Personal Protective Equipment (PPE).
- Strike an arc by gently touching the electrode to the workpiece and quickly lifting it slightly to maintain the arc.
- Maintain a consistent arc length and travel speed for optimal weld quality.

3.4 Powering Off

- After welding, turn off the main power switch on the machine.
- Disconnect the power cable from the wall outlet.
- Allow the machine to cool down before storing.

4. MAINTENANCE

Regular maintenance ensures the longevity and reliable performance of your DWT MMA-400SV welding machine.

4.1 Daily Maintenance

- Clean the machine exterior with a dry, soft cloth.
- Inspect welding cables, electrode holder, and earth clamp for damage or wear. Replace if necessary.
- Check for loose connections.

4.2 Periodic Maintenance (Monthly/Quarterly)

- Use compressed air to blow out dust and debris from inside the machine, especially from cooling vents. Ensure the machine is unplugged before doing this.
- Inspect internal components for signs of overheating or damage. This should ideally be done by qualified personnel.
- Check the power cord for any cuts or fraying.

4.3 Storage

- Store the welding machine in a clean, dry, and dust-free environment.

- Protect it from extreme temperatures and humidity.

5. TROUBLESHOOTING

This section provides solutions to common issues you might encounter with your DWT MMA-400SV welding machine.

Problem	Possible Cause	Solution
Machine does not power on	No power supply; Faulty power cable; Internal fuse blown	Check power outlet and circuit breaker; Inspect power cable; Contact qualified service personnel.
No welding arc	Poor earth clamp connection; Incorrect amperage setting; Wet or faulty electrode	Ensure good contact for earth clamp; Adjust amperage; Use dry, suitable electrodes.
Weak or unstable arc	Low input voltage; Long or thin welding cables; Incorrect arc length	Verify power supply; Use appropriate cable gauge and length; Adjust arc length.
Overheating indicator on	Exceeded duty cycle; Blocked cooling vents; High ambient temperature	Allow machine to cool down; Clean cooling vents; Operate in a cooler environment.

If you encounter problems not listed here or if solutions do not resolve the issue, please contact DWT customer support or a qualified service technician.

6. SPECIFICATIONS

Detailed technical specifications for the DWT Inverter Welding Machine MMA-400SV.



Image: Product label from the DWT MMA-400SV Inverter Welding Machine packaging, showing detailed technical specifications including voltage, frequency, amperage range, and weights.

Specification	Value
Model Number	MMA-400SV
Manufacturer	DWT
Input Voltage	220/380V AC
Frequency	50/60 Hz
Amperage Range	35-250A
Output Voltage	21.4-30V
Net Weight	13.5 kg
Gross Weight	16.6 kg
Shipping Dimensions	55 x 50 x 40 cm
Included Components	Tools
Batteries Required	No
First Available Date	February 16, 2023

7. WARRANTY AND SUPPORT

Information regarding product warranty and customer support is typically provided with your purchase documentation or on the manufacturer's official website.

- For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official DWT website.
- For technical support, service, or spare parts, contact DWT customer service through their official channels.