

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LIORQUE](#) /

› [LIORQUE Kitchen Timer User Manual](#)

LIORQUE YGH5270

LIORQUE Kitchen Timer User Manual

Model: YGH5270

1. PRODUCT OVERVIEW

The LIORQUE Kitchen Timer is a versatile digital timer designed for various time management needs, including cooking, studying, and fitness. It features a large LCD display, adjustable volume levels, and multiple placement options for convenience.



Figure 1: Front view of the LIORQUE Kitchen Timer.

2. KEY FEATURES

- **3-Level Volume Adjustment:** Choose between silent, medium (65dB), and high (85dB) alarm volumes to suit your environment.
- **Multi-functionality:** Operates as a countdown/count-up timer, a digital clock, and an alarm clock.
- **Quick Setting:** Dedicated H (Hours), M (Minutes), and S (Seconds) buttons for fast time input. Long press to quickly increase values.
- **Multiple Placement Options:** Features a strong magnetic back for attachment to metal surfaces, a foldable stand for tabletop use, and a hanging hole for hooks.
- **Extended Battery Life:** Designed for low power consumption, providing up to 6 months or more of operation on two AAA batteries.
- **Large LCD Display:** Clear and easy-to-read numbers for optimal visibility.



Figure 2: Visual representation of key features.

3. PACKAGE CONTENTS

- 1 x LIORQUE Kitchen Timer (Model YGH5270)
- 2 x AAA Batteries

4. SETUP

4.1 Battery Installation

The timer requires two AAA batteries for operation. These are included in the package.

1. Locate the battery compartment on the back of the timer.
2. Open the foldable stand to access the battery cover.

3. Push down on the battery cover and slide it off.
4. Insert two AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery cover and close the foldable stand.

Note: If the display shows "88:88:88", it indicates that the batteries need to be replaced.

4.2 Placement Options

The LIORQUE Kitchen Timer offers flexible placement options:

- **Magnetic Attachment:** Use the strong magnet on the back to fix the timer to metallic surfaces like refrigerators or ovens.
- **Foldable Stand:** Extend the integrated stand to place the timer upright on any flat surface, such as a countertop or desk.
- **Hanging Hole:** Utilize the small hole on the back to hang the timer on a hook or string.

Strong Magnetic, Easy to Fix



Hook Design, Multi-scene Use



Figure 3: Magnetic placement on a refrigerator.



Figure 4: Rear view showing magnetic and stand features.

5. OPERATING INSTRUCTIONS

5.1 Switching Modes (Timer, Clock, Alarm)

The LIORQUE Kitchen Timer has three main modes: Timer, Clock, and Alarm. To switch between these modes:

- **Timer Mode:** This is the default mode for countdown and count-up functions.
- **Clock Mode:** Displays the current time. To switch from Timer mode to Clock mode, **long press** the **ST/SP** button for 2 seconds.
- **Alarm Mode:** Allows setting an alarm time. While in Clock mode, **short press** the **ST/SP** button to switch to Alarm mode.
- To return to Timer mode from Clock or Alarm mode, **long press** the **ST/SP** button again.

3 Modes Switch



- Long press for 2 seconds to switch clock / timer modes.
- Short press [ST/SP] to set alarm clock in clock mode.

Timer:



Clock:



Alarm:



Figure 5: Switching between Timer, Clock, and Alarm modes.

5.2 Setting the Timer (Countdown)

To set a countdown time:

1. Ensure the timer is in Timer mode. If not, long press **ST/SP** to switch.

2. Press the **H** button to set hours, **M** for minutes, and **S** for seconds. Long press any button to increase the value rapidly.
3. To clear the set time to 00:00:00, press the **H** and **M** buttons simultaneously.
4. Press the **ST/SP** button to start the countdown.
5. To pause the countdown, press **ST/SP** again. Press it once more to resume.
6. When the countdown reaches 00:00:00, the alarm will sound (if not in silent mode).
7. To stop the alarm and restore the previously set countdown time, press **ST/SP**. This allows for quick reuse of the same timer setting.

Smart Setting



① When the countdown is over

00:00:00

② Press **[ST/SP]** to restore to the set time

ST/SP

① Easy to Use, in counting mode

99:59:59

② Press **[H]** & **[M]** and time return to 00:00



Figure 6: Restoring set time after countdown.

5.3 Using the Stopwatch (Count-up)

To use the timer as a stopwatch:

1. Ensure the timer is in Timer mode and the display shows 00:00:00. If not, press **H** and **M** simultaneously to clear.
2. Press the **ST/SP** button to start the count-up.

3. To pause the stopwatch, press **ST/SP** again. Press it once more to resume.
4. To reset the stopwatch to 00:00:00, press **H** and **M** simultaneously while the stopwatch is paused or running.

Smart Setting



① *When the countdown is over*



② *Press **[ST/SP]** to restore to the set time*



① *Easy to Use, in counting mode*



② *Press **[H]** & **[M]** and time return to 00:00*



Figure 7: Clearing the timer display.

5.4 Adjusting Volume

The timer features a physical switch on the right side to adjust the alarm volume:

- **Silent Mode:** Ideal for quiet environments like libraries or study rooms, ensuring no disturbance.
- **Medium Volume (65dB):** Suitable for general use, providing an audible alert without being overly loud.
- **High Volume (85dB):** Designed for noisy environments such as busy kitchens, ensuring the alarm is clearly heard.

3-Level Alarm Volume Adjustment



Mute

*Exams / Public Place /
Library / Etc.*



Soft

Naps / Children / Etc.



Loud

*Cooking / Fitness /
Elder People / Etc.*



5.5 Setting the Clock and Alarm

To set the current time and an alarm:

1. Setting Clock Time:

- Long press **ST/SP** to enter Clock mode.
- Press **H** to set hours, **M** for minutes, and **S** for seconds.
- The clock supports 12-hour and 24-hour formats.

2. Setting Alarm Time:

- While in Clock mode, short press **ST/SP** to enter Alarm mode.
- Press **H** to set alarm hours, **M** for alarm minutes.
- To activate or deactivate the alarm, press the **S** button. An alarm icon will appear/disappear on the display.

6. MAINTENANCE

To ensure the longevity and proper functioning of your LIORQUE Kitchen Timer:

- Clean the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- Avoid exposing the timer to extreme temperatures or direct sunlight for prolonged periods.
- If the timer will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Display shows "88:88:88".	Low battery power.	Replace the two AAA batteries.
Timer not responding to button presses.	Batteries are dead or incorrectly installed.	Check battery polarity or replace batteries.
Alarm is too quiet or too loud.	Volume setting is not optimal for the environment.	Adjust the volume switch on the right side of the timer to Silent, Medium, or High.
Cannot clear the timer display.	Incorrect button combination used.	Press the H and M buttons simultaneously to clear the time.

8. SPECIFICATIONS

Attribute	Detail
Brand	LIORQUE
Model Number	YGH5270
Colour	Black
Product Dimensions	2.3 x 7.1 x 9 cm (0.9 x 2.8 x 3.5 inches)

Attribute	Detail
Item Weight	110 g (3.88 ounces)
Material	Acrylonitrile Butadiene Styrene (ABS)
Power Source	2 x AAA Batteries (Included)
Max Countdown/Count-up	99 Hours, 59 Minutes, 59 Seconds
Volume Levels	Silent, Medium (65dB), High (85dB)

9. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the product packaging or contact the seller directly through your purchase platform. Ensure you have your product model number (YGH5270) and purchase details ready when contacting support.