

## PHILIPS HD9285/94

# Philips Airfryer HD9285/94 User Manual

Model: HD9285/94

[Introduction](#)   [Safety Information](#)   [Components](#)   [Setup](#)   [Operating](#)  
[Instructions](#)   [Maintenance](#)   [Troubleshooting](#)   [Specifications](#)   [Warranty & Support](#)

## 1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Philips Airfryer HD9285/94. This appliance utilizes Rapid Air Technology to cook food with up to 90% less fat compared to traditional deep frying, offering a healthier alternative for various dishes. With a generous 7.2-liter capacity and 2000W power, it is designed for versatile cooking, including frying, baking, grilling, roasting, dehydrating, reheating, and steaming. The Airfryer also features Wi-Fi connectivity, allowing integration with the NutriU app for enhanced control and access to recipes.



Image 1.1: The Philips Airfryer HD9285/94 positioned on a kitchen counter, surrounded by various fresh ingredients, illustrating its

## 2. IMPORTANT SAFETY INFORMATION

---

Before using the appliance, please read this user manual carefully and save it for future reference. Incorrect use can lead to electric shock, fire, or serious injury.

- Always place the appliance on a stable, horizontal, and level surface.
- Do not immerse the appliance in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate the appliance if the plug, main cord, or the appliance itself is damaged.
- Unplug the appliance when not in use and before cleaning.
- Do not let the main cord hang over the edge of a table or worktop.
- The appliance operates at high temperatures. Use oven mitts when handling hot surfaces.
- Ensure adequate ventilation around the appliance during use.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.

## 3. PRODUCT COMPONENTS

---

Familiarize yourself with the main parts of your Philips Airfryer HD9285/94:

- **Main Unit:** The primary housing of the Airfryer, containing the heating element and fan.
- **Control Panel:** Digital display with touch controls for temperature, time, presets, and power.
- **Basket:** Removable non-stick basket for holding food during cooking.
- **Pan:** The main drawer that holds the basket and collects excess oil.
- **Handle:** Ergonomic handle for safely pulling out the pan and basket.
- **Air Inlet:** Located on the top of the appliance.
- **Air Outlet:** Located at the back of the appliance.



Image 3.1: A detailed front view of the Philips Airfryer HD9285/94, highlighting its digital control panel with various icons and the prominent handle for the food basket.

## 4. INITIAL SETUP

---

### 4.1 Unpacking

Carefully remove all packaging materials from the appliance. Retain the packaging for potential future transport or storage.

### 4.2 Cleaning Before First Use

- Wipe the exterior of the appliance with a damp cloth.
- Remove the pan and basket. Clean them thoroughly with hot water, dish soap, and a non-abrasive sponge.
- Rinse and dry all parts completely before reassembling.

### 4.3 Placement

Place the Airfryer on a stable, heat-resistant surface. Ensure there is at least 10 cm of clear space around the back, sides, and above the appliance for proper air circulation.

### 4.4 Power Connection

Plug the main cord into a grounded wall socket. Ensure the voltage matches the specifications of the appliance.

### 4.5 Connecting to NutriU App (Wi-Fi)

Your Airfryer is Wi-Fi connected. Download the Philips NutriU app from your device's app store. Follow the in-app instructions to pair your Airfryer with your smartphone or tablet for remote control and access to a wide range of recipes.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Basic Operation

1. Pull the pan out of the Airfryer.
2. Place the ingredients in the basket. Do not exceed the MAX indication.
3. Slide the pan back into the Airfryer.
4. Press the power button to turn on the appliance.
5. Use the temperature and time control buttons to set your desired cooking parameters.
6. Press the start button to begin cooking.



Image 5.1: A hand interacting with the digital control panel of the Philips Airfryer HD9285/94, demonstrating the ease of setting cooking parameters.

### 5.2 Using Presets and 16-in-1 Functions

The Airfryer comes with pre-programmed settings for common dishes. Select the appropriate preset icon on the control panel. The appliance will automatically set the optimal temperature and time. You can manually adjust these settings if needed.

### 5.3 Shaking and Turning Food

For even cooking, especially with smaller items like fries or chicken wings, it is recommended to shake the basket or turn the food halfway through the cooking time. The Airfryer may beep to remind you.

### 5.4 Monitoring Cooking and Remote Control

You can monitor the cooking progress directly on the Airfryer's display or through the NutriU app. The app also allows you to start, pause, or adjust settings remotely.



Image 5.2: The Philips Airfryer HD9285/94 showcasing its versatility by preparing a variety of dishes, including a whole roasted chicken, golden fries, and baked muffins.



Image 5.3: A close-up view of a fully cooked, golden-brown whole chicken resting within the Airfryer's basket, demonstrating the appliance's cooking capabilities.

## 6. CLEANING AND MAINTENANCE

---

Regular cleaning ensures optimal performance and extends the lifespan of your Airfryer.

### 6.1 Cleaning the Pan and Basket

- After each use, allow the appliance to cool down completely.
- Remove the pan and basket. They are dishwasher-safe.
- Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for 10-15 minutes.

### 6.2 Cleaning the Interior and Exterior

- Wipe the exterior of the appliance with a damp cloth.
- Clean the interior with a soft sponge and hot water. Avoid using abrasive cleaners or metal scouring pads.
- For the heating element, use a cleaning brush to remove any food residue.

## 6.3 Storage

Ensure the Airfryer is clean and dry before storing. Store it in a cool, dry place, preferably in its original packaging.

## 7. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your Philips Airfryer HD9285/94.

Problem	Possible Cause	Solution
Airfryer does not turn on.	Appliance not plugged in; power outlet malfunction.	Ensure the plug is securely inserted into a working power outlet. Check your circuit breaker.
Food is not cooked evenly.	Basket overloaded; food not shaken/turned.	Do not overload the basket. Shake or turn food halfway through cooking.
White smoke comes from the appliance.	Fat residues from previous use; high-fat ingredients.	Clean the pan and basket thoroughly. For high-fat foods, absorb excess oil with a paper towel before cooking.
Fresh fries are not crispy.	Not soaked properly; too much moisture.	Soak fresh potato sticks in water for 30 minutes, then dry thoroughly before adding a little oil.
Appliance smells unusual.	New appliance smell; food residue.	The initial smell is normal and will dissipate. Ensure the appliance is clean.

## 8. TECHNICAL SPECIFICATIONS

---

Detailed specifications for the Philips Airfryer HD9285/94:

Feature	Detail
Model Number	HD9285/94
Brand	PHILIPS
Capacity	7.2 Liters (1.4 kg food capacity)
Power / Wattage	2000 Watts
Voltage	2.3E+2 Volts
Material	Aluminum
Color	Black
Product Dimensions (L x W x H)	41 x 30 x 33 cm
Item Weight	8 Kilograms
Special Features	Temperature Control, 16-in-1 Functions, Wi-Fi Connected, Rapid Air Technology
Recommended Uses	Bake, Dehydrate, Reheat, Roast, Steam, Fry



Image 8.1: A visual representation of the Philips Airfryer HD9285/94 with its key dimensions (height, width, depth) clearly marked for reference.

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

Your Philips Airfryer HD9285/94 comes with a **2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. This warranty covers manufacturing defects under normal use conditions.

### 9.2 Customer Support

For technical assistance, installation services, or warranty inquiries, please contact Philips customer support at the following regional numbers:

- **Riyadh:** +966 -11- 4094006 Ext – 113
- **Jeddah:** +966- 12- 6577714
- **Dammam:** +966-13- 8343691
- **Qassim:** +966 581044198
- **Abha:** +966 593322785

For additional support and product information, visit the official Philips website or consult the NutriU app.

