

HEAD 603260

HEAD Edge 85 HV Women's Ski Boot User Manual

Comprehensive guide for the HEAD Edge 85 HV Women's Ski Boots.

1. INTRODUCTION

This manual provides essential information for the proper use, setup, maintenance, and care of your HEAD Edge 85 HV Women's Ski Boots. Designed for intermediate to advanced skiers, these boots offer a blend of comfort and performance, featuring an adjustable profile, EZ Tech shell, Ski-Walk system, and an extended toe box. Please read this manual thoroughly before using your ski boots to ensure safety and optimal performance.

2. SETUP AND INITIAL ADJUSTMENT

Proper setup is crucial for comfort and control. Follow these steps for initial adjustment:

- Step-In:** The HEAD Edge 85 HV boots feature an EZ-On design, making them easy to step into. Ensure all buckles are fully open before attempting to put on the boots.
- Buckle Fastening:**
 - Start by fastening the buckles loosely, beginning with the two lower buckles over the forefoot, then the two upper buckles around the cuff.
 - Gradually tighten each buckle, working from the bottom up, until the boot feels snug but not uncomfortably tight. Avoid over-tightening, which can restrict circulation.
 - The micro-adjustable buckles allow for fine-tuning the fit.
- Calf Adjustment:** The women's adjustable profile allows the liner calf to widen freely. Ensure the calf area feels comfortable and secure without excessive pressure points.
- Flex Adjustment:** The boot's flex is designed for intermediate to advanced skiers. Familiarize yourself with the boot's forward lean and flex characteristics.



Image: Front view of the HEAD Edge 85 HV Women's Ski Boot. This image shows the overall design, including the four buckles and the high-top lower shell.

3. OPERATING YOUR SKI BOOTS

The HEAD Edge 85 HV boots are engineered for enhanced skiing experience and ease of use.

- **Ski-Walk System:** Engage the Ski-Walk mechanism when walking to increase comfort and mobility. Disengage it before skiing to ensure maximum power transmission and control. Refer to the specific lever or switch on the boot for activation/deactivation.
- **EZ-Ski Hi-Top Lower Shell:** This unique design efficiently transfers energy from your movements directly to the ski, enhancing responsiveness and control. Ensure your stance is balanced to fully utilize this feature.
- **Extended Toe Box:** The extended toe box provides additional comfort by reducing torsion and increasing power transmission. It also helps keep your toes warmer, contributing to all-day comfort on the slopes.
- **Liner Molding:** The Perfect Fit S liner will mold to your foot over time with use, providing a customized and comfortable fit.

4. MAINTENANCE AND CARE

Proper maintenance extends the life of your ski boots and ensures continued performance.

- **Cleaning:** After each use, wipe down the exterior of the boots with a damp cloth to remove dirt, snow, and salt. Avoid harsh chemicals.
- **Drying:** Remove the liners and footbeds to allow them to air dry completely at room temperature. Do not use direct heat sources like radiators or open flames, as this can damage the boot materials.
- **Storage:** Store your boots with all buckles lightly fastened to maintain their shape. Keep them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Regularly inspect buckles, straps, and the shell for any signs of wear, damage, or cracks. Replace damaged components immediately.

5. TROUBLESHOOTING COMMON ISSUES

Issue	Possible Cause	Solution
Discomfort or pressure points	Buckles too tight, improper liner fit, incorrect size.	Loosen buckles, allow liner to mold, consult a boot fitter for size verification.
Cold feet	Poor circulation from overtightening, inadequate socks, wet liners.	Ensure buckles are not too tight, wear appropriate ski socks, ensure liners are dry. The extended toe box helps with warmth.
Difficulty walking	Ski-Walk system not engaged.	Activate the Ski-Walk mechanism for increased mobility when not skiing.
Loose fit / lack of control	Buckles too loose, liner packed out, incorrect size.	Tighten buckles appropriately, consider professional liner adjustment or replacement, verify size.

6. SPECIFICATIONS

- **Brand:** HEAD
- **Model Name:** Edge 85 HV
- **Part Number:** 603260
- **Suggested Users:** Women's
- **Skill Level:** Intermediate/Advanced
- **Material:** Polyurethane (Shell)
- **Liner:** Perfect Fit S
- **Features:** EZ-On, EZ-Ski Hi-top lower shell, Ski-Walk system, Extended Toe Box, Women's adjustable profile

Size Chart

Refer to the following size chart to ensure you have the correct boot size. Mondo point sizing is generally recommended for ski boots.

Image: HEAD Ski Boot Size Chart. This table provides conversions between European, US, UK, and Mondo point sizing, along with the corresponding boot sole length in millimeters. For example, a Mondo size 22.5 corresponds to a boot sole length of 273mm.

7. WARRANTY AND SUPPORT

For detailed warranty information, please refer to the official HEAD Sports website or contact your authorized HEAD dealer. Keep your proof of purchase for any warranty claims.

For further assistance or product support, please visit the official HEAD store or contact their customer service.

Official HEAD Store: [Visit the HEAD Store on Amazon](#)

© 2023 HEAD Sports. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question