

[Manuals.plus](#) /

› [KOBE TOY COMPANY](#) /

› KOBE TOY Kids Balance Bike User Manual

KOBE TOY COMPANY KAB-GR-032123

KOBE TOY Kids Balance Bike User Manual

Model: KAB-GR-032123 | Brand: KOBE TOY COMPANY

1. INTRODUCTION

Thank you for choosing the KOBE TOY Kids Balance Bike. This manual provides essential information for the safe assembly, operation, and maintenance of your new balance bike. Designed for children aged 18 months to 5 years, this no-pedal training bicycle helps develop balance, coordination, and confidence, preparing them for a pedal bike.



Image 1.1: The KOBE TOY Kids Balance Bike in green, featuring a lightweight aluminum frame and black components.

2. SAFETY INFORMATION

Please read and understand all safety warnings before assembly and use. Failure to follow these instructions may result in serious injury.

- **Adult Supervision Required:** Always ensure an adult supervises the child during use.
- **Protective Gear:** Always ensure the child wears a properly fitted helmet, knee pads, and elbow pads.
- **Appropriate Age and Size:** This bike is suitable for children aged 18 months to 5 years. Ensure the child's feet can comfortably touch the ground while seated.
- **Safe Riding Environment:** Use the bike on flat, clear surfaces away from traffic, steep inclines, stairs, and water.
- **Inspect Before Each Use:** Before each ride, check that all bolts and fasteners are tight, tires are in good condition, and the seat and handlebars are securely adjusted.
- **Weight Limit:** Do not exceed the recommended weight limit for the bike.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all components are present. If any parts are missing or damaged, contact KOBE TOY COMPANY customer support immediately.

- Balance Bike Frame (with rear wheel attached)
- Front Wheel
- Handlebar Assembly
- Seat Post with Seat
- Assembly Kit (tools and fasteners)
- User Manual
- Bell



Image 3.1: Included bell, designed for easy attachment to the handlebar.

4. SETUP AND ASSEMBLY

Assembly is straightforward and requires minimal tools, which are included in the assembly kit.

1. **Attach the Front Wheel:** Insert the front wheel into the fork. Secure it using the provided nuts and washers. Ensure the wheel spins freely and is centered.
2. **Install the Handlebar:** Insert the handlebar stem into the head tube of the bike frame. Adjust the handlebar to the desired height (see Section 5 for adjustment details) and tighten the clamp bolt securely. Ensure the handlebar is aligned with the front wheel.
3. **Insert the Seat Post:** Insert the seat post with the attached seat into the seat tube of the bike frame. Adjust the seat to the appropriate height (see Section 5 for adjustment details) and secure it using the quick-release lever.
4. **Attach the Bell:** Secure the bell to the handlebar in a position easily accessible by the child.
5. **Final Check:** Double-check all bolts, nuts, and quick-release levers to ensure they are securely tightened before the first use.

KOBE BALANCE BIKE

Engineered with Quality Materials



BALANCE
Increase Balance

STRENGTH
Improves Leg Endurance

BRAINPOWER
Supports Faster Learning

CONFIDENCE
Boost Self Confidence

KOBE TOY COMPANY

The KOBE Balance Bike helps kids explore, strengthen their legs, and build endurance without the need for pedals or training wheels, giving them an early start on riding a regular bike.

Image 4.1: Front view of the KOBE TOY balance bike, showing the handlebar and front wheel assembly.

Premium Features for **KIDS** First Bike



Image 4.2: Side view of the KOBE TOY balance bike, illustrating the frame, seat, and wheels.

5. OPERATING INSTRUCTIONS

The KOBE TOY Balance Bike is designed to teach children balance and coordination without pedals, making the transition to a traditional bicycle easier.

5.1 Adjusting Seat and Handlebar Height

Proper adjustment is crucial for comfort and effective learning. The bike is designed to accommodate your child's growth.

- **Seat Height:** The seat height is adjustable from 11 inches to 16 inches. To adjust, open the quick-release lever on the seat post clamp, slide the seat to the desired height, and firmly close the lever. The child's feet should be flat on the ground with a slight bend in their knees when seated.
- **Handlebar Height:** The handlebar height is adjustable from 18 inches to 21 inches. Loosen the handlebar stem bolt, adjust to the desired height, and re-tighten securely. The handlebars should be at a comfortable height for the child to maintain an upright posture.



Image 5.1: Illustration of adjustable handlebar and seat heights, crucial for fitting the bike to your child.

5.2 How to Ride

The balance bike encourages children to use their feet to propel and balance.

1. **Push:** Encourage the child to sit on the seat and push off the ground with their feet, walking or running to gain momentum.
2. **Stride:** As they gain speed, encourage them to lift their feet and glide, using their body to steer and balance.
3. **Glide:** With practice, children will be able to glide for longer distances, developing the balance needed for a pedal bike.



Image 5.2: A child demonstrating the 'Push, Stride, Glide' method of riding a balance bike.

Grow with your child

The Perfect adjustable balance bike for children of different ages and height

Adjustable Handle Bar Height

From 18" to 21"

Adjustable Seat Height

From 11" to 16"



Image 5.3: The KOBE TOY Balance Bike helps children develop balance, strength, brainpower, and confidence.

6. MAINTENANCE

Regular maintenance will ensure the longevity and safe operation of your KOBE TOY Balance Bike.

- **Cleaning:** Wipe down the bike with a damp cloth after use. Avoid harsh chemicals.
- **Tires:** The bike features maintenance-free EVA polymer tires, which are puncture-free and do not require inflation. Keep them free of debris.
- **Fasteners:** Periodically check all bolts, nuts, and quick-release levers to ensure they are tight. Re-tighten as necessary.
- **Storage:** Store the bike in a dry place, away from direct sunlight and extreme temperatures, to prevent material degradation.



Image 6.1: The durable EVA polymer tires are designed for all-terrain adventures and are puncture-free.

7. TROUBLESHOOTING

Most issues can be resolved with simple checks.

- **Bike feels unstable:** Ensure all assembly bolts are tightened. Check that the handlebar and seat are securely clamped.
- **Child struggling to balance:** Verify the seat height is correct (feet flat on the ground). Encourage more practice in a safe, open area.
- **Squeaking noises:** Check for loose parts. A small amount of lubricant can be applied to moving parts if necessary, avoiding contact with tires.

8. SPECIFICATIONS

Feature	Detail
Model Number	KAB-GR-032123
Brand	KOBE TOY COMPANY
Age Range	18 Months to 5 Years (Toddler)
Bike Type	Balance Bike, Kids Bike
Frame Material	Aluminum
Color	Green
Item Weight	2.72 kg (4.3 lbs)
Wheel Size	12 Inches
Tire Type	EVA Polymer (Puncture-Free)
Adjustable Seat Height	11" - 16"

Adjustable Handlebar Height	18" - 21"
Included Components	Assembly kit, Balance Bike, Manual, Bell

9. WARRANTY AND SUPPORT

KOBE TOY COMPANY products come with a **60-day warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. For customer support, missing parts, or warranty inquiries, please contact KOBE TOY COMPANY directly. You can also visit the official KOBE TOY COMPANY store on Amazon for more information and products:

Visit KOBE TOY COMPANY
Store