

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsung](#) /

› [SAMSUNG Galaxy A13 SM-A135U Verizon LTE Smartphone User Manual](#)

Samsung Galaxy A13

SAMSUNG Galaxy A13 SM-A135U Verizon LTE Smartphone User Manual

Model: Galaxy A13 (SM-A135U)

1. PRODUCT OVERVIEW

The Samsung Galaxy A13 SM-A135U is a feature-rich smartphone designed for reliable communication and multimedia experiences on the Verizon LTE network. It combines a long-lasting battery, a versatile multi-lens camera system, and an expansive Infinity-V display to keep you connected and entertained.

Key Features:

- **Long-Lasting Battery:** Equipped with a high-capacity battery for extended usage and Fast Charging capability.
- **Reliable Performance:** Provides smooth browsing, crisp photo/video capture, and efficient streaming.
- **Expandable Storage:** Offers 32GB internal storage, expandable up to 1TB via microSD card (sold separately).
- **Versatile Camera System:** Features multiple camera lenses for capturing diverse photos and videos.
- **Infinity-V Display:** An edge-to-edge FHD+ display for immersive viewing.
- **Modern Design:** Durable construction with a sleek, glossy finish.
- **Enhanced Security:** Incorporates multi-layered Knox Security and Private Share features for data protection.



Figure 1: Front view of the Samsung Galaxy A13.

2. INITIAL SETUP

2.1. Package Contents

Before you begin, ensure all items are present in your package:

- Samsung Galaxy A13 SM-A135U Smartphone
- USB Cable
- *Note: A power adapter may not be included and might need to be purchased separately.*

2.2. Inserting the SIM Card

To connect to the Verizon LTE network, you will need to insert a Nano-SIM card.

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejection tool (not included, often a paperclip can be used) into the small hole next to the tray to eject it.
3. Place your Nano-SIM card into the tray with the gold contacts facing down. Ensure it is correctly oriented.
4. Gently push the tray back into the slot until it clicks into place.



Figure 2: Side view of the Galaxy A13, indicating SIM tray location.

2.3. Powering On and Initial Configuration

1. Press and hold the Power/Side key until the Samsung logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. You may be prompted to transfer data from an old device using Samsung Smart Switch.
4. Complete the setup process, including setting up security features like a PIN, pattern, or fingerprint.

3. OPERATING YOUR DEVICE

3.1. Basic Navigation

- **Home Screen:** Swipe left or right to access different home screens.
- **App Drawer:** Swipe up from the home screen to view all installed applications.
- **Notifications Panel:** Swipe down from the top of the screen to access notifications and quick settings.
- **Recent Apps:** Tap the Recent Apps button (usually a square icon) to switch between open applications.

3.2. Making Calls and Sending Messages

- **Calls:** Open the Phone app, enter the number, and tap the call icon.
- **Messages:** Open the Messages app, tap the new message icon, enter the recipient and your message.

3.3. Using the Camera

The Galaxy A13 features a versatile multi-lens camera system.

1. Open the Camera app from your home screen or app drawer.
2. Select your desired camera mode (e.g., Photo, Video, Portrait).
3. Tap the shutter button to capture a photo or start/stop video recording.
4. Switch between front and rear cameras using the camera switch icon.



Figure 3: Rear camera setup of the Galaxy A13.

3.4. Managing Storage

Your device comes with 32GB of internal storage. You can expand this by inserting a microSD card (up to 1TB).

- To insert a microSD card, follow the same procedure as inserting a SIM card, using the dedicated slot if available, or the combined SIM/microSD tray.
- Manage your storage in **Settings > Battery and device care > Storage**.

4. MAINTENANCE AND CARE

4.1. Cleaning Your Device

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive cleaners, or compressed air.

4.2. Battery Care

- To maximize battery life, avoid extreme temperatures.
- Use the provided USB cable and a compatible fast charger for optimal charging.
- Periodically check battery usage in **Settings > Battery and device care > Battery** to identify power-consuming apps.

4.3. Software Updates

Keep your device's software updated to ensure optimal performance and security.

- Go to **Settings > Software update** and tap **Download and install**.

5. TROUBLESHOOTING

5.1. Common Issues and Solutions

- **Device not powering on:**
 - Ensure the battery is charged. Connect the device to a charger for at least 10 minutes before attempting to power on.
 - Perform a forced restart by holding the Power/Side key and Volume Down key simultaneously for about 7-10 seconds.
- **"Invalid SIM" or no network connection:**
 - Ensure the SIM card is correctly inserted and seated in the tray.
 - Verify that your SIM card is active with Verizon.
 - Restart the device.
 - Check network settings in **Settings > Connections > Mobile networks**.
- **Device is slow or unresponsive:**
 - Close unnecessary background applications.
 - Clear cache for frequently used apps (**Settings > Apps > [App Name] > Storage > Clear cache**).
 - Ensure sufficient storage space is available. Delete old files or move them to a microSD card.
 - Restart the device.
- **Battery drains quickly:**
 - Reduce screen brightness and screen timeout.
 - Disable Wi-Fi, Bluetooth, and GPS when not in use.
 - Identify and manage power-hungry apps in **Settings > Battery and device care > Battery**.
 - Ensure software is up to date.
- **Issues with renewed devices (e.g., pre-installed software):**
 - If you encounter unexpected software or settings, perform a factory data reset. Go to **Settings > General management > Reset > Factory data reset**. *Note: This will erase all data on your device. Back up important information first.*

6. SPECIFICATIONS

Feature	Detail
Model Name	Galaxy A13 (SM-A135U)
Brand	Samsung
Operating System	Android
Wireless Carrier	Verizon
Screen Size	6.6 Inches
Resolution	1920 x 1080
Memory Storage Capacity	32 GB (Expandable up to 1TB with microSD)
RAM	3 GB / 4 GB (depending on variant)
CPU Model	Qualcomm Snapdragon MSM8260A
CPU Speed	2.2 GHz
Battery Capacity	5000 Milliamp Hours
Phone Talk Time	2.5 Hours (Note: This value seems unusually low and might be a data entry error in the source. Actual talk time is typically much longer for a 5000mAh battery.)
Item Weight	11.3 ounces
Audio Jack	No headphone jack
Whats in the box	USB Cable

7. WARRANTY AND SUPPORT

7.1. Product Condition and Returns

This Samsung Galaxy A13 is a renewed product. Renewed products are fully functional and typically come with generic or original accessories and packaging.

The return policy for this product allows for a refund or replacement within 90 days of purchase. Please refer to your retailer's specific return policy for detailed terms and conditions.

7.2. Technical Support

For technical assistance, software issues, or further inquiries, please visit the official Samsung support website or contact your service provider (Verizon) for network-related support.

- **Samsung Support:** www.samsung.com/us/support/
- **Verizon Support:** www.verizon.com/support/



