

[Manuals.plus](#) /

› [BELLA](#) /

› BELLA 2 qt Manual Air Fryer Oven and 5-in-1 Multicooker with Removable Nonstick and Dishwasher Safe Crisping Tray and Basket, 1200 Watt Heating System, Matte Black 2.0 Quart Black

BELLA 17800

BELLA 2 qt Manual Air Fryer Oven User Manual

Model: 17800

INTRODUCTION

Welcome to the world of convenient and healthy cooking with your new BELLA 2 qt Manual Air Fryer Oven. This versatile 5-in-1 multicooker is designed to simplify your meal preparation, allowing you to air fry, broil, bake, roast, and reheat with ease. Its compact design makes it a perfect fit for any kitchen countertop, saving valuable space while delivering delicious results.



Figure 1: Front view of the BELLA 2 qt Manual Air Fryer Oven.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Only for countertop use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your BELLA Air Fryer for optimal use.



Easy Cleaning

**Removable and dishwasher safe
crisping tray and cooking pan**

Figure 2: Removable nonstick basket and crisping tray for easy cleaning.

Key Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Dial:** Used to set the cooking time (up to 60 minutes) and activate the appliance.
- **Power Indicator Light:** Illuminates when the unit is powered on.
- **Heat On Indicator Light:** Illuminates when the heating element is active.
- **Removable Basket:** The primary cooking container for food.
- **Crisping Tray:** Sits inside the basket, allowing air to circulate around food for even crisping.



Figure 3: Top control dial with power and heat indicator lights.

SETUP

Before first use, ensure all packaging materials are removed. Wash the removable basket and crisping tray with warm, soapy water. Rinse thoroughly and dry completely. Wipe the main unit with a damp cloth. Do not immerse the main unit in water.

Pre-heating:

For best results, pre-heat the air fryer before adding food. Plug the unit into a grounded electrical outlet. Turn the control dial to the desired temperature (up to 400°F) and set the timer for 3-5 minutes. The Power and Heat On indicator lights will illuminate. Once pre-heating is complete, the timer will chime, and the Heat On light will turn off.

OPERATING INSTRUCTIONS

The BELLA Air Fryer utilizes Circular Heat Technology to cook food evenly and efficiently. It functions as a 5-in-1 multicooker, allowing for air frying, broiling, baking, roasting, and reheating.

General Operation:

1. Place the crisping tray inside the removable basket.
2. Place your food onto the crisping tray. Do not overfill the basket to ensure even cooking. The capacity is up to 1 Kg of food, suitable for 2-3 people.
3. Slide the basket back into the main unit until it clicks securely into place.
4. Turn the control dial to set the desired cooking time. The air fryer will begin cooking automatically.
5. The Power light will remain on, and the Heat On light will cycle on and off as the unit maintains the temperature.
6. For best results, shake or flip food halfway through the cooking time. Carefully pull out the basket, shake/flip, and reinsert. The unit will resume cooking.
7. Once the timer reaches zero, the unit will automatically shut off and emit an audible tone.
8. Carefully remove the basket and transfer cooked food to a serving dish.

Healthy and Delicious Meals

Adjustable temperature to prepare
crispy and juicy foods every time



Figure 4: Healthy and delicious meals prepared with less oil.

Official Product Video:

Your browser does not support the video tag.

Video 1: Demonstrates the BELLA 2 Qt Manual Air Fryer with Circular Heat Technology in action, showcasing its ease of use and cooking capabilities.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your air fryer and ensure optimal performance.

- Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
- The removable nonstick basket and crisping tray are dishwasher safe. For manual cleaning, wash with warm, soapy water using a non-abrasive sponge.

- Do not use abrasive cleaning materials or metal scouring pads, as these can damage the nonstick coating.
- Wipe the exterior of the main unit with a damp cloth. Never immerse the main unit in water or any other liquid.
- Ensure all parts are thoroughly dry before storing or next use.



Easy Cleaning

**Removable and dishwasher safe
crisping tray and cooking pan**

Figure 5: The removable basket and crisping tray are designed for easy cleaning.

TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Unit is not plugged in or timer is not set.	Ensure the power cord is securely plugged into a grounded outlet. Turn the timer dial to the desired cooking time.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket is overfilled or food is not shaken/flipped.	Do not overfill the basket. Shake or flip food halfway through cooking for even results.
White smoke coming from the unit.	Excess oil/grease from food or residue from previous use.	Clean the basket and crisping tray thoroughly after each use. For fatty foods, drain excess grease during cooking.
Food is not crispy.	Not enough cooking time or temperature too low.	Increase cooking time or temperature. Ensure food is not overcrowded in the basket.

SPECIFICATIONS

- **Model:** 17800
- **Capacity:** 2 Quarts (approx. 1 Kg food)
- **Power:** 1200 Watts
- **Voltage:** 1.2 Volts
- **Max Temperature:** 400°F
- **Control Method:** Manual Dial (Timer up to 60 minutes)
- **Materials:** Aluminum, Stainless Steel, Plastic
- **Nonstick Coating:** Yes (PFOA-free)
- **Dishwasher Safe Parts:** Removable Basket & Crisping Tray
- **Product Dimensions:** 11.02"D x 8.26"W x 10.43"H
- **Item Weight:** 5.89 pounds

10.43"



8.26"

Figure 6: Product dimensions for space planning.

WARRANTY AND SUPPORT

Your BELLA 2 qt Manual Air Fryer Oven comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For technical support, troubleshooting

assistance, or to inquire about replacement parts, please visit the official BELLA website or contact customer service using the information provided in your product documentation.

Online Support: [Visit the BELLA Store on Amazon](#)