

[Manuals.plus](#) /

› [SKMEI](#) /

› SKMEI Model 1888 Digital Sports Watch User Manual

SKMEI 1888

SKMEI Model 1888 Digital Sports Watch User Manual

Model: 1888

INTRODUCTION

Thank you for choosing the SKMEI Model 1888 Digital Sports Watch. This manual provides detailed instructions on how to set up, operate, and maintain your watch. The Model 1888 combines a sleek design with multiple functions, including a 3D pedometer, stopwatch, alarm, countdown timer, and dual time display, making it suitable for daily wear and sports activities.



Front view of the SKMEI Model 1888 Digital Sports Watch, displaying time and pedometer data.

PRODUCT FEATURES

- **Multifunctional Display:** Features time, date, day of the week, and dual time mode.
- **3D Pedometer:** Tracks steps, distance, and calories burned for fitness monitoring.
- **Stopwatch:** For timing events with precision.
- **Countdown Timer:** Useful for various timed activities.
- **Alarm Clock:** Daily alarm function.
- **EL Backlight:** Electroluminescent backlight for clear visibility in low-light conditions.
- **Water Resistance:** Rated for 30 meters, suitable for daily use like hand washing and rain.
- **Durable Construction:** Zinc alloy case with stainless steel band for longevity.

Key Features

Display
Digital

Dial Shape
Rectangle

Features
2 Time, Date, EL Light, Week

Strap Material
Stainless Steel

Water Resistance
50 m



Visual representation of the key features of the SKMEI 1888 watch.

WATCH COMPONENTS

The SKMEI 1888 watch typically features four buttons for operation and a digital display.

- **Button A (Top Left):** Used for EL backlight and selecting items.
- **Button B (Bottom Left):** Used for mode switching.
- **Button C (Top Right):** Used for adjusting values and starting/stopping functions.
- **Button D (Bottom Right):** Used for resetting or confirming settings.



Detailed view of the watch display and operational buttons.

SETUP AND BASIC OPERATION

1. Initial Power On

The watch is typically powered on from the factory. If the display is blank, press any button to activate it.

2. Mode Switching

Press **Button B** (bottom left) repeatedly to cycle through the different modes: Time Mode, Pedometer Mode, Stopwatch Mode, Alarm Mode, Countdown Mode, and Dual Time Mode.

3. EL Backlight

In any mode, press **Button A** (top left) to illuminate the display for a few seconds, enhancing visibility in dark environments.

TIME AND DATE SETTING

1. From Time Mode, press and hold **Button B** until the seconds begin to flash, indicating setting mode.
2. Press **Button B** again to cycle through the setting items: Seconds, Hours, Minutes, Year, Month, Day.

3. Use **Button C** (top right) to adjust the flashing value. Press **Button D** (bottom right) to reset seconds to zero.
4. Once all settings are correct, press **Button B** to exit the setting mode and return to normal Time Mode.

PEDOMETER FUNCTION

The 3D pedometer tracks your physical activity throughout the day.

1. Switch to Pedometer Mode by pressing **Button B** until "STEP" or a similar indicator appears on the display.
2. The display will show your current step count, distance traveled (KM), and calories burned (KCAL).
3. To reset the pedometer data, press and hold **Button D** while in Pedometer Mode.
4. The pedometer automatically starts tracking when movement is detected.



The watch display showing active pedometer tracking.

STOPWATCH FUNCTION

1. Press **Button B** to navigate to Stopwatch Mode. The display will show "00:00:00".
2. Press **Button C** to start the stopwatch.
3. Press **Button C** again to pause the stopwatch.
4. While paused, press **Button D** to reset the stopwatch to "00:00:00".
5. To resume timing after pausing, press **Button C**.

ALARM CLOCK FUNCTION

1. Press **Button B** to navigate to Alarm Mode. The display will show the alarm time.
2. Press and hold **Button B** until the alarm hours begin to flash.
3. Press **Button C** to adjust the hours.
4. Press **Button B** to select minutes, then use **Button C** to adjust.
5. Press **Button B** again to exit alarm setting.
6. To turn the alarm ON/OFF, press **Button C** while in Alarm Mode (not setting mode). An alarm icon will appear/disappear.

COUNTDOWN TIMER FUNCTION

1. Press **Button B** to navigate to Countdown Mode.
2. Press and hold **Button B** until the countdown hours begin to flash.
3. Use **Button C** to adjust the hours, then press **Button B** to select minutes and adjust with **Button C**. Repeat for seconds.
4. Press **Button B** to exit countdown setting.
5. Press **Button C** to start or pause the countdown.
6. When paused, press **Button D** to reset the countdown to its initial set time.

WATER RESISTANCE

The SKMEI Model 1888 watch is rated for 30 meters (3ATM) water resistance. This means it is suitable for daily use, such as splashes, rain, and hand washing.

Important: It is **not recommended** for swimming, diving, showering with hot water, or any activities involving prolonged water immersion or high-pressure water exposure. Do not operate buttons while the watch is wet or submerged.



Illustration of the watch's water resistance capabilities.



The watch's case back indicating 3ATM water resistance.

MAINTENANCE

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and dirt. For the stainless steel band, a slightly damp cloth can be used, followed by immediate drying.
- **Avoid Chemicals:** Do not expose the watch to strong chemicals, solvents, or detergents, as these can damage the case, strap, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods, as this can affect battery life and accuracy.
- **Battery Replacement:** When the display dims or functions become erratic, the battery may need replacement. This should ideally be done by a qualified watch technician to ensure water resistance is maintained. The battery type is typically CR2025 (as indicated on the case back).
- **Strap Adjustment:** The stainless steel strap can be adjusted for comfort. If you need to remove links, it is recommended to seek professional assistance to avoid damage.



The secure adjustable clasp of the watch band.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery (CR2025). Seek professional help to maintain water resistance.
Time is incorrect.	Time not set correctly or reset.	Refer to the "Time and Date Setting" section to reset the time.
Pedometer not tracking steps accurately.	Watch not worn correctly, or pedometer needs calibration/reset.	Ensure the watch is worn snugly on the wrist. Try resetting the pedometer data.
Buttons are unresponsive or hard to press.	Dirt/debris under buttons or internal issue.	Clean around the buttons. If issue persists, contact customer support.

SPECIFICATIONS

Model Number	1888
Display Type	Digital (LED Screen)
Movement Type	Quartz
Case Material	Zinc Alloy
Band Material	Stainless Steel
Water Resistance	30 Meters (3ATM)
Case Diameter	3.7 Centimeters
Case Thickness	1.05 Centimeters
Strap/Lug Width	20 MM

Item Weight	105.7 Grams
Battery Type	CR2025



 <p>Case Width 37MM</p>	 <p>Strap Material Stainless Steel</p>	 <p>Case Thickness 10.5MM</p>
---	--	---

Dimensional diagram of the SKMEI Model 1888 watch.

WARRANTY INFORMATION

This SKMEI watch comes with a **Limited Warranty**. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. The warranty typically covers manufacturing defects but may not cover damage resulting from improper use, accidents, or unauthorized repairs.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact your retailer or the official SKMEI customer service channels. Keep your purchase receipt and warranty card handy when contacting support.

