

[Manuals.plus](#) /

› [CBBEXP](#) /

› Instruction Manual for CBBEXP 1734-IE8C Current Input Module

CBBEXP 1734-IE8C

Instruction Manual

CBBEXP 1734-IE8C CURRENT INPUT MODULE

Model: 1734-IE8C

Product Overview

The CBBEXP 1734-IE8C is a current input module designed for industrial automation applications. This module facilitates the acquisition of analog current signals, typically 4-20mA, from various industrial sensors and devices. It is engineered for reliable performance within industrial environments.



Figure 1: Front view of the 1734-IE8C Current Input Module, showing status indicators and input channels.

Key Features

- Model: 1734-IE8C

- Type: Designed for industrial automation usage
- Condition: New, sealed in box
- Warranty: One-Year Warranty provided
- Customer-oriented support

Setup and Installation

Proper installation is crucial for the reliable operation of the 1734-IE8C module. Follow these general guidelines:

1. **Power Disconnection:** Ensure all power to the control system and associated equipment is disconnected before installation to prevent electrical shock or damage to components.
2. **Mounting:** Mount the module securely onto a compatible DIN rail within an appropriate industrial enclosure. Ensure adequate ventilation around the module.
3. **Wiring:** Connect the 4-20mA analog input devices to the designated input terminals (0-7) on the module as indicated by the wiring diagram on the module's label. Pay close attention to polarity.
4. **Network Connection:** Connect the module to the industrial network (e.g., PointBus) according to your system architecture.
5. **Grounding:** Ensure proper grounding of the module and associated wiring to minimize noise and ensure safety.
6. **Power Connection:** After all connections are secure and verified, restore power to the system.

Refer to the detailed wiring diagram printed on the side of the module for specific terminal assignments and connection types.

Operation

The 1734-IE8C module operates by converting incoming 4-20mA analog current signals from connected field devices into digital values that can be processed by a programmable logic controller (PLC) or other control system.

- **Input Channels:** The module features 8 independent input channels (0-7) for connecting multiple current input devices.
- **Status Indicators:**
 - **Module Status:** Indicates the operational status of the module (e.g., power on, fault).
 - **Network Status:** Indicates the status of the network communication.
 - **Node:** Displays the module's network address or node ID.
- **Data Acquisition:** Once powered and configured within the control system's programming software, the module continuously reads the current values from the connected sensors. These values are then available for use in control logic, monitoring, and data logging.

For detailed configuration and programming instructions, consult the documentation for your specific control system and software.

Maintenance

The 1734-IE8C module is designed for robust industrial use, requiring minimal maintenance. However, periodic checks can ensure long-term reliability:

- **Visual Inspection:** Regularly inspect the module for any signs of physical damage, loose connections, or excessive dust accumulation.

- **Cleaning:** If necessary, gently clean the exterior of the module with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents. Ensure power is disconnected before cleaning.
- **Environmental Conditions:** Verify that the operating environment remains within the specified temperature and humidity ranges to prevent premature component failure.
- **Connection Integrity:** Periodically check that all wiring connections are secure and free from corrosion.

Troubleshooting

If the module is not functioning as expected, consider the following troubleshooting steps:

- **No Power/Module Status Indicator Off:**
 - Verify that power is supplied to the module and the PointBus backplane.
 - Check for secure seating of the module on the DIN rail.
- **Network Status Indicator Flashing/Off:**
 - Check network cable connections.
 - Verify network configuration in the control system software.
 - Ensure the network adapter or controller is functioning correctly.
- **Incorrect or No Analog Readings:**
 - Verify the wiring from the sensor to the module, paying attention to polarity and terminal assignments.
 - Check the sensor itself for proper operation and calibration.
 - Confirm the input range and scaling configuration in the control system software matches the sensor and module.
 - Inspect for any open circuits or short circuits in the current loop.
- **Module Fault:**
 - If the Module Status indicator shows a fault, consult your control system's diagnostic tools for specific error codes or messages.
 - Try power cycling the module and system.

If issues persist, contact technical support.

Specifications

Attribute	Detail
Model Number	1734-IE8C
Manufacturer	CBBEXP
ASIN	B0C399HV6W
Type	Current Input Module
Application	Industrial Automation
Date First Available	April 22, 2023

Warranty and Support

This CBBEXP 1734-IE8C Current Input Module comes with a**One-Year Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or any inquiries regarding the module, please contact Zhengbang Automation. They specialize in PLC hardware and maintain a large stock, offering customer-oriented assistance.

Note: The warranty does not cover damage caused by improper installation, misuse, unauthorized modifications, or operation outside of specified environmental limits.

© 2023 CBBEXP. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question