

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BUYDEEM](#) /

› [BUYDEEM G553 Electric Food Steamer User Manual](#)

BUYDEEM G553

BUYDEEM G553 Electric Food Steamer User Manual

Model: G553 | Brand: BUYDEEM

1. INTRODUCTION

The BUYDEEM G553 Electric Food Steamer is a versatile kitchen appliance designed for healthy and convenient cooking. It integrates steaming, yogurt making, and slow cooking functions, offering a range of culinary possibilities. This manual provides essential information for safe operation, maintenance, and troubleshooting.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the main unit in water or other liquids.
- Ensure the appliance is unplugged when not in use and before cleaning.
- Keep out of reach of children.
- Use only on a stable, heat-resistant surface.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Exercise extreme caution when moving an appliance containing hot oil or other hot liquids.
- The appliance features dual boil-dry protection. If the water level is low, the cooker will pause and prompt you to add water. If there is no water, the power will shut down automatically.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your BUYDEEM G553 Electric Food Steamer:

- Main Unit with Control Panel and Water Reservoir
- Strengthened Glass Viewing Window Lid
- 18/8 Stainless Steel Large Steamer Tray
- BPA-Free Steam-gathering Ring
- Non-Stick Ceramic Plate
- All BPA Free Plastic components



Figure 3.1: Exploded view showing the main unit, 5L water reservoir, BPA-free plastic components, steam-gathering ring, 18/8 stainless steel large steamer tray, and strengthened glass viewing window lid.



Figure 3.2: The BUYDEEM G553 steamer shown with its BPA-free steam-gathering ring, non-stick ceramic plate, and two 18/8 stainless steel steamer trays.

4. SETUP AND FIRST USE

1. **Unpack:** Carefully remove all packaging materials and accessories.
2. **Clean:** Wash all removable parts (steamer trays, ceramic plate, lid) with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are dry before assembly.
3. **Assemble:** Place the steam-gathering ring into the main unit. Position the stainless steel steamer tray on top. If using, place the ceramic plate inside the steamer tray. Cover with the glass lid.
4. **Fill Water Reservoir:** Open the water inlet on the side of the main unit. Fill the 5-quart water reservoir with clean water up to the MAX line.



Figure 4.1: Water being poured into the individual water inlet on the side of the steamer.

5. **Power On:** Plug the power cord into a grounded electrical outlet. The display will illuminate.
6. **Initial Boil (Recommended):** For first use, run a steaming cycle with just water for 10-15 minutes to remove any manufacturing residues. Discard the water afterward.

5. OPERATING INSTRUCTIONS

5.1 Basic Steaming

1. Ensure the water reservoir is filled to an appropriate level.
2. Place food on the stainless steel steamer tray or ceramic plate.
3. Cover with the glass lid.
4. Press the **Menu** button to select the "Steam" function.
5. Use the rotary knob to adjust the desired steaming time (0-90 minutes).
6. Press **Start/Pause** to begin steaming. The appliance will quickly generate steam within 1 minute.
7. To add water during operation, use the side water inlet. The appliance will automatically pause if water levels are critically low.



Figure 5.1: The water level indicator shows MIN and MAX levels for easy monitoring.

8. Once the timer completes, the appliance will beep and may switch to a "Warm" setting if selected.

5.2 Smart Programs and Functions

The BUYDEEM G553 offers multiple smart programs for diverse cooking needs:

- **Steam (0-90 minutes):** Ideal for vegetables, seafood, fish, dumplings, dim sum, and meat.
- **Slow Cook (10 minutes - 6 hours):** Suitable for rice cooking, soups, and other water-cooked ingredients. After cooking, the appliance automatically keeps warm at 85°C for 6 hours.
- **Yogurt (8-9.5 hours):** For homemade yogurt, maintaining a temperature of 40°C.
- **Warm (0-18 hours):** Keeps food warm after cooking.

- **Preset (0-18 hours):** Allows you to program the start time up to 18 hours in advance.



Figure 5.2: The 18-hour delay timer allows for convenient meal planning.

To select a program, press the **Menu** button repeatedly until the desired function is displayed. Adjust time with the rotary knob and press **Start/Pause**.

5.3 Suggested Cooking Times

Food Item	Suggested Steam Time
Shrimp	10 mins
Weever fish	10-15 mins
Steamed water egg	15 mins
Pork rib	15-30 mins
Chinese leaf	10-15 mins
Rice	40 mins
Corn	30 mins
Steamed buns	25-45 mins

Food Item	Suggested Slow Cook Time
Bird nest	30 mins
Dessert	1 H
Congee	1 H
Soup	2 H

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your steamer.

1. **Unplug:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Clean Removable Parts:** The stainless steel steamer tray, ceramic plate, and lid are dishwasher safe or can be washed by hand with warm soapy water. Rinse thoroughly and dry.
3. **Clean Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. **Descaling:** Over time, mineral deposits may accumulate in the water reservoir. To descale, fill the reservoir with a mixture of water and white vinegar (1:1 ratio). Run a steaming cycle for 15-20 minutes. Allow to cool, then drain and rinse thoroughly.
5. **Storage:** Store the clean and dry appliance in a cool, dry place.



Figure 6.1: The drip tray design collects water waste into the reservoir, simplifying cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not properly plugged in; power outlet issue; boil-dry protection activated.	Ensure the power cord is securely plugged into a working outlet. Check the water level; add water if necessary. If the issue persists, contact customer support.
"Add Water" prompt appears during operation.	Water level in the reservoir is low.	Carefully open the side water inlet and add water until the MAX line is reached. The appliance will resume operation.
Steam production is low or inconsistent.	Insufficient water; mineral buildup in the heating element.	Check water level and refill if needed. Perform a descaling procedure as described in the Maintenance section.
Food is not cooking evenly.	Overcrowding the steamer tray; uneven food placement.	Avoid overcrowding; arrange food in a single layer for best results. Cut larger food items into smaller, uniform pieces.

Dual Boil Dry Protection



With the water at a low level, the cooker will stop working and reminds you of adding water.



With no water and the first protection breakdown, the power will shut down automatically.



Figure 7.1: The steamer's display indicates when water levels are low, prompting the user to add water.

8. SPECIFICATIONS

- **Model:** G553
- **Brand:** BUYDEEM
- **Capacity:** 5 Quarts
- **Color:** Cozy Greenish
- **Material:** Glass, Stainless Steel
- **Product Dimensions (L x W x H):** 13.19" x 11.61" x 11.22"
- **Item Weight:** 9.47 Pounds
- **Power:** Electric
- **UPC:** 810059970717
- **ASIN:** B0C3RGFNKM



Figure 8.1: Detailed dimensions of the BUYDEEM G553 Electric Food Steamer.

9. WARRANTY INFORMATION

For detailed warranty information regarding your BUYDEEM G553 Electric Food Steamer, please refer to the official BUYDEEM website or the warranty card included with your product. Warranty terms and conditions may vary by region and purchase date.

10. CUSTOMER SUPPORT

Should you have any questions, concerns, or require assistance with your BUYDEEM G553 Electric Food Steamer, please contact the BUYDEEM support team. Contact information can typically be found on the official BUYDEEM website or within your product packaging.