

[Manuals.plus](#) /

> [ZABBOW](#) /

> Multi-Functional Manual Food Processor,8 Cup Hand-powered Crank Chopper,Mincer Blender with Clear Container,for Vegetables Meat Fruits Nuts Herbs Onions (Without Base)

ZABBOW LG-006

ZABBOW Multi-Functional Manual Food Processor

Model: LG-006

PRODUCT OVERVIEW

The ZABBOW Multi-Functional Manual Food Processor is an 8-cup hand-powered crank chopper, mincer, and blender designed for a variety of ingredients including vegetables, meat, fruits, nuts, herbs, and onions. It features durable 420 stainless steel blades, a comfort soft grip lid, an anti-skid base for stability, and a large handle for easy leverage. This appliance is made from BPA-Free, food-grade plastic, ensuring safety and durability. It operates without electricity, making it quiet and portable, and all parts are detachable for easy hand washing.



Figure 1: ZABOW Multi-Functional Manual Food Processor assembled.

COMPONENTS

The ZABOW Manual Food Processor comes with the following components:

- **Main Bowl:** Clear, 1.5L capacity container.
- **Lid with Crank Handle:** Red and black lid with an integrated hand-crank mechanism. Features an egg yolk separator.
- **3-Blade Rotary Blade:** Sharp 420 stainless steel blades for chopping and mincing.
- **Stirring Blade:** White plastic attachment for mixing and pureeing.
- **Anti-Skid Base:** Integrated into the main bowl for stability during use.



Figure 2: Lid with Crank Handle.



Figure 3: 3-Blade Rotary Blade.



Figure 4: Stirring Blade.

SETUP

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Wash Before First Use:** Hand wash all components (bowl, blades, lid) with warm, soapy water. Rinse thoroughly and dry completely.
3. **Insert Blade:** Place either the 3-blade rotary blade or the stirring blade onto the central pin inside the main

bowl. Ensure it is securely seated.

4. **Attach Lid:** Align the lid with the main bowl and twist clockwise until it locks securely into place. The handle should be positioned for comfortable cranking.

Your browser does not support the video tag.

Video 1: Official ZABBOW Manual Food Processor demonstration, showing assembly and basic operation.

OPERATING INSTRUCTIONS

This manual food processor is versatile for various kitchen tasks:

Chopping and Mincing (using 3-Blade Rotary Blade):

1. **Prepare Ingredients:** Cut larger ingredients into smaller, manageable pieces (e.g., quarter an onion) to fit comfortably around the blades.
2. **Load Bowl:** Place prepared ingredients into the main bowl, ensuring not to overfill.
3. **Secure Lid:** Attach and lock the lid firmly.
4. **Crank:** Place one hand on top of the lid to stabilize the unit. Use the other hand to turn the crank handle. Turn clockwise for chopping. The more you crank, the finer the chop.
5. **Check Consistency:** Periodically remove the lid to check the consistency of your ingredients.



Figure 5: Chopping carrots with the manual food processor.

Mixing and Pureeing (using Stirring Blade):

1. **Insert Stirring Blade:** Replace the chopping blade with the stirring blade.
2. **Add Ingredients:** Place liquids or soft ingredients into the bowl. For egg yolks, use the dedicated separator on the lid.
3. **Secure Lid:** Attach and lock the lid firmly.
4. **Crank:** Turn the crank handle to mix or puree. Continue until desired consistency is achieved.



Figure 6: Mixing egg and flour using the stirring blade.

MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your food processor.

- **Disassembly:** Unlock and remove the lid. Carefully remove the blade(s) from the central pin.
- **Hand Wash Only:** All parts of the food processor are designed for hand washing. Use warm, soapy water and a soft sponge or brush. Be extremely careful when handling the sharp blades.
- **Rinse Thoroughly:** Rinse all components under running water to remove any soap residue.
- **Dry Completely:** Allow all parts to air dry completely before reassembling or storing to prevent mildew and odors.

Your browser does not support the video tag.

Video 2: Official ZABBOW Manual Food Processor demonstration, showing how to disassemble and clean the blades and bowl.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Blades not turning or difficulty cranking.	Bowl is overfilled; ingredients are too large or hard; lid not properly secured.	Reduce the amount of ingredients. Cut ingredients into smaller pieces. Ensure the lid is twisted and locked into place.
Ingredients not chopping evenly.	Not enough cranking; ingredients stuck to sides.	Continue cranking for a finer and more even chop. Scrape down the sides of the bowl with a spatula if needed.
Lid is difficult to remove.	Lid is still locked.	Twist the lid counter-clockwise to unlock before attempting to lift.

SPECIFICATIONS

Feature	Detail
Brand	ZABBOW
Model Name	Vegetable Chopper (LG-006)
Special Feature	Built-In Grinder (referring to chopping/mincing function)
Product Dimensions	7.28"D x 9.3"W x 9.2"H
Bowl Capacity	1.5 Liters (approx. 8 cups)
Blade Material	420 Stainless Steel
Power Source	Manual Winding
Product Care Instructions	Hand Wash
Item Weight	1.61 pounds

WARRANTY AND SUPPORT

As a professional manufacturer of kitchen manual tools, ZABBOW is committed to ensuring customer satisfaction. If you encounter any issues with your Multi-Functional Manual Food Processor, please feel free to contact us. We aim to resolve any problems within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official ZABBOW store online.

© 2023 ZABBOW. All rights reserved.