

58648-Mcgraw

Generic 6 in. Dual-Action Air Sander Instruction Manual

Model: 58648-Mcgraw

INTRODUCTION

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your Generic 6 in. Dual-Action Air Sander, Model 58648-Mcgraw. This tool is designed for aggressive material removal while delivering a smooth, swirl-free finish on both wood and metal surfaces. It features a 5/16 inch orbit, a 10,000 RPM motor with an adjustable speed regulator, a urethane pad for edging and feathering, sealed bearings for extended service life, a balanced design to reduce vibration, and a lightweight housing for comfortable handling.



Figure 1: Generic 6 inch Dual-Action Air Sander. This image shows the overall design of the air sander, highlighting its compact and ergonomic form factor.

SAFETY INFORMATION

Always observe basic safety precautions when using this air sander to reduce the risk of injury. Read and understand all instructions before operation.

- Wear appropriate personal protective equipment (PPE), including safety glasses, hearing protection, and a dust mask.
- Ensure your work area is clean, well-lit, and free from obstructions.
- Keep children and bystanders away from the operating area.
- Do not operate the tool in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Maintain a firm grip on the tool and be aware of its rotational force.
- Disconnect the air supply before making adjustments, changing accessories, or storing the tool.

- Use only accessories specifically designed for this air sander.
- Inspect the tool for damage before each use. Do not use if damaged.
- Ensure the air supply hose is free from kinks and damage.

INCLUDED COMPONENTS

Carefully unpack the contents and ensure all items are present and undamaged. If any parts are missing or damaged, contact customer support.

- Generic 6 in. Dual-Action Air Sander
- 6 in. PSA backing pad
- Spindle wrench

SETUP

Proper setup is crucial for safe and efficient operation.

1. Air Supply Connection:

- Ensure your air compressor can provide sufficient airflow (CFM) and pressure (PSI) for the sander's requirements. Refer to the Specifications section.
- Connect a 3/8 inch minimum diameter air hose to the air inlet of the sander. Use thread sealant tape on all threaded connections to prevent leaks.
- Install an in-line air filter/lubricator as close to the tool as possible to ensure clean, lubricated air.

2. Attaching the Sanding Pad:

- The sander comes with a 6 in. PSA (Pressure Sensitive Adhesive) backing pad.
- Align the sanding disc with the backing pad and press firmly to ensure good adhesion.
- For optimal performance, use high-quality sanding discs appropriate for your application.

3. Adjusting Air Pressure:

- Before connecting the tool to the air supply, ensure the air regulator on your compressor or air line is set to the lowest pressure.
- Connect the air hose to the sander.
- Gradually increase the air pressure to the recommended operating pressure (refer to Specifications). Do not exceed the maximum operating pressure.




Figure 2: Close-up view of the Generic 6 inch Dual-Action Air Sander. This image highlights the air inlet and the adjustable speed regulator, crucial for proper setup and operation.

OPERATING INSTRUCTIONS

Follow these steps for effective and safe operation of your air sander.

1. Workpiece Preparation:

- Secure the workpiece firmly to prevent movement during sanding.
- Clean the surface of any loose debris or contaminants.

2. Starting the Sander:

- Hold the sander firmly with both hands.
- Place the sanding pad flat against the workpiece surface before engaging the trigger.
- Press the trigger to start the sander.

3. Sanding Technique:

- Apply light, even pressure. Excessive pressure will reduce sanding efficiency and may damage the tool or workpiece.
- Move the sander in overlapping circular or elliptical patterns to ensure an even finish and prevent swirl marks.
- Adjust the speed regulator as needed for different materials and desired finish. Higher speeds are generally for aggressive removal, lower speeds for fine finishing.
- Avoid tilting the sander, as this can create uneven sanding and damage the pad or workpiece.

4. Stopping the Sander:

- Lift the sander off the workpiece before releasing the trigger.
- Always disconnect the air supply when not in use or when changing sanding discs.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your air sander.

• Daily:

- Disconnect from air supply.
- Wipe down the tool with a clean, dry cloth.
- Check the air hose for wear or damage.
- Ensure the air filter/lubricator is functioning correctly and filled with appropriate air tool oil.

• Weekly/After Heavy Use:

- Inspect the backing pad for wear or damage. Replace if necessary.
- Check all fasteners for tightness.
- Apply a few drops of air tool oil into the air inlet before and after each use, or as recommended by the air tool oil manufacturer.

• Storage:

- Store the sander in a clean, dry environment, away from direct sunlight and extreme temperatures.
- Disconnect the air supply and drain any moisture from the air compressor tank.

TROUBLESHOOTING

Refer to this section for common issues and their potential solutions.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Sander not operating or low power	Low air pressure; Restricted air flow; Lack of lubrication; Damaged internal components	Check air compressor pressure and regulator setting; Inspect air hose for kinks or blockages; Add air tool oil to air inlet; Contact qualified service personnel
Poor sanding finish / Swirl marks	Worn sanding disc; Incorrect grit for application; Excessive pressure; Uneven sanding technique	Replace sanding disc; Use appropriate grit; Apply lighter, even pressure; Improve sanding technique with overlapping passes
Excessive vibration	Damaged backing pad; Unbalanced sanding disc; Worn bearings	Inspect and replace backing pad if damaged; Ensure sanding disc is centered; Contact qualified service personnel for bearing inspection
Air leaks	Loose fittings; Damaged O-rings or seals	Tighten all air fittings; Apply thread sealant tape; Replace damaged O-rings or seals

SPECIFICATIONS

Feature	Detail
Brand	Generic
Model Number	58648-Mcgraw
Item Type Name	6 in. Dual-Action Air Sander
Power Source	Air Powered
Maximum Rotational Speed	10,000 RPM
Orbit Size	5/16 in.
Grit Type	Coarse, Medium, Fine (depending on disc used)
Item Weight	4.3 pounds
Included Components	Air Sander, 6 in. PSA backing pad, spindle wrench
UPC	193175443250

WARRANTY

The manufacturer guarantees this product to be free from defects in materials and workmanship for 90 days from the date of purchase. Limitations apply. Please retain your proof of purchase for warranty claims. For full details on warranty coverage and limitations, refer to the documentation included with your product or contact the manufacturer directly.

SUPPORT

For technical assistance, replacement parts, or further information regarding your Generic 6 in. Dual-Action Air Sander, please contact the manufacturer's customer support. Refer to the packaging or the manufacturer's website for current contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question