

MS-7848

Essentielb MS-7848 VER 1.0 LGA1150 DDR3 Desktop Motherboard User Manual

Model: MS-7848

1. INTRODUCTION

This manual provides detailed instructions for the installation, configuration, and maintenance of the Essentielb MS-7848 VER 1.0 Desktop Motherboard. This motherboard supports LGA1150 processors and DDR3 memory, designed for personal computer systems. Please read this manual thoroughly before proceeding with any installation or operation to ensure proper functionality and safety.

2. SAFETY INFORMATION

- Always disconnect the power supply from the wall outlet before installing or removing any components.
- Wear an anti-static wrist strap or frequently touch a grounded metal object to discharge static electricity before handling the motherboard or other components. Static electricity can damage electronic components.
- Handle the motherboard by its edges to avoid touching sensitive components.
- Ensure proper ventilation within the computer case to prevent overheating.
- Keep the motherboard away from moisture and extreme temperatures.

3. PACKAGE CONTENTS

Verify that all items are present in your package. If any item is missing or damaged, contact your retailer.

- Essentielb MS-7848 VER 1.0 Motherboard
- I/O Shield
- SATA Data Cable(s) (quantity may vary)
- User Manual (this document)
- Driver CD/DVD (or link to download drivers)

4. SETUP AND INSTALLATION

4.1 Motherboard Layout

Familiarize yourself with the various components and connectors on the motherboard before installation.




Figure 1: Top-down view of the Essentielb MS-7848 motherboard. This image displays the central LGA1150 CPU socket, two DDR3 RAM slots to its right, multiple PCIe expansion slots below, and various power and data connectors around the board's perimeter. The rear I/O panel is visible on the left side.




Figure 2: Close-up of the LGA1150 CPU socket. This image provides a detailed view of the CPU socket with its retention mechanism, surrounded by power delivery components and the CMOS battery. The model number 'MS-7848 VER 1.0' is clearly visible on the PCB.

4.2 CPU Installation

1. Locate the LGA1150 CPU socket on the motherboard.
2. Gently push down the load lever and pull it away from the socket to open the CPU socket cover.
3. Carefully align the notches on your LGA1150 CPU with the alignment keys on the socket. The golden triangle on the CPU should match the triangle on the socket.
4. Place the CPU gently into the socket. Do not force it. If it does not sit correctly, re-check alignment.
5. Close the load plate and push the load lever back into place until it clicks. This will secure the CPU.
6. Apply thermal paste to the CPU surface and install the CPU cooler according to its manufacturer's instructions.

4.3 RAM Installation

The Essentielb MS-7848 supports DDR3 memory modules. Refer to the specifications for supported speeds and

capacities.

1. Open the clips at both ends of the DIMM slot.
2. Align the notch on the DDR3 memory module with the key in the DIMM slot.
3. Insert the memory module firmly into the slot until the clips snap into place, securing the module.

4.4 Storage Device (SATA) Connection

Connect your SATA hard drives or SSDs to the SATA ports on the motherboard using SATA data cables. Connect the power cables from your power supply to the drives.

4.5 Expansion Card (PCIe) Installation

This motherboard features PCIe slots for graphics cards and other expansion cards.

1. Align the expansion card with the desired PCIe slot.
2. Press down firmly until the card is fully seated in the slot.
3. Secure the card with a screw to the computer case.

4.6 Front Panel Connections

Connect the front panel cables (power button, reset button, HDD LED, power LED, USB ports, audio jacks) from your computer case to the corresponding headers on the motherboard. Refer to the motherboard diagram for exact pin locations.

4.7 Power Supply Connection

Connect the 24-pin ATX main power connector and the 4-pin or 8-pin ATX 12V CPU power connector from your power supply to the respective ports on the motherboard.

5. OPERATING INSTRUCTIONS

5.1 First Boot

After completing all hardware installations, connect your monitor, keyboard, and mouse. Power on the system. The system should display the BIOS/UEFI splash screen.

5.2 BIOS/UEFI Configuration

During startup, press the designated key (usually **DEL** or **F2**) to enter the BIOS/UEFI setup utility. Here you can configure boot order, system time, and other hardware settings. Save changes before exiting.

5.3 Driver Installation

After installing your operating system, install the necessary drivers for the motherboard's chipset, audio, network, and any other integrated components. These drivers are typically provided on a CD/DVD or can be downloaded from the manufacturer's website.

6. MAINTENANCE

6.1 Cleaning

Regularly clean the interior of your computer case to prevent dust buildup, which can lead to overheating. Use compressed air to remove dust from fans, heatsinks, and other components. Ensure the system is powered off and

unplugged before cleaning.

6.2 BIOS Updates

Periodically check the manufacturer's website for BIOS/UEFI updates. Updates can improve system stability, add support for new hardware, or fix bugs. Follow the update instructions carefully to avoid damaging the motherboard.

7. TROUBLESHOOTING

- **No Power:** Ensure all power cables (24-pin ATX, 4/8-pin CPU) are securely connected. Check the power supply unit (PSU) and wall outlet.
- **No Display:** Verify that the monitor is connected and powered on. Ensure the graphics card (if dedicated) is properly seated and powered. Try reseating RAM modules.
- **System Instability/Crashes:** Check RAM modules for proper seating. Ensure CPU cooler is correctly installed and making good contact. Verify power supply is sufficient for all components.
- **Operating System Not Booting:** Check boot order in BIOS/UEFI. Ensure storage drives are properly connected and detected.
- **Peripheral Issues:** Ensure USB devices are connected to functional ports. Install correct drivers for all peripherals.

8. SPECIFICATIONS

Feature	Specification
Brand	Generic
Model Name	MS 7848
CPU Socket	LGA 1150
Compatible Processors	Intel Core i5-4xxx, Intel Core i7-4xxx, Intel Core i5-5xxx, Intel Core i7-5xxx
RAM Technology	DDR3
Available Memory Slots	1
Compatible Devices	Personal Computer
Platform	Windows
Main Power Connector	24-pin
Graphics Card Interface	PCI Express
Supported System Bus Standard	PCIe 2.0
Total SATA Ports	6
Total USB Ports	2
Total PCIe Ports	1
Part Number	VCDi_Sei_101665

ASIN	B0C64XFTV1
------	------------

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided by your retailer or contact the product manufacturer directly. Keep your proof of purchase for warranty claims.