

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Morphy Richards](#) /
- › [Morphy Richards 5 Litre Classic Air Fryer Instruction Manual](#)

## Morphy Richards 510059

# Morphy Richards 5 Litre Classic Air Fryer Instruction Manual

Model: 510059

## 1. INTRODUCTION

---

Thank you for choosing the Morphy Richards 5 Litre Classic Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, using rapid air circulation technology to fry, bake, grill, and roast with little to no oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image 1.1: The Morphy Richards 5 Litre Classic Air Fryer, showcasing its compact and modern design.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Always ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow for proper air circulation.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- The air fryer features a **cool-touch handle** for safe handling of the basket during and after cooking. Always use the handle to remove the basket.
- This appliance is equipped with **voltage fluctuation protection** to safeguard against unexpected power changes. However, always unplug the appliance when not in use and before cleaning.
- Do not block any ventilation openings.
- Keep all ingredients in the basket to prevent contact with heating elements.
- Do not overfill the basket.
- Regularly inspect the power cord for any damage. If damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

### 3. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your Morphy Richards Air Fryer:

- **Temperature Control Knob:** Used to set the desired cooking temperature.
- **Timer Control Knob:** Used to set the cooking time.
- **Air Inlet:** Located at the top of the appliance.
- **Air Outlet Vents:** Located at the rear of the appliance.
- **Fry Basket:** The removable cooking container with a non-stick coating.
- **Fry Tray:** Inserted into the fry basket for optimal air circulation and fat separation.
- **Cool-Touch Handle:** For safe removal and insertion of the fry basket.

**Morphy  
Richards**  
Happiness Engineered

**Smart cooking solutions  
for your kitchen**



Image 3.1: Key components of the air fryer, including the non-stick coated basket, cool-touch handle, and control knobs.

### 4. SETUP AND FIRST USE

---

Before using your air fryer for the first time, follow these steps:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the fry basket and fry tray thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
3. Wipe the inside and outside of the appliance with a damp cloth.
4. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm of free space at the back and sides, and 10 cm above the appliance.
5. Plug the appliance into a grounded wall socket.
6. It is recommended to run the air fryer empty for about 10 minutes at 200°C (400°F) during the first use to burn off any manufacturing residues. A slight odor may be present, which is normal.

## 5. OPERATING INSTRUCTIONS

---

The Morphy Richards Classic Air Fryer features easy-to-use knob controls for precise cooking.

### 5.1. Basic Operation

1. Place the fry tray into the fry basket, then slide the fry basket into the air fryer.
2. Place your ingredients into the fry basket. Do not exceed the MAX fill line.
3. Plug the air fryer into a power outlet.
4. Turn the **Temperature Control Knob** to your desired temperature.
5. Turn the **Timer Control Knob** to the required cooking time. The air fryer will start heating automatically.
6. During cooking, you can pull out the basket to shake or flip ingredients. The air fryer will pause and resume once the basket is reinserted.
7. When the timer reaches zero, the air fryer will automatically switch off. Carefully pull out the basket and remove the cooked food.

**Morphy  
Richards**  
Happiness Engineered



\*T&C apply

Image 5.1: The intuitive knob controls for setting temperature and time.

## 5.2. Adjustable Time & Temperature Control

The air fryer allows you to precisely control both cooking time and temperature for a wide range of recipes:

- **Temperature Range:** Typically from 80°C to 200°C (175°F to 400°F). Adjust based on the food type and desired crispiness.
- **Timer Range:** Up to 30 minutes. For longer cooking times, reset the timer after each cycle.
- Always refer to recipe guidelines for specific time and temperature settings.

## 6. COOKING GUIDE

The Morphy Richards Air Fryer is versatile and can be used for various cooking methods. Here are some general guidelines:

- **Frying:** Achieve crispy results for items like French fries, chicken nuggets, and spring rolls with significantly less oil than traditional deep frying.
- **Roasting:** Perfect for vegetables such as potatoes, carrots, and broccoli, or smaller cuts of meat.
- **Grilling:** Ideal for chicken wings, fish fillets, or small skewers.

- **Baking:** Suitable for small cakes, muffins, or baked apples.

For best results, preheat the air fryer for 3-5 minutes before adding ingredients. Shake the basket halfway through cooking for even browning.



Image 6.1: The air fryer preparing various delicious and healthier meals.

## 7. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

- **Fry Basket and Fry Tray:** These parts have a **non-stick coating**. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residues, soak them in hot water for about 10 minutes.
- **Appliance Exterior:** Wipe with a damp cloth. Do not use abrasive cleaning agents.
- **Interior:** Wipe the inside with a damp cloth. If necessary, use a soft brush to remove food residues from the heating element.
- The fry basket and fry tray are **not dishwasher safe**. Hand washing is recommended to preserve the non-stick coating.



Image 7.1: The non-stick coated basket and accessories, designed for easy cleaning.

## 8. TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not work.	The appliance is not plugged in. The timer is not set.	Plug the main plug into a grounded wall socket. Turn the timer knob to the desired cooking time.
Food is not cooked evenly.	Basket is overloaded. Ingredients are not shaken.	Reduce the amount of ingredients. Shake or flip ingredients halfway through cooking.
White smoke comes from the appliance.	Fat residues from previous use. Excess oil on ingredients.	Clean the basket and tray thoroughly. Pat ingredients dry before air frying.
Fresh fries are not crispy.	Not enough oil used. Incorrect temperature/time.	Add a little oil to the fries. Adjust temperature and time as per recipe.

If the problem persists after checking these points, please contact customer support.

## 9. SPECIFICATIONS

Feature	Specification
Model Name	Morphy Richards 5 Litre Classic Air Fryer Black
Item Model Number	510059

Feature	Specification
Capacity	5 litres
Wattage	1500 Watts
Voltage	230 Volts
Control Method	Knob
Special Feature	Temperature Control, Voltage Fluctuation Protection
Material	Plastic (Outer), Non-stick (Inner)
Product Dimensions	35.7D x 35.7W x 37H Centimeters
Item Weight	4.39 Kilograms
Included Components	Air Fryer: 1N, Fry Basket: 1N, Fry Tray: 1N, Warranty Card: 1N, Instruction Manual: 1N

## 10. WARRANTY AND SUPPORT

---

Your Morphy Richards 5 Litre Classic Air Fryer comes with a **2-year warranty** by the brand, covering manufacturing defects from the date of purchase. Please retain your purchase receipt for warranty claims.

For any product-related queries, service requests, or warranty claims, please contact:

- **Manufacturer/Importer:** Imported & Marketed by Bajaj Electricals Ltd
- **Email:** [consumercare@morphyrichardsindia.com](mailto:consumercare@morphyrichardsindia.com)