

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [DOOMAY](#) /

› [DOOMAY Digital Alarm Clock Instruction Manual](#)

### DOOMAY 5293B

## DOOMAY Digital Alarm Clock Instruction Manual

Model: 5293B  
Brand: DOOMAY

### 1. INTRODUCTION

Thank you for choosing the DOOMAY Digital Alarm Clock. This compact and modern alarm clock is designed for convenience and reliability, featuring an LCD display, adjustable volume, snooze function, weekend mode, and indoor temperature display. This manual provides detailed instructions to help you set up and operate your new alarm clock effectively.



Figure 1: Front view of the DOOMAY Digital Alarm Clock.

## 2. PACKAGE CONTENTS

---

- DOOMAY Digital Alarm Clock (1 unit)
- AAA Batteries (2 units)
- Instruction Manual (This document)

## 3. SETUP

---

### 3.1 Battery Installation

The DOOMAY Digital Alarm Clock is powered by two AAA batteries. These batteries are included in the package.

1. Locate the battery compartment cover on the back of the alarm clock.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover by sliding it upwards until it clicks into place.



Figure 2: Back view with battery compartment and control buttons.

**Note:** When the display flashes '8888' and the clock beeps, it indicates that the batteries are low and need to be replaced.

#### 4. OPERATING INSTRUCTIONS

The DOOMAY Digital Alarm Clock offers various functions for timekeeping, alarming, and environmental monitoring. Refer to the buttons on the back of the clock for settings.



Figure 3: Overview of clock features.

## 4.1 Time and Date Setting

To set the current time and date:

1. Press and hold the **SET** button (usually represented by a clock icon or '12/24H' button) on the back of the clock until the numbers on the display begin to flash.
2. Use the **+** and **-** buttons to adjust the flashing value (Year, Month, Day, Hour, Minute).
3. Press the **SET** button again to confirm the setting and move to the next value.
4. Once all values are set, the display will stop flashing. The day of the week will automatically update based on the date.

For a visual guide, refer to the video below, specifically from [0:18 for Date Setting](#) and [0:32 for Time Setting](#).

## 4.2 Alarm Setting

To set your alarm time:

1. Press the **ALARM** button (bell icon) on the back of the clock. The alarm time will appear and flash.
2. Use the **+** and **-** buttons to adjust the desired alarm hour and minute.



3. Press the **ALARM** button again to confirm the alarm setting.
4. To turn the alarm ON or OFF, simply press the **ALARM** button once. An alarm icon will appear on the display when the alarm is active.

For a visual guide, refer to the video below, specifically from [0:13 for turning alarm ON/OFF](#) and [0:37 for Alarm Setting](#).

### 4.3 Snooze Function

When the alarm sounds, gently touch the **SNOOZE/LIGHT** button located on the top of the clock. This will activate the snooze function, providing an additional 9 minutes of sleep before the alarm sounds again. You can repeat this process multiple times.



Figure 4: Activating the snooze function.

To turn off the alarm completely after it sounds, press any button on the back of the clock.

For a visual guide, refer to the video below, specifically from [0:46 for Snooze function](#).

### 4.4 Weekend Mode

The Weekend Mode allows you to set the alarm to only sound from Monday to Friday, preventing it from disturbing you on weekends.

- Press the **WEEKEND** button (calendar icon) on the back of the clock to toggle Weekend Mode ON or OFF.
- When Weekend Mode is active, 'WEEKEND' will be displayed on the screen, and the alarm will be automatically disabled on Saturday and Sunday.



## WEEKEND MODE ON

Alarm only goes off from Monday to Friday



Figure 5: Weekend Mode and Alarm Volume Levels.

For a visual guide, refer to the video below, specifically from [0:50 for Weekend Mode ON/OFF](#).

### 4.5 Backlight Function

The clock features a convenient 5-second on-demand backlight for viewing the time in low-light conditions.

- Simply touch the **SNOOZE/LIGHT** button on the top of the clock to activate the backlight.
- The backlight will illuminate for approximately 5 seconds and then automatically turn off to conserve battery life.

# 5 SECONDS BACKLIGHT

The backlight does not stay on all the time, only for 5s



Figure 6: Backlight in use.

For a visual guide, refer to the video below, specifically from [0:54 for 5 Seconds Backlight](#).

## 4.6 Temperature Display

The clock displays the indoor temperature. You can switch between Celsius (°C) and Fahrenheit (°F) units.

- Press the °C/°F button on the back of the clock to toggle between Celsius and Fahrenheit.



# Indoor Temperature Display

°F/°C Switchable



Figure 7: Indoor Temperature Display.

## 4.7 12/24 Hour Time Format

You can switch the time display between 12-hour (with AM/PM indicator) and 24-hour formats.

- Press the **12/24H** button on the back of the clock to switch between the two formats.

For a visual guide, refer to the video below, specifically from [0:58 for 12/24Hr Time Format Switchable](#)

## 4.8 Alarm Volume Adjustment

The alarm clock offers two volume levels for the alarm sound: LOW (70dB) and HIGH (85dB).

- While setting the alarm, or when the alarm is sounding, you can cycle through the volume levels by pressing the appropriate button (often the + or - button, or a dedicated volume button if available). Refer to the icons on the back of your clock.

For a visual guide, refer to the video below, specifically from [0:42 for 2 Levels of Volume Adjustable](#).

## Operating Instructions Video Guide



Your browser does not support the video tag.

Video 1: Comprehensive guide on setting up and operating the DOOMAY Digital Alarm Clock. This video demonstrates battery installation, setting time and date, alarm functions, snooze, weekend mode, backlight, and volume adjustment.

## 5. MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the low battery indicator appears (flashing '8888' and beeping). Always use new AAA batteries.
- **Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is blank or dim.	Batteries are dead or incorrectly installed.	Replace batteries with new AAA batteries, ensuring correct polarity.
Alarm does not sound.	Alarm is not activated or Weekend Mode is ON.	Press the ALARM button to activate. Check if Weekend Mode is active and disable if necessary.
Time/Date is incorrect.	Not set correctly or batteries were removed.	Follow instructions in Section 4.1 to reset time and date.
Backlight does not stay on.	This is normal operation.	The backlight is designed to illuminate for 5 seconds to conserve battery life. It is not a continuous backlight.




## 7. SPECIFICATIONS

- **Model:** 5293B
- **Display Type:** Digital LCD
- **Power Source:** 2 x AAA Batteries (Included)
- **Product Dimensions:** 4.29"W x 2.72"H (approx. 10.9cm x 6.9cm)
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Features:** Alarm, Snooze, Weekend Mode, Indoor Temperature (°C/°F), 12/24H Time Format, 5-second Backlight
- **Alarm Volume:** 2 levels (70dB, 85dB)
- **Item Weight:** 4.48 ounces (approx. 127g)

## 8. WARRANTY AND SUPPORT

DOOMAY products are manufactured with high-quality materials and craftsmanship. For any questions, concerns, or technical support regarding your DOOMAY Digital Alarm Clock, please contact the seller or refer to the product listing on the platform where it was purchased. Please retain your proof of purchase for warranty claims.



	<p><a href="#">DOOMAY Digital Alarm Clock User Manual</a></p> <p>Comprehensive guide for the DOOMAY Digital Alarm Clock, covering setup, features like snooze and weekend modes, and battery operation for bedroom, office, and travel use.</p>
	<p><a href="#">DOOMAY 5293 Digital Alarm Clock User Manual - Setup, Features, and Warranty</a></p> <p>Comprehensive user manual for the DOOMAY 5293 Digital Alarm Clock. Learn how to set time, date, alarms, use snooze, weekend mode, backlight, and understand warranty information.</p>
	<p><a href="#">DOOMAY Digital Alarm Clock Model 5293 User Manual</a></p> <p>User manual for the DOOMAY Digital Alarm Clock, Model 5293. This guide provides detailed instructions on setting the time, date, alarms, utilizing weekend mode, snooze function, backlight, and understanding temperature units and warranty information.</p>