

JD689B

Silver Crest Air Fryer User Manual

Model: JD689B

1. INTRODUCTION

Thank you for purchasing the Silver Crest Air Fryer, Model JD689B. This appliance is designed to cook a variety of foods using rapid hot air circulation, offering a healthier alternative to traditional frying with little to no oil. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your air fryer. Please read this manual thoroughly before first use and keep it for future reference.



Image 1: Front view of the Silver Crest Air Fryer, Model JD689B, showcasing its compact design and control panel.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate the appliance if the plug, power cord, or the appliance itself is damaged.
- Always unplug the appliance after use and before cleaning.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm of free space on the back and sides and 10 cm of free space above the appliance.
- Hot air is released through the air outlet opening. Keep your hands and face at a safe distance from the openings.
- Do not fill the basket with oil or other liquids, as this may cause a fire hazard.
- The surfaces may become hot during use. Do not touch hot surfaces directly. Use handles or knobs.
- This appliance is intended for household use only.

3. SETUP AND FIRST USE

Before using your air fryer for the first time, follow these steps:

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Retain the packaging for future storage or transport.
2. **Cleaning:** Wipe the exterior of the appliance with a damp cloth. Wash the removable basket and pan with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface, away from walls and other appliances to allow for proper air circulation.
4. **Initial Run:** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 180°C (356°F) to eliminate any manufacturing odors. A slight odor or smoke may be present, which is normal. Ensure the area is well-ventilated.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image 2: The air fryer with its cooking basket partially pulled out, demonstrating its internal capacity.

4. OPERATING INSTRUCTIONS

The Silver Crest Air Fryer features an intuitive touch control LCD screen for easy operation.

4.1 Basic Operation

- 1. Prepare Food:** Place your ingredients into the air fryer basket. Do not overfill the basket to ensure even cooking.
- 2. Insert Basket:** Slide the basket back into the air fryer until it clicks into place.
- 3. Power On:** Plug in the appliance. The LCD screen will illuminate.
- 4. Set Temperature and Time:**
 - Use the temperature control buttons on the touch screen to adjust the desired cooking temperature (e.g., 180°C).
 - Use the timer control buttons to set the desired cooking time (e.g., 15 minutes).
- 5. Start Cooking:** Press the start button to begin the cooking process. The air fryer will automatically preheat and then start cooking.
- 6. Shaking (Optional):** For some foods, especially smaller items like fries, shaking the basket halfway through cooking can ensure more even results. Carefully pull out the basket, shake the contents, and reinsert. The air fryer will resume cooking.
- 7. Completion:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and remove the cooked food.

4.2 Preset Modes

The air fryer comes with 4 preset modes for common dishes, allowing for one-touch cooking.



Image 3: Close-up of the smart LED screen showing touch controls and preset buttons for various cooking functions.

- Select the desired preset icon on the touch screen.
- The air fryer will automatically set the time and temperature.
- You can adjust the time or temperature manually even after selecting a preset if needed.
- Press the start button to begin cooking.

Smart LED Screen with One-touch Cooking Functions

4 Pre-Set Modes & Adjustable Time and Temperature, Start cooking in two steps, you can adjust the time or temperature to suit your usage.



Image 4: Diagram illustrating the 360° Rapid Air Circulation Technology within the air fryer, showing hot air flow around food.

The 360° Rapid Air Circulation Technology ensures even cooking by circulating hot air at high speed, locking in moisture and nutrients.

5. MAINTENANCE AND CLEANING

Regular cleaning of your air fryer will ensure its longevity and hygienic operation.

- Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
- Clean Basket and Pan:** The removable basket and pan are non-stick. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes. They are generally dishwasher safe, but hand washing is recommended to preserve the non-stick coating.
- Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or steel wool.
- Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
- Storage:** Ensure all parts are completely dry before storing the appliance. Store it in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in; power outlet malfunction.	Ensure the power cord is securely plugged into a working outlet.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket is overfilled; food not shaken.	Do not overfill the basket. Shake smaller food items halfway through cooking.
White smoke coming from the appliance.	Greasy residue from previous use; fatty ingredients.	Clean the basket and pan thoroughly after each use. For fatty foods, absorb excess oil with a paper towel.
Appliance emits a burning smell.	Food stuck in the heating element; excessive oil.	Unplug and let cool. Check for food debris in the heating element and clean. Ensure basket is not overfilled with oily food.

7. SPECIFICATIONS

Detailed technical specifications for the Silver Crest Air Fryer, Model JD689B:

Brand: Generic (Silver Crest)

Model Number: JD689B

Capacity: 8 Liters

Power: 1400 Watts

Voltage: 220 Volts

Material: Aluminum

Color: White

Product Dimensions (D x W x H): 30 cm x 30 cm x 40 cm

Item Weight: 750 grams

Special Features: Touch Control LCD Screen, Adjustable Timer, Temperature Control

Recommended Uses: Grilling, Defrosting, Steaming, Baking, Reheating

Healthier & Faster & More Versatile Cooking



Image 5: The air fryer highlighting its large 8-liter capacity, suitable for cooking for 4-6 people.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

For further assistance or technical inquiries, please visit the manufacturer's official website or contact their customer service hotline.