

Cuifati Cuifatipg823zgbh9

Cuifati ATX B75A Motherboard User Manual

Model: Cuifatipg823zgbh9

INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your Cuifati ATX B75A Motherboard. Please read this manual thoroughly before proceeding with installation to ensure proper setup and optimal performance. This motherboard is designed for desktop systems, supporting LGA1155 processors and DDR3 memory.

PRODUCT OVERVIEW AND KEY FEATURES

The Cuifati ATX B75A Motherboard offers a robust platform for your desktop computing needs. Key features include:

- High Definition Video Output:** Equipped with VGA and HD Multimedia Interface ports for digital high-definition video output.
- Rich Connectivity:** Features 2 x DDR3 memory slots, 1 x SATA3.0, 3 x SATA2.0 hard disk interfaces, and a total of 10 USB interfaces (including USB 3.0).
- Network Capability:** Supports a 100M network card interface for reliable internet connectivity.
- Stable Power Delivery:** Utilizes multiphase power design for enhanced stability and efficiency.
- Easy Installation:** Constructed with premium printed circuit board material for durability and straightforward setup.
- NVMe M.2 Support:** Includes an NVMe M.2 slot for high-speed storage solutions.
- PCIe 16X Slot:** Provides a dedicated slot for graphics cards.



Figure 1: Top-down view of the Cuifati ATX B75A Motherboard, showcasing the CPU socket, DDR3 memory slots, PCIe slot, and various ports.



Cuifati **B75A Motherboard**

The B75A desktop motherboard is a high-end computer motherboard with server-level performance, it is committed to creating the ultimate smooth computer experience, which is deeply loved by game enthusiasts

2xDDR3

1xNVME M.2

1xPCIe 16X

1xSATA3.0

1xVGA

1xWiFi M.2

1xHDMI

3xSATA2.0

Figure 2: Overview of the Cuifati B75A Motherboard highlighting key features such as 2xDDR3, 1xNVMe M.2, 1xPCIe 16X, 1xSATA3.0, 1xVGA, 1xWiFi M.2, 1xHDMI, and 3xSATA2.0.




Figure 3: Diagram illustrating product features including Intel LGA 1155 socket, DDR3 memory support, WiFi M.2, PCIe 16X, SATA 3.0 and 2.0 ports, and NVMe M.2 slot.



All solid state capacitance
All solid state, performance
is stable, greatly extend the
service life of the motherboard



100M network card
Realtek 8106E 100M network card



Front USB3.0 interface
Plug and play, 10 times
faster than USB2.0



VGA and HD Multimedia Interface
HD interface, maximize usability
and convenience

Figure 4: Motherboard view accompanied by icons representing solid state capacitance for stability, 100M network card, front USB 3.0 interface, and VGA/HD Multimedia Interface.

TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	Cuifati
Model Name	Cuifatipg823zgbh9
CPU Socket	LGA 1155
Compatible Processors	Intel Core 2 DUO (and other LGA 1155 compatible CPUs)
Chipset Type	Intel B75 Express
RAM Memory Technology	DDR3

Feature	Detail
Memory Clock Speed	Up to 2400 MHz (OC)
Memory Storage Capacity (Max)	16 GB
Product Dimensions	6.69 x 6.69 x 6.7 inches
Item Weight	1.1 pounds
Video Output	VGA, HD Multimedia Interface
Storage Interfaces	1 x SATA3.0, 3 x SATA2.0, 1 x NVMe M.2
Expansion Slots	1 x PCIe 16X
USB Interfaces	Multiple USB 2.0 and USB 3.0 ports
Network	100M Ethernet
Platform	Windows 10 compatible

SETUP GUIDE

Follow these steps to properly install your Cuifati ATX B75A Motherboard into your computer system.




Figure 5: Detailed diagram highlighting key components and connectors on the motherboard, including CPU Slot, DDR3 Memory Slots, 24PIN CPU Power Supply, SATA ports, NVMe M.2, USB ports, HDMI, VGA, and front panel connectors. Refer to this diagram for component locations during installation.

1. Preparation

- Ensure your power supply is disconnected from the wall outlet.
- Gather necessary tools: Phillips head screwdriver, anti-static wrist strap (recommended).
- Prepare your computer case by removing the side panel.

2. CPU Installation

1. Locate the LGA 1155 CPU socket on the motherboard (refer to Figure 5).
2. Gently lift the load plate lever and open the load plate.
3. Carefully align your LGA 1155 processor with the socket, ensuring the gold triangle on the CPU matches the indicator on the socket. Do not force the CPU into the socket.
4. Close the load plate and secure it with the lever.
5. Apply thermal paste to the CPU and install the CPU cooler according to its manufacturer's instructions.

3. Memory (RAM) Installation



Figure 6: Close-up view of the DDR3 memory slots and the 24-pin ATX power connector, essential for RAM and main power connections.

1. Identify the DDR3 memory slots (refer to Figure 5 and Figure 6).
2. Open the clips at both ends of the memory slot.
3. Align the notch on the DDR3 memory module with the key in the memory slot.
4. Press down firmly on both ends of the memory module until the clips snap into place.

4. Motherboard Installation into Case

1. Install the I/O shield into the rear opening of your computer case.
2. Carefully place the motherboard into the case, aligning the screw holes with the standoffs.
3. Secure the motherboard with screws. Do not overtighten.

5. Power Supply Connections

1. Connect the 24-pin ATX power connector from your power supply to the 24PIN CPU Power Supply header on the motherboard (refer to Figure 5 and Figure 6).
2. Connect the 4-pin or 8-pin CPU power connector (if applicable) to the 4PIN Power Supply header near the CPU socket.

6. Storage Device Connections

1. Connect your SATA storage devices (HDDs/SSDs) to the SATA3.0 (1 port) or SATA2.0 (3 ports) connectors on the motherboard using SATA data cables (refer to Figure 5).
2. If using an NVMe M.2 SSD, insert it into the NVMe M.2 slot and secure it with the provided screw (refer to Figure 5).

7. Front Panel Connections

Connect the front panel cables (Power SW, Reset SW, Power LED, HDD LED, Front USB, Front Audio) to their respective headers on the motherboard. Refer to Figure 5 for the location of these headers.

- **POWER SW:** Connects to the power button on your case.
- **RESET SW:** Connects to the reset button on your case.
- **POWER LED:** Connects to the power indicator light. Observe polarity.
- **HDD LED:** Connects to the hard drive activity indicator light. Observe polarity.
- **Front USB:** Connects to the front USB ports on your case.
- **Front Audio:** Connects to the front audio jacks on your case.

8. Expansion Cards

If installing a dedicated graphics card or other PCIe expansion cards, insert them into the PCIe 16X slot and secure them with the case's retention mechanism (refer to Figure 5).

9. Final Checks




Figure 7: Close-up view of the rear I/O panel, showing various ports including USB, Ethernet, VGA, and HD Multimedia Interface, where external devices will connect.

- Double-check all connections to ensure they are secure.
- Ensure no loose screws or cables are obstructing fans or components.
- Close the computer case side panel.

OPERATING INSTRUCTIONS

Once the motherboard and all components are correctly installed, you can proceed with operating your system.

1. Initial Power On

1. Connect your monitor, keyboard, and mouse to the appropriate ports on the rear I/O panel (refer to Figure 7).
2. Connect the power cable to your power supply and plug it into a wall outlet.
3. Press the power button on your computer case.
4. The system should power on, and you should see output on your monitor.

2. BIOS/UEFI Setup

Upon initial boot, you may need to enter the BIOS/UEFI setup to configure settings such as boot order, date/time, and enable specific features. Typically, you can access BIOS by pressing the **DEL** or **F2** key repeatedly during startup.

3. Operating System Installation

Install your preferred operating system (e.g., Windows 10) from a bootable USB drive or DVD. Follow the on-screen instructions provided by the operating system installer.

4. Driver Installation

After installing the operating system, install the necessary drivers for the motherboard chipset, audio, network, and any dedicated graphics cards. These drivers are usually provided on a CD/DVD with your components or can be downloaded from the manufacturer's websites.

MAINTENANCE

Proper maintenance ensures the longevity and stable performance of your motherboard and overall system.

- **Keep it Clean:** Regularly clean the interior of your computer case to prevent dust buildup on components, especially heatsinks and fans. Use compressed air for this purpose.
- **Ensure Proper Airflow:** Make sure your computer case has adequate ventilation and that fans are operating correctly to prevent overheating.
- **Update Drivers:** Periodically check for and install the latest drivers for your motherboard chipset, graphics card, and other peripherals to ensure optimal performance and compatibility.
- **BIOS/UEFI Updates:** Only update the BIOS/UEFI if necessary, and follow the manufacturer's instructions precisely. Incorrect BIOS updates can render your motherboard inoperable.
- **Avoid Physical Stress:** Handle the motherboard with care. Avoid bending or applying excessive force to components or connectors.

TROUBLESHOOTING

This section provides solutions to common issues you might encounter.

No Power / System Does Not Turn On

- **Check Power Connections:** Ensure the 24-pin ATX power connector and the 4-pin/8-pin CPU power connector are securely seated on the motherboard.
- **Power Supply:** Verify that the power supply is switched on and connected to a working power outlet. Test the power supply if possible.
- **Front Panel Connections:** Double-check the POWER SW header connection on the motherboard.
- **Short Circuit:** Remove the motherboard from the case and test it on a non-conductive surface (e.g., cardboard box) with only essential components (CPU, one RAM stick, CPU cooler, power supply). This helps rule out short circuits caused by the case.

No Display Output

- **Monitor Connection:** Ensure the monitor is properly connected to the VGA or HD Multimedia Interface port on the motherboard (or dedicated graphics card) and is powered on.
- **RAM:** Reseat the DDR3 memory modules. Try booting with only one RAM stick.
- **Graphics Card:** If using a dedicated graphics card, ensure it is properly seated in the PCIe 16X slot and has auxiliary power connected (if required).
- **BIOS Settings:** If you have a dedicated graphics card, ensure the BIOS is configured to use it as the

primary display output.

System Instability / Random Crashes

- **Overheating:** Check CPU and case temperatures. Ensure CPU cooler is properly installed and fans are working. Clean dust from heatsinks.
- **RAM Issues:** Run a memory diagnostic tool to check for faulty RAM modules.
- **Driver Issues:** Ensure all drivers are up-to-date and correctly installed.
- **Power Supply:** An insufficient or failing power supply can cause instability.

Slow Performance / Lagging

- **Storage:** Check the health of your storage drives (HDD/SSD). Ensure the operating system is installed on a fast drive (e.g., NVMe M.2 SSD).
- **CPU/RAM Usage:** Monitor CPU and RAM usage to identify resource-intensive applications.
- **Drivers:** Outdated drivers can sometimes lead to performance issues.
- **Operating System:** Ensure your operating system is optimized and free from malware.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Cuifati website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Cuifati customer support through their official channels. Please have your product model number (Cuifatipg823zgbh9) and purchase details ready.