

[Manuals.plus](#) /

› [Royal Silver Crest](#) /

› Royal Silver Crest 8L Air Fryer User Manual

## Royal Silver Crest 18

# Royal Silver Crest 8L Air Fryer User Manual

Model: 18

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read these safety instructions carefully before using the appliance and keep them for future reference. Incorrect use may result in personal injury and property damage.

- **Electrical Safety:** Ensure the voltage matches your local power supply. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- **Hot Surfaces:** Surfaces may become hot during use. Do not touch hot surfaces directly. Use handles or oven mitts.
- **Ventilation:** Do not block any ventilation openings. Allow sufficient space around the appliance for proper air circulation.
- **Placement:** Place the appliance on a stable, heat-resistant surface, away from walls and other heat sources.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Damage:** Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.

## 2. PRODUCT OVERVIEW

---

The Royal Silver Crest Air Fryer utilizes rapid air convection heating technology to cook food with significantly less oil, offering a healthier alternative to traditional frying.

### 2.1 Components

- Main Unit with Control Panel
- Removable Frying Basket
- Crisper Plate
- Power Cord

## 2.2 Features

- **Capacity:** 8 Liters
- **Power:** 2400 Watts
- **Technology:** Rapid Air Heating for frying with up to 90% less fat.
- **Functions:** Fry, bake, grill, roast, and even reheat.
- **Control:** Temperature control feature.
- **Material:** Stainless Steel.



Figure 2.2.1: Royal Silver Crest 8L Air Fryer and its packaging.

This image shows the Royal Silver Crest 8L Air Fryer in black, positioned next to its product packaging. The air fryer features a sleek design with a digital control panel and a gold-colored handle on the frying basket.



Figure 2.2.2: Front view of the Air Fryer.

A direct front view of the Royal Silver Crest Air Fryer, highlighting its digital touch control panel with various cooking presets and an ON/OFF button. The prominent gold handle of the basket is visible at the bottom.



Figure 2.2.3: Air Fryer with basket and crisper plate.

This image displays the Royal Silver Crest Air Fryer with its frying basket pulled out and the crisper plate detached, showing the internal components. This illustrates how the basket and plate can be separated for cleaning or food placement.



Figure 2.2.4: Air Fryer Dimensions.

A diagram illustrating the dimensions of the Royal Silver Crest Air Fryer. The main unit measures approximately 35cm (depth) x 30cm (width) x 30cm (height). The internal basket dimensions are also shown, indicating its capacity.

### 3. SETUP

---

1. **Unpacking:** Carefully remove all packaging materials and stickers from the appliance.
2. **Cleaning:** Before first use, clean the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Wipe the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance to allow for proper air circulation.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

### 4. OPERATING INSTRUCTIONS

---

#### 4.1 Pre-heating

Pre-heating the air fryer ensures more even cooking results.

1. Plug in the air fryer.
2. Press the power button to turn on the display.
3. Set the desired temperature (e.g., 180°C) and time (e.g., 3-5 minutes) for pre-heating.
4. Press the start button to begin pre-heating.

## 4.2 Cooking Food

1. After pre-heating, carefully pull out the frying basket.
2. Place the food inside the basket, ensuring not to overfill. For best results, food should be in a single layer.
3. Slide the basket back into the air fryer until it clicks into place.
4. Select the appropriate cooking preset or manually set the temperature and time.
5. Press the start button to begin cooking.
6. Some recipes may require shaking or flipping food halfway through cooking. The air fryer may beep to remind you.
7. Once cooking is complete, carefully pull out the basket and remove the food.

## 4.3 Recommended Cooking Settings

The following table provides general guidelines. Cooking times and temperatures may vary based on food quantity and desired crispiness.

Food Item	Temperature (°C)	Time (Minutes)	Notes
Frozen Fries	200	15-20	Shake halfway
Chicken Wings	180	20-25	Flip halfway
Steak	190	10-15	Depends on thickness
Vegetables	160	10-12	Lightly oil

## 5. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool completely before cleaning.
2. **Basket and Crisper Plate:** These parts are dishwasher safe. Alternatively, wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak in warm soapy water for 10-15 minutes.
3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Never immerse the main unit in water or any other liquid.
4. **Heating Element:** Use a cleaning brush to remove any food residue from the heating element inside the appliance.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

## 6. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; appliance malfunction.	Check power cord connection; try a different outlet; contact customer support if problem persists.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Basket overloaded; food not shaken/flipped; incorrect temperature/time.	Cook in smaller batches; shake/flip food halfway; adjust temperature/time.
White smoke coming from appliance.	Greasy food; oil residue from previous use.	Drain excess oil from food; clean basket and crisper plate thoroughly after each use.
Appliance smells during first use.	Normal for new appliances.	This is normal and will dissipate after a few uses. Ensure good ventilation.

## 7. SPECIFICATIONS

Specification	Value
Brand	Royal Silver Crest
Model Number	18
Color	Black
Capacity	8 Liters
Power / Wattage	2400 Watts
Voltage	220 Volts
Material	Stainless Steel
Special Features	Temperature Control
Product Dimensions (D x W x H)	35 x 30 x 30 cm
Item Weight	2 Kilograms

## 8. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact the retailer or the manufacturer's customer service department. Keep your purchase receipt as proof of purchase.

- **Extended Warranty Options:** Extended warranty plans may be available from third-party providers. (e.g., [1-Year Extended Warranty](#), [2-Year Extended Warranty](#))