

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ERICAT](#) /

> [ERICAT Electronic Cash Register User Manual](#)

ERICAT Electronic Cash Register

ERICAT Electronic Cash Register User Manual

Model: Electronic Cash Register (ASIN: B0CB7F9NFT)

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your ERICAT Electronic Cash Register. Please read this manual thoroughly before using the device to ensure proper functionality and longevity.

SETUP INSTRUCTIONS

1. Unpacking and Placement

- Carefully remove all components from the packaging.
- Place the cash register on a stable, flat surface. Ensure adequate ventilation around the unit.



Image: Front view of the ERICAT Electronic Cash Register, showing the main display and integrated thermal printer.

2. Power Connection

1. Locate the DC-12V 4A power adapter.
2. Connect the power adapter to the designated power input port on the cash register.
3. Plug the power adapter into a standard electrical outlet.
4. Press the power button, usually located on the side or rear of the unit, to turn on the device.



Abundant external interface

Image: Illustration of the cash register's external interfaces, demonstrating connectivity for peripherals such as a barcode scanner or external payment terminal.

OPERATING INSTRUCTIONS

1. Dual Screen Functionality

The ERICAT Electronic Cash Register features a 10.1-inch main display for operator use and a 10.1-inch 8-digit tube customer display. The main display is a true flat touch screen with a fast 5-millisecond response time, designed for anti-scratch durability. The customer display can show transaction details or be utilized for advertising new products and discount information.



Image: Rear view of the ERICAT Electronic Cash Register, highlighting the customer-facing 10.1-inch 8-digit tube display.

2. Basic Operations

The main touch screen interface typically presents options such as "Help," "Program," "Report," and "Sale."

- **Help:** Access on-screen assistance and user guides.
- **Program:** Configure product information (PLU), department settings, and receipt formats. Refer to the on-screen instructions for detailed programming steps.
- **Report:** View and print daily sales reports and other financial summaries.
- **Sale:** Initiate sales transactions.



Image: The main touch screen display of the cash register, showing the "Help," "Program," "Report," and "Sale" menu options.

3. Thermal Printer Usage

The integrated 58mm thermal printer automatically prints receipts for transactions. Ensure thermal paper is loaded correctly before operation.



Image: A close-up view of the 58mm thermal printer slot, showing a printed receipt emerging from the unit.

MAINTENANCE

1. Cleaning

- **Screens:** Use a soft, lint-free cloth lightly dampened with a non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- **Shell:** Wipe the ABS shell with a dry or slightly damp cloth. Avoid harsh chemicals that may damage the powder coating.

2. Thermal Paper Replacement

1. Open the printer cover.

2. Remove the empty paper roll core.
3. Insert a new 58mm thermal paper roll, ensuring the paper feeds correctly from the bottom.
4. Close the printer cover securely.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Power cable disconnected; power outlet fault.	Ensure power cable is securely connected. Test power outlet with another device.
Printer not printing.	No thermal paper; paper loaded incorrectly; printer error.	Check and replace thermal paper. Re-load paper correctly. Restart the device.
Touch screen unresponsive.	Temporary software glitch; screen calibration issue.	Restart the cash register. If issue persists, consult the "Help" section for screen calibration options.

SPECIFICATIONS

Product Name	Electronic Cash Register
Main Display	10.1 inch (1024*600)
Customer Display	10.1 inch 8 digital tube display
Printer	58mm Thermal Printer
Cashbox	External standard POS box (not included, refers to compatibility)
Shell Material	ABS
Power Supply	DC-12V 4A
Dimensions (POS)	17*26*34 CM

SUPPORT AND WARRANTY

For technical support or warranty inquiries, please refer to the contact information provided with your purchase documentation. Keep your purchase receipt as proof of purchase for warranty claims.