

[manuals.plus](#) /› [GreenLife](#) /› [GreenLife Digital Rice & Beans Cooker \(Model CC007461-003\) User Manual](#)

GreenLife CC007461-003

GreenLife Digital Rice & Beans Cooker User Manual

Model: CC007461-003

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your GreenLife Digital Rice & Beans Cooker. Please read all instructions carefully before first use and retain for future reference.

The GreenLife Digital Rice & Beans Cooker is designed to simplify the preparation of various grains, including white rice, brown rice, beans, and steel cut oats. It features a healthy ceramic nonstick interior and intuitive one-touch presets for consistent results.

2. IMPORTANT SAFEGUARDS

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance body in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.

3. PRODUCT OVERVIEW & COMPONENTS

Familiarize yourself with the parts of your GreenLife Digital Rice & Beans Cooker.



Image: The GreenLife Digital Rice & Beans Cooker shown with its measuring cup and spatula.

Included Components:

- GreenLife Digital Rice & Beans Cooker Unit
- Removable Nonstick Ceramic Pot
- Measuring Cup
- Spatula

Control Panel Features:



Image: A detailed view of the cooker's control panel, highlighting the digital display and function buttons.

- **Digital Display:** Shows cooking time and settings.
- **Menu Button:** Cycles through preset cooking functions (White Rice, Brown Rice, Beans, Steel Cut Oats).
- **+/- Buttons:** Adjust cooking time for certain functions or delay timer settings.
- **Start Button:** Initiates the selected cooking program.
- **Keep Warm/Stop Button:** Activates the keep warm function or cancels the current program.
- **Delay Timer Button:** Sets a delayed start time for cooking.

4. SETUP

Before First Use:

1. Remove all packaging materials and promotional labels.
2. Wash the removable nonstick ceramic pot, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the cooker body with a damp cloth. Do not immerse the cooker body in water.
4. Ensure all parts are completely dry before assembly and use.

5. OPERATING INSTRUCTIONS

General Operation:

1. Place the cooker on a stable, heat-resistant surface.
2. Measure the desired amount of grains using the provided measuring cup. Note: The measuring cup is not a standard cup measurement. Refer to the cooking guide for specific ratios.

3. Rinse grains thoroughly under cold water until the water runs clear.
4. Add the rinsed grains to the removable nonstick ceramic pot.
5. Add the appropriate amount of water to the pot, following the water level markings inside the pot or the cooking guide.
6. Place the pot into the cooker body and close the lid securely.
7. Plug the power cord into a standard electrical outlet. The digital display will illuminate.

Using Preset Functions:

1. Press the **Menu** button repeatedly to cycle through the available preset functions: White Rice, Brown Rice, Beans, Steel Cut Oats. The indicator light next to the selected function will illuminate.
2. The digital display will show the default cooking time for the selected preset.
3. Press the **Start** button to begin cooking. The cooker will automatically adjust cooking based on Fuzzy Logic Technology.

Using the Delay Timer:

1. Select your desired cooking preset using the **Menu** button.
2. Press the **Delay Timer** button. The display will show a default delay time.
3. Use the **+/** buttons to adjust the delay time in hours. The delay timer can be set for up to 24 hours.
4. Press the **Start** button. The cooker will begin the countdown for the delay time, and then automatically start the cooking program once the delay time has elapsed.

Keep Warm Function:

- After a cooking cycle is complete, the cooker will automatically switch to the Keep Warm function. The Keep Warm indicator light will illuminate.
- To manually activate the Keep Warm function, press the **Keep Warm/Stop** button.
- To stop the Keep Warm function or any active program, press the **Keep Warm/Stop** button.

RICE & BEANS IN ONE TOUCH



NO-GUESS PRESETS

Choose White Rice, Brown Rice, Beans, or Steel Cut Oats

Image: Fluffy white rice cooked perfectly inside the ceramic nonstick pot.



Image: A hand uses the provided spatula to serve cooked rice from the pot into a bowl.

6. COOKING GUIDE

The following are general guidelines. Always refer to the specific instructions for your type of grain and adjust water levels to achieve desired consistency.

Rice & Water Ratios (using provided measuring cup):

Grain Type	Grains (cups)	Water (cups)
White Rice	1	1
White Rice	2	2
Brown Rice	1	1.5
Brown Rice	1.5 (max)	2.25
Beans	Refer to recipe	Refer to recipe
Steel Cut Oats	Refer to recipe	Refer to recipe

Note: The maximum capacity for uncooked white rice is 2 measuring cups, yielding approximately 4 cups of cooked rice. For brown rice, the maximum is 1.5 measuring cups.

Video: An overview of the GreenLife 4-Cup PFAS-Free Nonstick Rice Cooker, demonstrating its features and ease of use.

7. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and performance of your cooker.

Cleaning the Removable Pot and Accessories:

- The nonstick ceramic pot, measuring cup, and spatula are dishwasher safe.
- Alternatively, wash them with warm, soapy water using a soft sponge or cloth. Avoid abrasive cleaners or metal scouring pads to protect the nonstick coating.

DISHWASHER SAFE PARTS



HASSLE-FREE CLEANING

Wipe parts clean or place the pot in the dishwasher

Image: A hand gently cleans the removable nonstick ceramic pot with a sponge under running water.



Image: The removable nonstick ceramic pot being rinsed under a kitchen faucet, demonstrating its easy-to-clean surface.

Cleaning the Cooker Body and Lid:

- Unplug the cooker and allow it to cool completely before cleaning.
- Wipe the exterior of the cooker body with a damp cloth. Do not immerse the cooker body in water.
- The inner lid is removable for thorough cleaning. Gently detach it and wash with warm, soapy water. Ensure it is completely dry before reattaching.
- Ensure all parts are dry before storing.

8. TROUBLESHOOTING

- **Rice is too hard/dry:** Add slightly more water in the next cooking cycle. Ensure the lid is properly sealed during cooking.
- **Rice is too soft/mushy:** Reduce water slightly in the next cooking cycle. Ensure grains are rinsed properly.
- **Cooker does not turn on:** Check if the power cord is securely plugged into both the cooker and the wall outlet. Ensure the outlet is functional.
- **Water/steam leaks from lid:** Ensure the lid is properly closed and sealed. Check if the inner lid is correctly attached. Avoid overfilling the pot beyond the maximum capacity.
- **Food sticks to the pot:** Ensure the nonstick coating is not damaged. Use only the provided plastic spatula or other non-abrasive utensils.

9. SPECIFICATIONS

- **Brand:** GreenLife
- **Model Name:** CC007461-003
- **Capacity:** 2 cups uncooked rice / 4 cups cooked rice
- **Product Dimensions:** 7.44"D x 8.23"W x 7.36"H
- **Power Source:** Corded Electric
- **Voltage:** 120 Volts
- **Material:** Ceramic (pot), Plastic (lid, body)
- **Special Feature:** Non-Stick, Fuzzy Logic Technology, Delay Timer, Auto Keep Warm
- **Product Care Instructions:** Dishwasher Safe (removable parts)
- **Item Weight:** 4.29 pounds



Image: The GreenLife Digital Rice & Beans Cooker with its height, depth, and width dimensions indicated.

10. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the warranty card included with your purchase or visit the official GreenLife website. Do not attempt to repair the appliance yourself.

Related Documents - CC007461-003



[GreenLife Healthy Power 5-in-1 Electric Skillet Instruction Manual](#)

Comprehensive guide for the GreenLife Healthy Power 5-in-1 Electric Skillet, covering safety precautions, parts, features, operation, cooking tips, and warranty information. Learn how to use and maintain your electric skillet for healthy and delicious meals.

 <p>1.5QT RICE COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 1.5-Quart Rice Cooker: Instruction Manual & User Guide</u> Comprehensive instruction booklet for the GreenLife 1.5-Quart Rice Cooker. Learn about important safeguards, parts, operation, cleaning, warranty, and terms of sale for your GreenLife appliance.</p>
 <p>GO GRAINS! RICE & GRAINS COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife Go Grains Rice & Grains Cooker Instruction Manual</u> Official instruction booklet for the GreenLife Go Grains Rice & Grains Cooker. Learn about important safeguards, parts, control panel operation, cleaning, troubleshooting, and warranty information.</p>
 <p>3-IN-1 BREAKFAST MAKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 3-in-1 Breakfast Maker Instruction Booklet - User Guide</u> Official instruction booklet for the GreenLife 3-in-1 Breakfast Maker. Includes important safety precautions, parts identification, operating instructions, cleaning guide, warranty information, and terms of sale.</p>
 <p>SLOW COOKER INSTRUCTION BOOKLET CUSTOMER SERVICE 1-877-949-4263</p>	<p><u>GreenLife 3.5QT Slow Cooker Instruction Booklet User Manual</u> Official instruction booklet for the GreenLife 3.5QT Slow Cooker. Includes safety precautions, operating instructions, cleaning, troubleshooting, and warranty information.</p>
 <p>SANDWICH PRO INSTRUCTION BOOKLET</p>	<p><u>GreenLife Sandwich Pro Instruction Booklet: User Guide and Tips</u> Comprehensive instruction booklet for the GreenLife Sandwich Pro, covering important safeguards, usage instructions, tips, cleaning, maintenance, storage, warranty, and terms of sale. Learn how to make sandwiches, omelets, quesadillas, and more.</p>