

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hermitlux](#) /

› [Hermitlux HAF55B31 5.5L XXL Air Fryer User Manual](#)

## Hermitlux HAF55B31

# Hermitlux 5.5L XXL Air Fryer User Manual

Model: HAF55B31

## INTRODUCTION

---

Thank you for choosing the Hermitlux 5.5L XXL Air Fryer. This appliance is designed to prepare delicious and healthy meals with minimal oil, utilizing 360° hot air circulation for crispy, evenly cooked results. Please read this manual thoroughly before use to ensure safe and optimal operation.



*Image: The Hermitlux 5.5L XXL Air Fryer, showcasing its sleek black design and compact form factor.*

## SAFETY INSTRUCTIONS

- Always place the air fryer on a stable, heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Ensure the voltage indicated on the appliance matches your local mains voltage.
- Do not operate the appliance if the plug, power cord, or the appliance itself is damaged.
- Unplug the air fryer from the outlet when not in use and before cleaning.
- Do not block the air inlet and outlet openings.
- The appliance features an automatic safety shut-off function: the program will pause when the outer basket is removed and resume when reinserted.

## SETUP AND FIRST USE

---

1. **Unpacking:** Carefully remove the air fryer and all accessories from the packaging.
2. **Cleaning:** Before first use, clean the basket and grill thoroughly with warm soapy water. Wipe the exterior of the appliance with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a flat, stable, and heat-resistant surface, ensuring adequate ventilation around the unit (at least 10 cm clearance on all sides).
4. **Pre-heating (Initial Run):** To eliminate any manufacturing odors, operate the air fryer empty at maximum power (200°C) for approximately 20 minutes. Allow it to cool down completely afterward.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

## OPERATING INSTRUCTIONS

---

### Control Panel Overview

The Hermitlux Air Fryer features an intuitive LED touch screen with 10 preset cooking programs for various foods.

# 360°-Heißluftzirkulationssystem

Schnelleres und gleichmäßigeres Erhitzen



*Image: Close-up of the air fryer's LED touch screen, displaying temperature, time, and icons for 10 preset cooking programs including fries, steak, chicken, fish, shrimp, bacon, vegetables, small vegetables, pizza, and toast.*

## Cooking Process

1. **Prepare Food:** Place your ingredients into the air fryer basket. Do not overfill. For best results, use parchment paper liners if desired, ensuring they do not exceed the basket's edges or touch the heating element.
2. **Insert Basket:** Slide the basket firmly into the air fryer.
3. **Power On:** Press the power icon on the LED touch screen to turn on the appliance.
4. **Select Program:** Choose one of the 10 preset programs by tapping the corresponding icon (e.g., chicken leg for poultry, fries for potatoes). The display will show default temperature and time settings.
5. **Adjust Settings (Optional):** If needed, adjust the temperature (40°C to 200°C) and time using the arrow icons on the display. This can be done before or during cooking.
6. **Start Cooking:** Press the start/pause icon to begin the cooking process.
7. **Mid-Cycle Shake/Turn:** For many foods, the air fryer will emit an audible signal halfway through the cooking cycle. This indicates it's time to shake or turn the food for even cooking. Carefully remove the basket (the appliance will

pause automatically), shake or turn the food, and reinsert the basket to resume.

8. **Completion:** Once the cooking cycle is complete, the air fryer will beep. Carefully remove the basket and transfer the cooked food.

The 360° hot air circulation system ensures faster and more uniform heating, resulting in perfectly cooked food with less fat.

## Familiengroßes Fassungsvermögen von 5.5 L

Bereiten Sie alles vom Frühstück bis zum Abendessen in einem Frittierkorb zu.



Image: Cross-section view of the air fryer demonstrating the 360-degree hot air circulation system for efficient and even cooking.

### Special Functions

- **Preheat:** The air fryer can be preheated to the desired temperature before adding food.
- **Keep Warm:** A keep warm function is available to maintain food temperature after cooking.
- **Defrost:** An option to defrost food, such as bread, is included.

The Hermitlux Air Fryer operates quietly, with noise levels below 50 dB, allowing for undisturbed cooking.

# Sicherheits-Stromabschaltfunktion

Der Strom schaltet sich automatisch ab, wenn der Außentopf abgenommen wird.



*Image: The Hermitlux air fryer in a home setting, emphasizing its quiet operation with a sleeping child in the background.*

## MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your Hermitlux Air Fryer.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Basket and Grill:** The air fryer basket and grill are dishwasher safe. Alternatively, they can be washed by hand with warm soapy water and a non-abrasive sponge.
3. **Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasives or scouring pads.
4. **Interior:** For thorough cleaning, wipe the interior with a damp cloth. Ensure no water enters the electrical components.
5. **Storage:** Store the cleaned and dried air fryer in a cool, dry place.

# Genießen Sie das Kochen, ohne Ihre Familie zu Stören

Lauf leise, weniger als 50 dB



Image: Visual guide demonstrating the easy cleaning process for the air fryer basket and grill, highlighting dishwasher compatibility and simple wiping.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance damage.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If damaged, contact customer support.
Food is not cooked evenly.	Basket overloaded; food not shaken/turned; incorrect temperature/time.	Do not overload the basket. Shake or turn food halfway through cooking. Adjust temperature and time as needed.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease residue from previous use; fatty ingredients.	Clean the basket and interior thoroughly. For fatty foods, ensure excess oil is drained. This is usually harmless.
Food is not crispy.	Too much moisture; not enough oil (for certain foods); basket overloaded.	Pat food dry before cooking. A small amount of oil can help crispiness. Do not overload.

## SPECIFICATIONS

<b>Model Number</b>	HAF55B31
<b>Brand</b>	Hermitlux
<b>Capacity</b>	5.5 Litres
<b>Power</b>	1500 Watts
<b>Voltage</b>	220 Volts (AC)
<b>Dimensions (L x W x H)</b>	33.5 x 23.5 x 31 cm
<b>Weight</b>	3.74 Kilograms
<b>Material</b>	Plastic
<b>Noise Level</b>	50 Decibels
<b>Special Features</b>	Automatic shut-off, Temperature control, Timer, Programmable, Stain resistant

## Andere:

Die Korbstruktur ist kompliziert und nicht leicht zu reinigen.  
Das Schnallendesign birgt die Gefahr eines Sturzes.

## Einfache Reinigung



Image: The Hermitlux air fryer with its dimensions (33.5cm x 23.5cm x 31cm) and 5.5L capacity highlighted, shown with food inside.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Hermitlux website.

**Manufacturer:** Hermitlux

**ASIN:** B0CDC7JMQD

