

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SHIMANO](#) /

› [SHIMANO CUES RD-U3020 Direct Mount Rear Derailleur 9-Speed User Manual](#)

### SHIMANO RD-U3020

# SHIMANO CUES RD-U3020 Direct Mount Rear Derailleur 9-Speed User Manual

Model: RD-U3020

## 1. INTRODUCTION

This manual provides essential information for the proper installation, operation, and maintenance of your SHIMANO CUES RD-U3020 Direct Mount Rear Derailleur. The RD-U3020 is designed for 9-speed bicycle drivetrains, offering reliable and precise shifting performance. Please read this manual thoroughly before use to ensure safe and optimal performance of your bicycle component.



Figure 1: SHIMANO CUES RD-U3020 Direct Mount Rear Derailleur. This image shows the complete rear derailleur unit, highlighting its black finish and the SHIMANO CUES branding.

## 2. SAFETY INFORMATION

---

- Always wear appropriate safety gear, including gloves and eye protection, when installing or maintaining bicycle components.
- Ensure all bolts are tightened to the manufacturer's specified torque values. Overtightening or undertightening can lead to component failure or injury.
- If you are unsure about any installation or adjustment procedure, consult a professional bicycle mechanic.
- Regularly inspect your derailleur and drivetrain for wear, damage, or loose components. Replace worn parts immediately.
- Keep hands and clothing clear of moving parts, especially the chain and cogs, during operation and adjustment.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in the package before beginning installation.

- SHIMANO CUES RD-U3020 Direct Mount Rear Derailleur (1 unit)

- Instruction Manual (this document)
- *Note: Additional bike parts such as cables, housing, and mounting bolts may be sold separately.*

## 4. SETUP AND INSTALLATION

---

The SHIMANO CUES RD-U3020 is a direct mount rear derailleur designed for frames with a compatible direct mount hanger. Proper installation is crucial for optimal shifting performance and safety.

1. **Preparation:** Ensure your bicycle frame has a direct mount derailleur hanger. Clean the hanger area thoroughly.
2. **Mounting the Derailleur:** Align the derailleur with the direct mount hanger. Insert and tighten the mounting bolt to the specified torque (refer to SHIMANO's official technical documentation for precise torque values).
3. **Chain Installation:** Install the bicycle chain, ensuring it is routed correctly through the derailleur's guide and tension pulleys.
4. **Cable Routing:** Route the shift cable from the shifter to the derailleur, ensuring smooth movement without kinks or excessive friction. Secure the cable to the derailleur's cable fixing bolt.
5. **Limit Screw Adjustment:** Adjust the high (H) and low (L) limit screws to prevent the chain from shifting beyond the smallest and largest cogs, respectively. This prevents the chain from falling off the cassette or into the spokes.
6. **B-Tension Adjustment:** Adjust the B-tension screw to set the proper distance between the upper guide pulley and the cassette cogs. This ensures smooth shifting across the entire cassette.
7. **Indexing Adjustment:** Fine-tune the cable tension using the barrel adjuster on the shifter or derailleur to achieve precise and consistent shifting across all 9 gears.
8. **Final Check:** After all adjustments, cycle through all gears multiple times to confirm smooth operation and proper chain retention. Check all bolts for tightness.

*For detailed, step-by-step visual instructions and torque specifications, please refer to the official SHIMANO dealer's manual or technical service instructions available on the SHIMANO website.*

## 5. OPERATING INSTRUCTIONS

---

The SHIMANO CUES RD-U3020 rear derailleur operates in conjunction with a compatible 9-speed shifter and cassette.

- **Shifting Up (to smaller cogs):** Press the smaller lever or button on your shifter to move the chain to a smaller (higher gear) cog.
- **Shifting Down (to larger cogs):** Press the larger lever or button on your shifter to move the chain to a larger (lower gear) cog.
- **Smooth Shifting:** Always pedal forward with consistent, moderate pressure when shifting. Avoid shifting under heavy load or while standing still, as this can damage the drivetrain.
- **Anticipate Shifts:** Plan your shifts in advance, especially when approaching hills or changes in terrain, to maintain momentum and reduce stress on components.

## 6. MAINTENANCE

---

Regular maintenance will extend the life of your derailleur and ensure consistent performance.

- **Cleaning:** Keep the derailleur, especially the pulleys and cage, clean from dirt and grime. Use a degreaser and brush, then rinse and dry thoroughly.
- **Lubrication:** Periodically lubricate the pivot points of the derailleur and the chain with appropriate bicycle lubricant. Avoid over-lubricating, which can attract dirt.
- **Cable and Housing:** Inspect shift cables and housing for fraying, corrosion, or damage. Replace them if necessary to maintain smooth shifting.

- **Pulleys:** Check the guide and tension pulleys for wear. Worn pulleys can lead to poor shifting and increased noise. Replace them if the teeth are significantly worn or damaged.
- **Bolt Tightness:** Periodically check all mounting and adjustment bolts for proper tightness.

## 7. TROUBLESHOOTING

---

If you experience issues with your derailleur, consult the following common troubleshooting tips:

- **Poor Shifting / Ghost Shifting:**

- Check cable tension: Adjust the barrel adjuster. Turn clockwise to loosen tension (shift down), counter-clockwise to tighten (shift up).
- Inspect cable and housing: Look for kinks, fraying, or dirt. Replace if damaged.
- Verify limit screw settings: Ensure the H and L screws are correctly set.
- Check derailleur hanger alignment: A bent hanger is a common cause of poor shifting. This often requires a special tool and professional attention.

- **Chain Rubbing / Noise:**

- Check B-tension adjustment: Ensure proper clearance between the upper pulley and cassette cogs.
- Clean and lubricate drivetrain: Dirt and lack of lubrication can cause noise.
- Inspect chain for wear: A worn chain can cause poor shifting and noise.

- **Derailleur Not Moving:**

- Check for obstructions: Ensure no debris is jamming the derailleur.
- Verify cable connection: Make sure the cable is securely attached and not broken.

If problems persist after attempting these steps, it is recommended to consult a qualified bicycle mechanic.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	SHIMANO
Model Name	RD-U3020 (Part Number: ERDU3020SGS)
Speed Compatibility	9-speed
Mounting Type	Direct Mount
Material	Compound
Item Weight	0.1 Kilograms
Item Dimensions (LxWxH)	3.94 x 3.94 x 3.94 inches
GTIN	04550170171933

## 9. WARRANTY AND SUPPORT

---

This SHIMANO product comes with a **2 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims.

For technical support, detailed installation guides, or warranty service, please visit the official SHIMANO website or contact

your authorized SHIMANO dealer.

- **SHIMANO Official Website:** [bike.shimano.com](https://bike.shimano.com)
- **Dealer Locator:** Use the dealer locator tool on the SHIMANO website to find an authorized service center near you.

© 2024 SHIMANO. All rights reserved. Information subject to change without notice.