

Fritaire Fritaire-01-WH-FBA

Fritaire Non-Toxic Air Fryer Pro Instruction Manual

Model: Fritaire-01-WH-FBA

INTRODUCTION

Thank you for choosing the Fritaire Non-Toxic Air Fryer Pro. This innovative 9-in-1 appliance is designed to provide a healthier and more convenient cooking experience. Featuring a durable glass bowl, self-cleaning functionality, and versatile accessories like a rotisserie and tumbling basket, it allows you to air fry, bake, roast, broil, reheat, and dehydrate with ease. The 400°F Vortex air circulation ensures even cooking and crispy results.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always place the air fryer on a stable, heat-resistant surface.
- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts when handling hot components.
- To protect against electrical shock, do not immerse the cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer, as this may cause injuries.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended use.
- The glass bowl is made from durable, non-toxic materials, free from BPA, Teflon, and PFAS.

PRODUCT COMPONENTS

Your Fritaire Air Fryer Pro comes with several components to enhance your cooking experience:

- Main Unit (Lid with control panel and heating element)
- Glass Bowl (5-quart capacity)
- Base Unit

- Air Stand (Cooking Rack)
- Tumbling Basket
- Rotisserie Skewer with Forks
- Rotisserie Motor (Battery-operated)
- Grabber Tool (for safe removal of hot accessories)

9-IN-1 AIR FRYER MAGIC

Make meals from crispy fries to baked goods, all in one glass air fryer.



**ROTISSERIE • TUMBLING BASKET • SELF-CLEANING
MEAT • FISH • CHICKEN • FRIES • CAKE • DEHYDRATE**

Image: Fritaire Air Fryer Pro with its main unit, glass bowl, and various accessories including the air stand, tumbling basket, rotisserie skewer, and grabber tool.

SETUP

Before first use, ensure all packaging materials are removed. Wash the glass bowl and all accessories (air stand, tumbling basket, rotisserie skewer, grabber tool) with warm, soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.

1. Place the base unit on a stable, flat, heat-resistant surface.

2. Carefully place the clean glass bowl onto the base unit.
3. Insert the desired accessory (air stand, tumbling basket, or rotisserie skewer) into the glass bowl as per the cooking method.
4. Place the main unit (lid) securely onto the glass bowl. Ensure it clicks into place for proper operation.
5. If using the tumbling basket or rotisserie skewer, attach the rotisserie motor to the designated slot on the side of the main unit. Ensure batteries are installed in the motor.
6. Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The Fritaire Air Fryer Pro features an intuitive touch control panel for easy operation.

Control Panel Overview

The top panel features a digital display for temperature and time, along with various pre-set cooking functions and manual controls for adjustment.

- **Power Button:** Turns the appliance on/off.
- **Temperature Controls (+/-):** Adjust cooking temperature (up to 400°F).
- **Time Controls (+/-):** Adjust cooking time.
- **Pre-set Functions:** Icons for Airfry, Bake, Roast, Broil, Reheat, Dehydrate. Select an icon for optimized settings.
- **Start/Pause Button:** Begins or pauses the cooking cycle.

Cooking with the Air Stand (Rack)

Ideal for items that require stable placement, such as bagels or larger pieces of food.

1. Place the air stand inside the glass bowl.
2. Arrange your food evenly on the air stand.
3. Close the lid and select your desired pre-set function or manually set the temperature and time.
4. Press the Start button. The transparent glass bowl allows you to monitor cooking progress without opening the lid.

ROTISSERIE & TUMBLING BASKET

From golden rotisserie chicken to evenly crisped fries, the rotating accessories do the work you enjoy the flavor.



Image: Mozzarella sticks cooking on the air stand, visible through the clear glass bowl of the Fritaire Air Fryer.

Using the Tumbling Basket

Perfect for achieving even crispiness on items like fries, vegetables, or popcorn chicken.

1. Open the tumbling basket and load your food. Securely close the basket.
2. Insert the tumbling basket into the designated slots within the glass bowl.
3. Attach the rotisserie motor to the side of the main unit.
4. Close the lid, select a pre-set function (e.g., for fries), or manually set temperature and time.
5. Press Start. Turn on the rotisserie motor to begin tumbling.

SELF-CLEANING AIR FRYER

Just add soap & water, it cleans itself.



Image: French fries being cooked in the rotating tumbling basket, ensuring even crisping.

Using the Rotisserie Skewer

Ideal for roasting whole chickens or other large cuts of meat, ensuring even cooking and browning.

1. Secure your food (e.g., a whole chicken) onto the rotisserie skewer using the forks.
2. Insert the rotisserie skewer into the designated slots within the glass bowl.
3. Attach the rotisserie motor to the side of the main unit.
4. Close the lid, select a pre-set function (e.g., for chicken), or manually set temperature and time.
5. Press Start. Turn on the rotisserie motor to begin rotation.

THE #1 NON-TOXIC AIR FRYER™

Cook with peace of mind in a glass bowl
that's free from harmful coatings.



Image: A whole chicken being roasted on the rotisserie skewer, visible through the transparent glass bowl.

Official Product Video: Rotisserie, Tumbling, and Self-Cleaning

Video: This official Fritaire video demonstrates the air fryer's rotisserie function with a whole chicken, the tumbling basket for fries, and the self-cleaning mode in action.

MAINTENANCE & CLEANING

Proper maintenance ensures the longevity and optimal performance of your Fritaire Air Fryer Pro.

Self-Cleaning Mode

The Fritaire Air Fryer Pro features a convenient self-cleaning mode for effortless cleanup of the glass bowl.

1. After cooking, ensure the appliance is unplugged and has cooled slightly.
2. Remove any large food debris from the glass bowl.

3. Add 1-2 inches of water and a few drops of dish soap to the glass bowl.
4. Place the lid back on the appliance.
5. Select the self-cleaning function (refer to the control panel icons) or set the temperature to 400°F for 10 minutes.
6. Press Start. The hot air circulation will create a soapy vortex to clean the interior of the bowl.
7. Once the cycle is complete, unplug the appliance, carefully remove the lid, and pour out the soapy water.
8. Rinse the glass bowl thoroughly with clean water and dry with a soft cloth.

THE MOST BEAUTIFUL AIR FRYER YOU HAVE EVER SEEN



ACCORDING TO

**BEST
BUY**

Men'sHealth

COSTCO
WHOLESALE

**GOOD
MORNING
AMERICA**

Q **QVC**

CNET

Image: The Fritaire Air Fryer actively cleaning itself with soapy water circulating in the glass bowl.

Manual Cleaning

All accessories (air stand, tumbling basket, rotisserie skewer, grabber tool) are dishwasher safe. The glass bowl can also be washed by hand with warm, soapy water. The main unit (lid) contains electrical components and should never be submerged in water. Wipe it clean with a damp cloth and mild detergent, then dry thoroughly.

SPECIFICATIONS

Feature	Detail
Model Name	Fritaire-01-WH-FBA
Capacity	5 Quarts
Product Dimensions	10.8"D x 13.9"W x 12.6"H
Item Weight	11 Pounds
Material	Glass, Plastic, Stainless Steel
Outer Material	Glass
Inner Material	Stainless Steel
Has Nonstick Coating	No
Output Wattage	1300 Watts
Voltage	60 Volts
Control Method	Touch
Max Temperature Setting	400 Degrees Fahrenheit
Air Frying Technology	Vortex Convection
Special Features	Self-Cleaning Mode, BPA Free Glass Bowl, Rotisserie Capability, 6-IN-1 Single Touch
Included Components	Air Fryer (Main Unit, Glass Bowl, Base, Air Stand, Tumbling Basket, Rotisserie Skewer, Grabber Tool)

TROUBLESHOOTING

If you encounter any issues with your Fritaire Air Fryer Pro, please refer to the following common troubleshooting tips:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working outlet and the lid is correctly seated on the glass bowl.
- **Food not cooking evenly:** Ensure food is not overcrowded in the basket or on the rack. For tumbling accessories, confirm the rotisserie motor is properly attached and activated.
- **Smoke coming from the appliance:** This may be due to excess oil or food residue. Unplug immediately, allow to cool, and clean thoroughly. Ensure food is not excessively greasy.
- **Rotisserie motor not rotating:** Check if the motor is correctly attached and if the batteries are properly installed and charged.

For further assistance, please contact Fritaire customer support.

WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please visit the official Fritaire website or contact their customer service department. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question