

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BERGNER](#) /

› [BERGNER Master Pro Air Fryer User Manual](#)

## BERGNER BGMP-9231

# BERGNER Master Pro Air Fryer User Manual

Model: BGMP-9231 | Brand: BERGNER

## 1. INTRODUCTION AND OVERVIEW

---

The BERGNER Master Pro Air Fryer is designed to provide a healthier alternative to traditional frying, utilizing 360-degree airflow technology to cook food with little to no oil. This appliance features a powerful 1300W motor and a generous 4.8-liter capacity, making it suitable for various cooking needs. Its intuitive touch controls and multi-preset cooking menu simplify meal preparation, while the non-stick basket ensures easy food release and cleaning.

Key features include:

- Powerful 1300W performance for efficient cooking.
- 4.8-liter basket capacity, ideal for larger meals.
- Advanced 360-degree airflow technology for even cooking and crispy results.
- Multiple preset cooking menus for convenient, one-touch operation.
- Non-stick coated cooking basket for easy cleaning.
- Sleek black design with user-friendly touch controls.



Image 1.1: Front view of the BERGNER Master Pro Air Fryer, showcasing its design and capacity, with air-fried food items.

## 2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

### 3. PRODUCT COMPONENTS

---

The BERGNER Master Pro Air Fryer comes with the following components:

- Air Fryer Main Unit
- Removable Non-stick Coated Basket
- Accessories (as included in packaging)

Familiarize yourself with the main parts of your air fryer:

**Control Panel:** Located on the top, featuring touch controls for temperature, time, and preset functions.

**Air Inlet:** Located on the top of the unit.

**Air Outlet:** Located at the back of the unit.

**Power Cord:** For connecting to an electrical outlet.



Image 3.1: The main unit of the BERGNER Master Pro Air Fryer.



## Smart Touch Controls

Image 3.2: Side view of the air fryer, highlighting the basket handle.

### 4. SETUP

---

1. **Unpacking:** Carefully remove all packaging materials from the air fryer. Ensure all components are present and undamaged.
2. **Initial Cleaning:** Before first use, wipe the exterior of the air fryer with a damp cloth. Wash the removable basket and any accessories with warm, soapy water. Rinse thoroughly and dry completely.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 10 cm or 4 inches) around the back and sides of the appliance for proper air circulation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your appliance.

### 5. OPERATING INSTRUCTIONS

---

The BERGNER Master Pro Air Fryer features a user-friendly touch control panel for easy operation.

Image 5.1: The touch control panel, showing temperature and timer settings.

1. **Prepare Food:** Place the food you wish to air fry into the non-stick basket. Do not overfill the basket to allow for proper air circulation.
2. **Insert Basket:** Slide the basket firmly back into the air fryer until it clicks into place.
3. **Power On:** Press the power button on the touch control panel to turn on the appliance.
4. **Set Temperature and Time:**
  - Use the temperature control buttons (usually '+' and '-') to set the desired cooking temperature. The minimum temperature setting is 100 degrees Celsius.
  - Use the timer control buttons (usually '+' and '-') to set the desired cooking time.
5. **Use Preset Menu (Optional):** The air fryer comes with a multi-preset cooking menu. Press the 'M' button to cycle through the available presets. Each preset has a pre-programmed temperature and time for specific food types.
6. **Start Cooking:** Once temperature and time are set (or a preset is selected), press the start button (often the power button again or a dedicated start icon) to begin the cooking process.
7. **Shaking/Flipping Food:** For even cooking, especially for smaller items, it is recommended to shake or flip the food halfway through the cooking time. Carefully pull out the basket, shake or flip the contents, and then reinsert the basket. The air fryer will resume cooking automatically.
8. **Completion:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket and transfer the cooked food to a serving plate.



Image 5.2: Illustration of the 360-degree hot air technology for even cooking.

## 6. COOKING GUIDE (PRESET FUNCTIONS)

---

The BERGNER Master Pro Air Fryer offers 8 convenient preset functions to simplify your cooking. These presets are optimized for common food types, providing ideal temperature and time settings.



Image 6.1: Visual representation of the 8 multiple cooking preset functions.

The 8 preset functions include:

- Fries
- Ribs
- Shrimp
- Cake
- Chicken Legs
- Steak
- Fish
- Reheat

To use a preset, simply press the 'M' button on the control panel until the desired food icon is illuminated. The air fryer will automatically set the optimal temperature and time. You can adjust these settings manually after selecting a preset if needed.

## 7. MAINTENANCE AND CLEANING

---

Regular cleaning of your air fryer will ensure its longevity and optimal performance.

1. **Before Cleaning:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Cleaning the Basket and Accessories:** The non-stick coated basket and any accessories should be washed with warm, soapy water after each use. Use a non-abrasive sponge or cloth to avoid damaging the non-stick coating. Rinse thoroughly and dry completely before storing or next use. These parts are generally dishwasher safe, but hand washing is recommended to prolong their lifespan.

3. **Cleaning the Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn food residue, use a mild detergent and a soft brush. Ensure the interior is completely dry before plugging in the appliance.
4. **Cleaning the Exterior:** Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
5. **Never Immerse:** Never immerse the main unit of the air fryer in water or any other liquid.

## 8. TROUBLESHOOTING

If you encounter any issues with your BERGNER Master Pro Air Fryer, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working electrical outlet. Check your home's circuit breaker.
Food is not cooked evenly.	Basket is overfilled. Food pieces are too large.	Do not overfill the basket; cook in smaller batches if necessary. Cut food into smaller, more uniform pieces. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use. Cooking fatty foods.	Clean the basket and interior thoroughly after each use. For fatty foods, add a small amount of water to the bottom of the outer pan to prevent smoke.
Food is not crispy.	Not enough oil (if required). Basket overfilled. Temperature too low.	Lightly brush or spray food with oil for crispier results. Do not overfill the basket. Increase cooking temperature slightly.

## 9. SPECIFICATIONS

Feature	Detail
Model Name	MasterPro
Item Model Number	BGMP-9231
Brand	BERGNER
Capacity	4.8 litres
Output Wattage	1300 Watts
Control Method	Touch
Min Temperature Setting	100 Degrees Celsius
Material	Metal, Non-stick coated metal (Inner)
Has Nonstick Coating	Yes
Product Dimensions (D x W x H)	25D x 31W x 31H Centimeters
Item Weight	3.8 kg (3800 Grams)

Feature	Detail
Colour	Black
Country of Origin	China

## 10. WARRANTY AND SUPPORT

---

The BERGNER Master Pro Air Fryer comes with a **1-year manufacturer's warranty** from the date of purchase, covering defects in materials and workmanship under normal use.

For warranty claims, technical support, or any inquiries regarding your product, please contact BERGNER customer service. Keep your purchase receipt as proof of purchase for warranty validation.

Manufacturer: Bergner Impex India Pvt Ltd

Contact information (generic placeholder as specific details are not provided):

- Website: [www.bergner.in](http://www.bergner.in) (example)
- Email: [support@bergner.in](mailto:support@bergner.in) (example)
- Phone: Refer to product packaging or official website for local support numbers.