

BERGNER BGMP-9236-BK

Bergner Masterpro Air Fryer User Manual

Model: BGMP-9236-BK

INTRODUCTION

This user manual provides essential information for the safe and efficient operation of your Bergner Masterpro Air Fryer. Please read all instructions carefully before first use and retain this manual for future reference.

The Bergner Masterpro Air Fryer is designed to prepare a variety of delicious meals with significantly less oil, utilizing 360-degree airflow technology for even cooking. It features a 4-liter capacity and 1500 watts of power, making it suitable for baking, grilling, roasting, heating, and defrosting.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To prevent electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before use.
- Do not immerse the cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Do not block any ventilation openings.

- The appliance operates at high temperatures. Do not touch hot surfaces. Use handles or knobs.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Bergner Masterpro Air Fryer.



Figure 1: Front view of the Bergner Masterpro Air Fryer, showcasing its sleek black design and digital touch control panel.



Figure 2: Overview highlighting key features such as 1500W max power, 8 preset functions, 4L capacity, 200°C max temperature, and 1-year warranty.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** LED display with touch controls for temperature, timer, and preset menus.
- **Frying Basket:** 4-liter capacity with non-stick coating for easy food placement and removal.
- **Basket Handle:** For safe handling of the hot frying basket.
- **Air Inlet/Outlet:** For proper air circulation during operation.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and promotional labels from the air fryer.
2. **Cleaning:** Before first use, clean the frying basket and any removable accessories with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the main unit with a damp cloth. Ensure all parts are

completely dry before use.

3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of free space on the back, sides, and above the appliance.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

OPERATING INSTRUCTIONS

The Bergner Masterpro Air Fryer features intuitive touch controls for easy operation.



Figure 3: Detailed view of the smart touch control panel, showing various preset icons and digital display.

Basic Operation:

1. **Prepare Food:** Place your ingredients into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying basket back into the main unit until it clicks into place.
3. **Power On:** Press the power button on the touch control panel.

4. Set Temperature and Time:

- Use the temperature control buttons (+ / -) to adjust the desired cooking temperature (up to 200°C).
- Use the timer control buttons (+ / -) to set the cooking time (up to 60 minutes).

5. **Start Cooking:** Press the start/pause button to begin the air frying process. The air fryer will automatically shut off when the timer reaches zero.

6. **Check Food:** For best results, shake or toss the food halfway through the cooking time. Carefully pull out the basket, shake, and reinsert. The air fryer will resume cooking automatically.

7. **Remove Food:** Once cooking is complete, carefully pull out the basket using the handle. Place the basket on a heat-resistant surface. Use tongs to remove the cooked food.

Using Preset Cooking Menus:

The air fryer comes with 8 pre-programmed settings for common dishes:

- French Fries
- Chicken
- Fish
- Vegetables
- Bake
- Roast
- Reheat
- Keep Warm

To use a preset, simply select the corresponding icon on the touch control panel after powering on. The air fryer will automatically set the optimal temperature and time for that dish. You can adjust these settings manually if desired.



Figure 4: Illustration of the 8-in-1 versatility, including Air fry, Bake, Roast, Broil, Reheat, Keep Warm, French Fries, and Wings functions.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your air fryer.

- 1. Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
- 2. Clean Basket and Pan:** The frying basket and pan have a non-stick coating. Clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes. They are generally dishwasher safe, but hand washing is recommended to preserve the non-stick coating.
- 3. Clean Interior:** Wipe the interior of the appliance with a damp cloth. Do not use abrasive cleaners or steel wool.
- 4. Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth.
- 5. Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

TROUBLESHOOTING

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overfilled. Food pieces are too large.	Do not overfill the basket. Shake or toss food halfway through cooking. Cut food into smaller, uniform pieces.
White smoke coming from the appliance.	Grease residue from previous use. Fatty ingredients being cooked.	Clean the basket and pan thoroughly after each use. For fatty foods, drain excess oil during cooking.
Food is not crispy.	Not enough oil used (for certain foods). Temperature or time settings incorrect.	Lightly brush or spray food with oil for crispier results. Adjust temperature and time as per recipe or preference.

SPECIFICATIONS

- **Model Name:** MasterPro
- **Item Model Number:** BGMP-9236-BK
- **Capacity:** 4 Litres
- **Output Wattage:** 1500 Watts
- **Voltage:** 220 Volts (AC)
- **Control Method:** Touch
- **Special Feature:** Temperature Control, Timer, Automatic Shut-Off
- **Product Dimensions:** 32D x 24W x 30H Centimeters
- **Item Weight:** 3.73 Kilograms
- **Material:** Stainless Steel (Inner: Non-stick coating)
- **Colour:** Black
- **Country of Origin:** China

WARRANTY AND SUPPORT

Your Bergner Masterpro Air Fryer comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your purchase receipt as proof of purchase.

For technical support, service, or warranty claims, please contact Bergner customer service. Contact details can typically be found on the product packaging or the official Bergner website.

Manufacturer: Bergner Impex India Pvt Ltd

Office Address: Office No. 1107, B Wing, Mittal Commercial, Marol, Off. Andheri Kurla Road, Next to Mittal Industrial Estate, Andheri East, Mumbai – 400059. Maharashtra, India.