

Sokany SK-005

Sokany Air Fryer SK-005 User Manual

Model: SK-005 | Capacity: 8.5L | Power: 1700W

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating the appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

PRODUCT OVERVIEW

The Sokany Air Fryer SK-005 is designed for healthy cooking with minimal to no oil. It features an 8.5-liter capacity, a powerful 1700W heating element, and intuitive controls for temperature and time.



Image: Main view of the Sokany Air Fryer SK-005, showcasing its sleek black design and overall structure.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Features temperature and timer knobs.
- **Frying Basket:** Removable basket for holding food.
- **Basket Handle:** For safe insertion and removal of the frying basket.



Image: Front view of the Sokany Air Fryer SK-005, highlighting the control panel with temperature and timer dials.



Image: The Sokany Air Fryer SK-005 with its frying basket partially pulled out, demonstrating the removable design.

SETUP

1. **Unpack:** Carefully remove all packaging materials and any promotional labels or stickers from the air fryer.
2. **Clean:** Before first use, clean the frying basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space on the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
4. **Power:** Plug the power cord into a grounded wall outlet.

OPERATING INSTRUCTIONS

1. **Prepare Food:** Place the ingredients into the frying basket. Do not overfill the basket to ensure even

cooking.

- 2. Insert Basket:** Slide the frying basket back into the air fryer until it clicks into place.
- 3. Set Temperature:** Turn the temperature control knob to your desired temperature (e.g., 180°C for most foods).
- 4. Set Timer:** Turn the timer knob to the required cooking time. The air fryer will start heating immediately.
- 5. Cooking Process:** The indicator light will illuminate, indicating the appliance is heating. During cooking, some foods may require shaking or turning for even results. To do this, pull out the basket, shake or turn the food, and then slide the basket back in. The air fryer will resume cooking.
- 6. Completion:** When the timer reaches zero, the air fryer will emit an audible signal and automatically shut off.
- 7. Remove Food:** Carefully pull out the frying basket. Use heat-resistant tongs to remove the cooked food. Avoid touching the hot basket or pan directly.
- 8. Cool Down:** Allow the appliance to cool down completely before cleaning or storing.

Basic Cooking Guide:

This table provides general guidelines. Actual cooking times and temperatures may vary based on food quantity, size, and desired crispness.

Food Item	Temperature	Time	Notes
Frozen Fries (thin)	180°C	15-20 min	Shake halfway
Chicken Drumsticks	180°C	20-25 min	Turn halfway
Fish Fillet	160°C	10-15 min	
Vegetables (mixed)	160°C	10-15 min	Shake halfway



Image: The Sokany Air Fryer SK-005 positioned next to a plate of golden-brown fries, illustrating a typical use case.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Basket and Pan:** The frying basket and pan are dishwasher safe. Alternatively, they can be cleaned with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn food residues, use a non-abrasive sponge and mild detergent.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not use harsh abrasive cleaners or scouring pads, as they may damage the surface.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer. Store it in a cool, dry place.

TROUBLESHOOTING

If you encounter any issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Timer not set.	Ensure the power cord is securely plugged into a grounded outlet. Set the timer to the desired cooking time.
Food is not cooked evenly.	Basket is overfilled. Food not shaken/turned.	Do not overfill the basket. Shake or turn food halfway through cooking.
White smoke comes from the appliance.	Grease residue from previous use. Excess oil on food.	Clean the basket and pan thoroughly after each use. Remove excess oil from food before air frying.
Food is not crispy.	Temperature too low or cooking time too short.	Increase temperature or cooking time. Ensure food is not overcrowded.

SPECIFICATIONS

Detailed technical specifications for the Sokany Air Fryer SK-005.



Image: Diagram showing the dimensions of the Sokany Air Fryer SK-005: 30cm depth, 30cm width, and 40cm height.

Feature	Specification
Brand	Sokany
Model	SK-005
Capacity	8.5 Liters
Power / Wattage	1700 Watts
Material	Aluminum
Color	Black
Product Dimensions (D x W x H)	30 x 30 x 40 cm
Item Weight	6.96 Kilograms

Feature	Specification
Control Method	Touch (referring to the control panel interface)
Special Features	Temperature Control
Dishwasher Safe Parts	Yes (Basket and Pan)

WARRANTY INFORMATION

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Sokany customer support. Contact details can typically be found on the product packaging or the official Sokany website.