

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [JOOLA](#) /

> [JOOLA Pickleball Chair \(Model 18279\) Instruction Manual](#)

JOOLA 18279

JOOLA Pickleball Chair (Model 18279) Instruction Manual

Brand: JOOLA

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your JOOLA Pickleball Chair, Model 18279. Designed for portability and comfort, this lightweight chair is suitable for various outdoor activities including pickleball courts, camping, beach trips, backpacking, and concerts.

COMPACT PORTABLE PICKLEBALL CHAIR



PERFECT FOR ANY OCCASSION

- FOLDED DIMENSIONS: 14" X 5"
- WEIGHT: 2 LBS
- ASSEMBLED DIMENSIONS:
21" X 19.5" X 28.2



Image: The JOOLA Pickleball Chair in its assembled state, showcasing its compact design.

SAFETY INFORMATION

Please read and understand all safety warnings before using the chair.

- **Maximum Weight Capacity:** Do not exceed the maximum weight capacity of 265 pounds (120 kg).
- **Stable Surface:** Always use the chair on a flat, stable, and level surface to prevent tipping.
- **Foot Protection:** The chair features rubberized feet designed to prevent slipping and protect surfaces. Ensure these are intact before use.
- **Assembly Caution:** Exercise caution during assembly to avoid pinching fingers or hands.
- **Children:** Keep children away from the chair during assembly and ensure proper supervision when children are near the assembled chair.

SETUP INSTRUCTIONS

The JOOLA Pickleball Chair is designed for quick and easy assembly, typically taking less than 30 seconds.

1. Unpacking

Remove the chair frame and seat fabric from the carry bag. The frame components are connected by shock-cord for organized assembly.



Image: The JOOLA Pickleball Chair components neatly packed in its carry bag.

2. Frame Assembly

1. Gently shake the frame components. The internal shock-cord will guide the poles into their respective connectors.
2. Ensure all poles are fully seated and locked into place to form a stable base.

EASY & QUICK SET-UP



- SHOCK-CORD POLES
KEEPS EVERYTHING
TOGETHER
- SEAT EASILY
SLIDES INTO PLACE
- TAKES LESS THAN 30
SECONDS TO SET UP



Image: Detailed view of the shock-cord pole system during assembly.

3. Seat Attachment

1. Locate the four reinforced sleeves or loops at the corners of the seat fabric.
2. Align the sleeves with the top ends of the frame poles.
3. Using the pull tabs, stretch the fabric and slip each corner onto its corresponding pole end. It may require some effort to stretch the fabric for the last corner.
4. Ensure all four corners are securely attached to the frame.



Image: The seat fabric being stretched and attached to the frame poles.

OPERATION AND FEATURES

Your JOOLA Pickleball Chair is designed for optimal comfort and convenience during use.

Comfort Features

- **Ergonomic Design:** The chair features a slightly lower height and perfectly angled seat to provide relaxation without fatiguing your legs.
- **Mesh Panels:** Integrated mesh panels promote air circulation, helping you stay cool and comfortable, especially during warm weather.



Image: The chair's mesh panels and angled seat design for enhanced comfort.

Storage Features

- **Side Pocket:** A convenient side pocket is included to keep items like water bottles or towels easily accessible.
- **Carry Bag Integration:** The carry bag can be attached to the chair frame, transforming it into a zippered storage spot for keys, phones, or extra pickleball balls.



Image: The chair's integrated side pocket and the carry bag functioning as additional storage.

MAINTENANCE

To ensure the longevity of your JOOLA Pickleball Chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For stubborn dirt, use mild soap and water, then rinse thoroughly and air dry.
- **Storage:** When not in use, disassemble the chair and store it in its carry bag in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically inspect the frame and fabric for any signs of wear or damage. Do not use if components are compromised.

TROUBLESHOOTING

If you encounter any issues with your JOOLA Pickleball Chair, please refer to the following common solutions:

- **Difficulty Assembling Frame:** Ensure all shock-cord poles are fully extended and clicked into their connectors. Sometimes a firm shake helps align them.
- **Difficulty Attaching Seat Fabric:** The fabric is designed to be taut. Start by attaching two opposite corners, then use the pull tabs to stretch and attach the remaining two corners. This may require some force.
- **Chair Feels Unstable:** Verify that all frame poles are securely connected and the seat fabric is fully attached to all four corners. Ensure the chair is placed on a flat, even surface.

SPECIFICATIONS

Feature	Detail
Brand	JOOLA
Model Name	Pickleball Chair
Item Model Number	18279
Product Dimensions (Assembled)	19.5"D x 21"W x 28.2"H
Folded Dimensions	14" x 5" (approximate, based on description)
Item Weight	2 pounds (0.9 kg)
Maximum Weight Recommendation	265 pounds (120 kg)
Frame Material	7075 Aluminum Alloy
Seat Fabric	900D Oxford Cloth, Mesh Panels
Special Feature	Foldable, Side Pocket, Carry Bag Storage
Indoor/Outdoor Usage	Outdoor



Image: Illustration of the chair's durable construction materials.

WARRANTY INFORMATION

For detailed warranty information regarding your JOOLA Pickleball Chair, please refer to the product packaging or visit the official JOOLA website. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance, or need to report an issue with your JOOLA Pickleball Chair, please contact JOOLA customer support through their official website or the contact information provided on the product packaging.