

PerGar WS0232

PerGar Wireless Weather Station User Manual

Model: WS0232

1. INTRODUCTION

Thank you for choosing the PerGar Wireless Weather Station. This device is designed to provide accurate and comprehensive weather data for your home or office, including indoor and outdoor temperature, humidity, wind speed, wind direction, and moon phase. Its large digital display ensures all data, current time, and date are clearly visible. This manual will guide you through the setup, operation, and maintenance of your new weather station.

2. WHAT'S INCLUDED

Carefully unpack your PerGar Wireless Weather Station and ensure all components listed below are present:

- 1 x Wind Vane
- 1 x Bracket
- 1 x Receiver (Outdoor Sensor Unit)
- 1 x Support Rod
- 1 x Display Unit (Indoor Console)
- 6 x Screws
- 2 x Nuts
- 4 x Expansion Tubes
- 1 x Instruction Manual



Figure 2.1: All components included in the PerGar Wireless Weather Station package.

3. PRODUCT SPECIFICATIONS

Feature	Specification
Model	WS0232
Transmission Frequency	433MHz
Transmission Distance (MAX)	Approx. 100m / 328.1ft (without physical obstructions)
Outdoor Temperature Range	-20 °C to +60 °C (± 1 °C accuracy)
Indoor Temperature Range	0 °C to +50 °C (± 1 °C accuracy)
Humidity Measurement Range	20% to 90% (R H) ($\pm 5\%$ accuracy)
Meteorological Station Power Supply	2 x AA alkaline batteries (not included)

Feature	Specification
Display Power Supply	2 x AAA alkaline batteries (not included)
Material	ABS
Special Feature	Alarm Function
Dimensions (Assembled Outdoor Unit)	Approx. 240mm (W) x 510mm (H) / 9.45in (W) x 20.08in (H)




Figure 3.1: Approximate dimensions of the assembled outdoor sensor unit.

4. SETUP AND INSTALLATION

4.1 Battery Installation

Both the outdoor meteorological station and the indoor display unit require batteries for operation. Ensure you have the correct battery types as specified in the specifications table.

1. **Outdoor Meteorological Station:** Locate the battery compartment on the outdoor sensor unit. Insert 2 x AA alkaline batteries, ensuring correct polarity.
2. **Indoor Display Unit:** Locate the battery compartment on the back of the display unit. Insert 2 x AAA alkaline batteries, ensuring correct polarity.


After inserting batteries, the units should power on automatically and attempt to establish a connection.



Figure 4.1: Location of the battery compartment on the display unit.

4.2 Outdoor Sensor Assembly

Assemble the outdoor sensor unit by attaching the wind vane, wind sensor cups, and support rod to the main sensor body. Refer to the diagram below for proper assembly.



Remote Wind Gauge Sensor Unit

Figure 4.2: Assembly of the Remote Wind Gauge Sensor Unit.



Figure 4.3: Detail of the wind vane and sensor cups.

4.3 Placement and Mounting

The PerGar Wireless Weather Station offers flexible mounting options for the outdoor sensor and placement for the indoor display unit.

- **Outdoor Sensor:** The outdoor sensor unit can be either wall-mounted or placed on a suitable surface using the provided bracket and screws/expansion tubes. Choose a location that is open and free from obstructions (such as large buildings, trees, or metal structures) to ensure accurate readings for wind speed/direction and optimal wireless signal transmission to the indoor display unit. The maximum transmission distance is approximately 100 meters (328 feet) in open areas.
- **Indoor Display Unit:** The display unit can be placed on a desktop using its integrated stand or mounted on a wall using the keyhole slot on its back. Position it in a central location within your home for easy viewing and to ensure good reception from the outdoor sensor.

TRANSMISSION DISTANCES UP TO 328

feet between the display and sensor
without physical obstructions
(such as sheds or trees)
blocking signal transmission



Figure 4.4: Examples of mounting and placement options for the weather station.

Temperature/ Humidity/ Wind Speed Measurement



Figure 4.5: The indoor display unit and outdoor sensor unit.

5. OPERATING INSTRUCTIONS

5.1 Digital Display Overview

The large digital screen of the indoor display unit provides a clear and easy-to-read overview of all weather data. It displays:

- Current indoor temperature and humidity
- Current outdoor temperature and humidity
- Wind speed and direction
- Moon phase
- Current time and date
- Weather forecast icons (sunny, cloudy, rainy, snowy)

Household measurement of indoor and outdoor temperature, humidity and wind direction and speed



Industrial and agricultural monitoring of temperature and humidity



Figure 5.1: The digital display interface showing real-time weather data and forecast.

5.2 Basic Functions

Once powered on and connected, the weather station will automatically begin displaying data. The display unit features buttons for navigation and settings:

- **MODE/NEXT:** Press to cycle through different display modes or to confirm settings during setup.
- **+/-:** Use these buttons to adjust values when setting time, date, or alarms.
- **SET/HISTORY:** Press to enter setup mode for time/date, alarm settings, or to view historical data.

5.3 Setting Time and Date

Refer to the specific instructions in your printed manual for detailed steps on setting the time and date, as button sequences may vary slightly.

5.4 Alarm and Warning Settings

The weather station allows you to customize temperature, humidity, and wind speed warnings. This feature alerts you when specific thresholds are met. Consult your printed manual for detailed instructions on setting these alarms.

6. MAINTENANCE

To ensure the longevity and accuracy of your PerGar Wireless Weather Station, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the display unit and outdoor sensor with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as they may damage the surfaces.
- **Battery Replacement:** Replace batteries in both units when the low battery indicator appears on the display, or if readings become inconsistent. Always replace with new alkaline batteries of the specified type.
- **Outdoor Sensor Placement:** Periodically check the outdoor sensor's mounting to ensure it remains secure and free from new obstructions that could affect readings or signal transmission. Clear any debris (leaves, dirt) from the wind vane and sensor cups.
- **Storage:** If storing the weather station for an extended period, remove all batteries to prevent leakage and corrosion.

7. TROUBLESHOOTING

If you encounter issues with your weather station, try the following common troubleshooting steps:

- **No Readings on Display / Outdoor Data Missing:**
 - Check batteries in both the indoor display unit and the outdoor sensor. Replace if low or depleted.
 - Ensure the outdoor sensor is within the effective transmission range (approx. 100m) and there are no significant physical obstructions (thick walls, large metal objects) between the units.
 - Try bringing the outdoor sensor closer to the indoor display unit temporarily to re-establish connection.
 - Restart both units by removing and reinserting batteries.
- **Inaccurate Readings:**
 - **Temperature/Humidity:** Ensure the outdoor sensor is not in direct sunlight or near heat sources (e.g., vents, appliances) that could skew readings. The indoor unit should also be away from direct heat or cold sources.
 - **Wind Speed/Direction:** Verify that the wind vane and sensor cups on the outdoor unit are spinning freely and are not obstructed by debris. Ensure the unit is mounted securely and level.
- **Display Not Working:**
 - Check the batteries in the display unit.
 - Ensure batteries are inserted with correct polarity.

If problems persist after attempting these steps, please refer to the support section.

8. WARRANTY AND SUPPORT

PerGar is committed to providing high-quality products. For any product-related inquiries, technical support, or warranty information, please contact PerGar customer service through the official PerGar store on Amazon or via the contact information provided in your product packaging.

You can visit the [PerGar Store on Amazon](#) for more information and support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question