

Zuomeng ZM-006

Zuomeng Septic Pump Alarm ZM-006

Instruction Manual

Model: ZM-006

Setup &
Introduction Safety Information Installation Operation Maintenance Troubleshooting
Specifications Warranty & Support

1. INTRODUCTION

The Zuomeng Septic Pump Alarm (Model ZM-006) is designed to provide reliable high water level detection for sewage pits, septic tanks, sump pumps, water tanks, and lift stations. This system alerts you to rising water levels through an audible alarm and a flashing light, helping to prevent potential flood damage to your property. It can also be configured to activate an external submersible pump for drainage.

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Zuomeng Septic Pump Alarm.



Figure 1: Overview of the Zuomeng Septic Pump Alarm and its application in preventing flood threats.

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and operation. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure all power is disconnected before performing any installation or maintenance. All wiring should be performed by a qualified electrician in accordance with local electrical codes.
- **UL Certified Components:** The wiring and circuit breaker are UL certified, ensuring compliance with international safety standards.
- **Weatherproof Casing:** The alarm unit features an IP67-rated weatherproof casing, suitable for both indoor and harsh outdoor conditions. However, ensure the casing is properly sealed after any internal access.
- **Pump Overload Protection:** If connecting an external pump, ensure the pump has internal overload protection.
- **Children and Pets:** Keep the alarm unit and its components out of reach of children and pets.

3. SETUP & INSTALLATION

The Zuomeng Septic Pump Alarm is designed for quick installation with pre-wiring in its internal design. It is suitable for wall mounting.

3.1 Components

- Alarm Control Panel (main unit with flashing light and audible alarm)
- Float Switch (for water level detection)
- Mounting hardware (e.g., clamps)

3.2 Mounting the Alarm Unit

Select a suitable location for the alarm control panel. It should be easily accessible for visual and audible alerts, and protected from direct impact. The unit is wall-mountable. Secure the unit firmly to a stable surface using appropriate fasteners.



Figure 2: The IP67-rated weatherproof casing ensures durability in various environments.

3.3 Float Switch Installation

Install the float switch at the desired high water level in your sewage pit, septic tank, or sump. Ensure the float switch has sufficient clearance to move freely and activate when the water level reaches the alert point. The float switch cable should be routed securely to the alarm control panel.

3.4 Electrical Connections

The alarm system features separated pump and alarm circuits. The unit comes pre-wired internally for ease of installation.

- 1. Power Connection:** Connect the alarm control panel to a 120V power source.
- 2. Float Switch Connection:** Connect the float switch wires to the designated terminals within the control panel.
- 3. External Pump Connection (Optional):** If you intend to use the alarm to activate an external submersible pump, connect the pump's power circuit to the designated terminals in the control panel. Refer to the circuit diagram for correct wiring. Ensure the pump has its own internal overload protection.




Figure 3: Product Circuit Diagram. Note: Motor must have internal overload protection.




Figure 4: Multiple Working Modes: 1. Connect the float switch. 2. External submersible pump. 3. Connect the float switch and external water pump.

4. OPERATION

4.1 Powering On

Once all connections are secure and verified, restore power to the alarm unit. The unit will enter standby mode.

4.2 High Water Level Detection

When the water level rises and activates the float switch, the alarm control panel will initiate an alert:

- An audible alarm will sound at 110 decibels.
- A bright warning light will flash.

If an external submersible pump is connected and configured, it will automatically activate to begin drainage.




Figure 5: The alarm features a 110-decibel siren and a bright flashing light for effective alerts.

4.3 Test Function

The alarm unit includes a test switch. To test the alarm, activate the test switch. This will simulate a high water event, triggering the audible alarm and flashing light. This function allows you to verify the system's operational status without needing to raise the water level.

4.4 Mute Function

The alarm can be temporarily muted after activation. Refer to the control panel's specific switch or button for muting the audible alarm. The visual alarm (flashing light) typically continues until the water level drops below the float switch activation point.

5. MAINTENANCE

Regular maintenance ensures the reliable operation of your Zuomeng Septic Pump Alarm.

- Regular Testing:** Periodically use the test function to ensure the alarm and light are working correctly. It is recommended to test the system monthly.
- Float Switch Inspection:** Annually inspect the float switch for any debris, corrosion, or damage that might impede its movement. Clean the float switch and its cable if necessary.
- Casing Inspection:** Check the alarm unit's IP67 casing for any cracks or damage that could compromise its weatherproof seal. Ensure all latches are securely closed.
- Wiring Check:** Periodically inspect all electrical connections for tightness and signs of wear or corrosion. Ensure all wiring is intact and properly insulated.
- Cleaning:** Keep the exterior of the alarm unit clean. Use a soft, damp cloth to wipe away dust or dirt. Do not use abrasive cleaners or solvents.

6. TROUBLESHOOTING

If you encounter issues with your Zuomeng Septic Pump Alarm, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Alarm does not sound or light does not flash when water level is high.	<ul style="list-style-type: none">No power to the unit.Float switch is stuck or faulty.Wiring issue.Alarm/light component failure.	<ul style="list-style-type: none">Check power supply and circuit breaker.Inspect float switch for obstructions; test its movement.Verify all wiring connections are secure.Contact customer support if components are faulty.
Alarm sounds continuously without high water.	<ul style="list-style-type: none">Float switch is stuck in the 'up' position.Faulty float switch.	<ul style="list-style-type: none">Inspect float switch for obstructions and ensure it can drop freely.Test float switch functionality; replace if faulty.

Problem	Possible Cause	Solution
External pump does not activate.	<ul style="list-style-type: none"> Pump not properly connected. Pump power issue. Float switch not activating pump circuit. Pump malfunction. 	<ul style="list-style-type: none"> Verify pump wiring to the control panel. Check pump's power supply and internal breaker. Ensure float switch is correctly wired for pump activation. Test the pump independently.
Test function does not work.	<ul style="list-style-type: none"> No power to the unit. Faulty test switch. 	<ul style="list-style-type: none"> Check power supply. Contact customer support for test switch replacement.

7. SPECIFICATIONS

Below are the technical specifications for the Zuomeng Septic Pump Alarm ZM-006:

Feature	Specification
Model Number	ZM-006
Voltage	120 Volts
Wattage	550 watts (for connected pump)
Noise Level	110 Decibels
Control Method	Float Switch
Mounting Type	Wall Mount
Sensor Technology	Float Switch
Item Weight	1.61 Kilograms (3.54 pounds)
Product Dimensions	6 x 4 x 5 inches (Alarm Unit)
IP Rating	IP67 (Weatherproof Casing)
Compatible Devices	Submersible Pump
Power Source	Corded Electric
Included Components	Clamps, Diffuser, PVC hose, Pond & Lake Aeration System (Note: Some components may vary based on package)

Pre-wiring



Figure 6: Product dimensions for the alarm unit and float switch.

8. WARRANTY & SUPPORT

8.1 Warranty Information

The Zuomeng Septic Pump Alarm ZM-006 comes with a **2-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Zuomeng Septic Pump Alarm, please contact Zuomeng customer support through the retailer where the product was purchased or refer to the contact information provided with your product packaging.