Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- AMD /
- > AMD Ryzen™ Threadripper™ 7960X 24-Core, 48-Thread Processor User Manual

AMD AMD Ryzen™ Threadripper™ 7960X

AMD Ryzen™ Threadripper™ 7960X Processor User Manual

Model: AMD Ryzen™ Threadripper™ 7960X

INTRODUCTION

The AMD Ryzen™ Threadripper™ 7960X is a high-performance desktop processor designed for professional workloads and demanding applications. It features 24 cores and 48 processing threads, providing exceptional multi-threaded performance. This processor supports up to 1TB of memory with wide Quad-Channel bandwidth and offers 80 usable PCIe lanes for extensive connectivity and I/O.

This manual provides essential information for the installation, operation, and maintenance of your AMD Ryzen™ Threadripper™ 7960X processor.



Image: The AMD Ryzen™ Threadripper™ 7960X processor, showcasing its integrated heat spreader (IHS) and overall form factor.

SETUP AND INSTALLATION

Proper installation of your AMD Ryzen™ Threadripper™ 7960X processor is crucial for optimal performance and system stability. This processor utilizes the TRX50 socket.

Before Installation:

- Ensure your motherboard is compatible with the AMD Ryzen™ Threadripper™ 7000 series processors and features a TRX50 socket.
- Verify that your motherboard's BIOS/UEFI is updated to the latest version supporting the 7960X processor.
- Gather necessary tools, including a compatible CPU cooler (not included with the processor), thermal paste, and a Phillips head screwdriver.
- Work in a static-free environment and use anti-static precautions (e.g., anti-static wrist strap).

Installation Steps:

1. Prepare the Motherboard Socket: Carefully open the CPU retention mechanism on the TRX50 socket according to

your motherboard's instructions.

- 2. **Align the Processor:** Gently remove the processor from its packaging. Align the triangular marker on the processor with the corresponding marker on the motherboard socket. Ensure the processor is oriented correctly.
- 3. **Insert the Processor:** Carefully lower the processor straight down into the socket. Do not force it. If it does not seat easily, re-check alignment.
- 4. Secure the Processor: Close the CPU retention mechanism to secure the processor in place.
- 5. **Apply Thermal Paste:** Apply a small amount of high-quality thermal paste to the center of the processor's integrated heat spreader (IHS). Refer to your thermal paste manufacturer's instructions for the recommended application method.
- 6. **Install CPU Cooler:** Mount your compatible CPU cooler onto the motherboard, ensuring it makes firm and even contact with the processor's IHS. Follow the cooler manufacturer's installation instructions.
- 7. **Connect Cooler Fan:** Connect the CPU cooler's fan cable to the designated CPU_FAN header on your motherboard.



Image: Side view of the AMD Ryzen™ Threadripper™ 7960X processor packaging, highlighting key features and compatibility information.

The AMD Ryzen™ Threadripper™ 7960X is designed for high-performance computing. Its operational characteristics are defined by its core architecture and advanced features.

- Core and Thread Count: Equipped with 24 physical cores and 48 processing threads, it excels in highly parallelized tasks such as 3D rendering, video editing, and scientific simulations.
- Clock Speed: The processor features an incredible 5.3 GHz Max Boost Frequency, allowing for strong single-threaded performance in addition to its multi-core capabilities.
- **Memory Support:** Supports Quad-Channel DDR5 RDIMM memory configurations up to 1TB, providing massive memory bandwidth essential for data-intensive applications.
- PCIe Lanes: Offers 80 usable PCIe lanes, enabling extensive expansion with multiple high-speed NVMe SSDs, graphics cards, and other PCIe devices.
- **Overclocking:** The processor is unlocked, allowing for manual overclocking to achieve higher performance. It also features automatic overclocking capabilities.
- Thermal Design Power (TDP): The 7960X has a TDP of 350W, indicating its power consumption and heat output. A robust cooling solution is essential to maintain optimal operating temperatures.




Image: An internal view of the AMD Ryzen™ Threadripper™ 7960X processor die, illustrating its complex multi-chip module design.

MAINTENANCE

Once installed, the AMD Ryzen™ Threadripper™ 7960X processor requires minimal direct maintenance. The primary focus should be on maintaining the overall health of your computer system to ensure the processor operates efficiently.

• Cooling System: Regularly inspect and clean your CPU cooler and case fans to prevent dust buildup, which can

impede airflow and lead to higher temperatures. Ensure thermal paste is not dried out or degraded over time (typically after several years).

- System Software: Keep your operating system, motherboard drivers (especially chipset drivers), and BIOS/UEFI firmware updated to ensure compatibility and optimal performance.
- Environmental Factors: Operate your system in a well-ventilated area, away from direct sunlight and excessive dust. Maintain a stable room temperature.

TROUBLESHOOTING

If you encounter issues with your system after installing the AMD Ryzen™ Threadripper™ 7960X processor, consider the following common troubleshooting steps:

System Not Booting/No Display:

- Verify that the processor is correctly seated in the socket and the retention mechanism is fully closed.
- Ensure all power cables (24-pin ATX, 8-pin CPU, etc.) are securely connected to the motherboard and power supply.
- Check RAM modules are properly seated in their slots. Try booting with only one RAM stick.
- · Confirm your CPU cooler is correctly installed and its fan is spinning.
- Reset CMOS (Clear Complementary Metal-Oxide-Semiconductor) on your motherboard.

Overheating Issues:

- Ensure the CPU cooler is properly mounted and making good contact with the processor.
- Verify that thermal paste was applied correctly and sufficiently.
- Check for proper airflow within your computer case; ensure case fans are oriented correctly and not obstructed by dust.
- Monitor CPU temperatures using system monitoring software.

• System Instability/Crashes:

- Ensure your motherboard's BIOS/UEFI is updated to the latest version.
- Run memory diagnostic tools to check for RAM issues.
- If overclocking, revert to default settings to rule out instability caused by excessive clock speeds or voltages.

For more advanced troubleshooting or persistent issues, consult your motherboard's manual or contact AMD support.

SPECIFICATIONS

Feature	Detail
Processor Model	AMD Ryzen™ Threadripper™ 7960X
Cores / Threads	24 Cores / 48 Threads
Max Boost Frequency	Up to 5.3 GHz
Base Clock Speed	Not specified (typically lower than boost)
Cache	152MB (L2+L3 Combined)
Socket Type	TRX50

Feature	Detail
Memory Support	Quad-Channel DDR5 RDIMM, up to 1TB
PCle Lanes	80 usable PCIe lanes
Thermal Design Power (TDP)	350W
Integrated Graphics	None (Dedicated graphics card required)
Item Weight	2.82 ounces (approx. 80 grams)
Product Dimensions (LxWxH)	11.81 x 11.81 x 11.81 inches (packaging dimensions)
First Available Date	November 21, 2023

WARRANTY AND SUPPORT

For information regarding the warranty of your AMD Ryzen™ Threadripper™ 7960X processor, please refer to the warranty documentation included with your product packaging or visit the official AMD website.

For technical support, driver downloads, and additional resources, please visit the official AMD support website:

AMD Official Support

When contacting support, please have your processor model number (AMD Ryzen™ Threadripper™ 7960X) and any relevant system information readily available.

© 2023 AMD. All rights reserved. AMD, the AMD Arrow logo, Ryzen, Threadripper, and combinations thereof are trademarks of Advanced Micro Devices, Inc. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

Related Documents - AMD Ryzen™ Threadripper™ 7960X



AMD Ryzen Master 1.5 Quick Reference Guide: Optimize Processor Performance

Discover AMD Ryzen Master 1.5, a software utility for enthusiasts to monitor, tune, and optimize AMD Ryzen and Ryzen Threadripper desktop processors for enhanced performance and stability.



AMD AOCL User Guide: Optimize Performance on Zen Processors

The AMD Optimizing CPU Libraries (AOCL) User Guide provides comprehensive instructions for installing, using, and tuning a suite of high-performance numerical libraries optimized for AMD 'Zen'-based processors. It covers AOCL-BLIS, AOCL-libFLAME, AOCL-FFTW, AOCL-LibM, AOCL-ScaLAPACK, AOCL-RNG, AOCL-SecureRNG, AOCL-Sparse, AOCL-LibMem, AOCL-Cryptography, and AOCL-Compression, along with integration with HPL and MUMPS, and performance tuning guidelines.

