

[manuals.plus](#) /› [Princess](#) /› [Princess 01.182238.01.001 Hot Air Fryer User Manual](#)

Princess 01.182238.01.001

Princess 01.182238.01.001 Hot Air Fryer User Manual

Model: 01.182238.01.001

1. INTRODUCTION

Thank you for purchasing the Princess 01.182238.01.001 Hot Air Fryer. This appliance is designed for healthy cooking, allowing you to fry, grill, roast, and bake with little to no oil. Please read this manual carefully before using the appliance to ensure safe and optimal performance. Keep this manual for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Supervise children to ensure they do not play with the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance and its cord out of reach of children.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.
- Always unplug the appliance after use and before cleaning. Allow it to cool down completely before handling.
- Do not use accessories not recommended by the manufacturer, as this may cause injuries.
- This appliance is intended for household use only.
- Hot air is released through the air outlet opening. Keep your hands and face at a safe distance from the openings.
- The surfaces may become hot during use. Do not touch hot surfaces directly. Use handles or knobs.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Princess Hot Air Fryer.



Image 1: Princess 01.182238.01.001 Hot Air Fryer. This image shows the compact design of the hot air fryer, typically featuring a main body, a removable basket with a handle, and control dials or a digital panel on the front for temperature and timer settings.

Key components typically include:

- **Main Unit:** Houses the heating element and fan.
- **Frying Basket:** Removable basket with a non-stick coating for holding food.
- **Handle:** For safely removing and inserting the frying basket.
- **Control Panel:** Dials or buttons for setting temperature and time.
- **Air Inlet/Outlet:** For proper air circulation during operation.

4. SETUP

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Remove any stickers or labels.
2. **Cleaning:** Before first use, clean the frying basket and pan thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a moist cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces. Ensure there is at least 10 cm of free space at the back and sides of the appliance and above it.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

5. OPERATING INSTRUCTIONS

The Princess Hot Air Fryer is designed for various cooking tasks including roasting, grilling, and baking.

- Preheating (Optional):** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature. Turn the temperature dial to the desired setting and the timer dial to 3-5 minutes.
- Prepare Food:** Place the food you wish to cook into the frying basket. Do not overfill the basket to allow for proper air circulation. The capacity of this model is 4 liters.
- Insert Basket:** Slide the frying basket back into the appliance until it clicks into place.
- Set Temperature and Time:**
 - Turn the temperature control dial to your desired temperature (e.g., 180°C for fries).
 - Turn the timer control dial to the required cooking time. The appliance will start operating. This model features a timer function.
- Cooking Process:** The appliance will automatically switch off when the timer reaches zero. You can pull out the basket at any time to shake or turn the food for even cooking.
- Remove Food:** Once cooking is complete, carefully pull out the frying basket using the handle. Place it on a heat-resistant surface.
- Serve:** Empty the cooked food into a serving dish. Be cautious of hot oil or food residue.

Note: Cooking times and temperatures may vary depending on the type and quantity of food. Refer to recipes or adjust as needed. The appliance operates at 1350 watts.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your hot air fryer.

- Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
- Clean Basket and Pan:** The frying basket and pan have a non-stick coating. Clean them with hot water, dishwashing liquid, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes. They may also be dishwasher safe (check product specific instructions if available, otherwise hand wash is recommended).
- Clean Exterior:** Wipe the exterior of the appliance with a damp cloth. Do not use abrasive cleaning agents or scouring pads.
- Clean Interior:** Clean the inside of the appliance with a non-abrasive sponge or cloth.
- Storage:** Store the appliance in a dry, clean place once it is completely dry.

7. TROUBLESHOOTING

If you encounter issues with your hot air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; timer not set.	Ensure the plug is securely in the outlet. Check the power outlet with another appliance. Set the timer to the desired cooking time.
Food is not cooked evenly.	Basket is overfilled; food not shaken/turned.	Do not overfill the basket. Shake or turn food halfway through cooking.

Problem	Possible Cause	Solution
White smoke coming from the appliance.	Grease residue from previous use; fatty food being cooked.	Clean the basket and pan thoroughly. Remove excess oil from food before cooking.
Food is not crispy.	Not enough oil (for certain foods); temperature too low; cooking time too short.	Lightly brush food with oil. Increase temperature or cooking time.

8. SPECIFICATIONS

Brand	Princess
Model Number	01.182238.01.001
Capacity	4 Liters
Power/Wattage	1350 Watts
Voltage	230V
Material	Aluminum, Plastic
Color	Black
Special Features	Timer, Non-stick coating
Product Dimensions (D x W x H)	34 x 33 x 32 cm (approximate)
Item Weight	3.9 Kilograms

9. WARRANTY AND SUPPORT

This Princess appliance comes with a guarantee period of at least 2 years from the date of purchase. This warranty covers manufacturing defects and material faults. In case of a defect or malfunction, please contact your retailer or the Princess customer support for assistance. Do not attempt to repair the appliance yourself. For further support or inquiries, please refer to the contact information provided with your purchase or visit the official Princess website.