

[manuals.plus](#) /› [ThreeH](#) /› [ThreeH Rainbow Digital Projection Alarm Clock H-AE20Black User Manual](#)

## ThreeH H-AE20Black

# ThreeH Rainbow Digital Projection Alarm Clock H-AE20Black User Manual

Model: H-AE20Black

## 1. INTRODUCTION

Thank you for choosing the ThreeH Rainbow Digital Projection Alarm Clock H-AE20Black. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper function and to maximize your user experience. Keep this manual for future reference.

## 2. PRODUCT OVERVIEW

The ThreeH H-AE20Black is a versatile digital alarm clock featuring a large LED mirror display, time projection, ambient night light, and dual USB charging ports. Its design incorporates adjustable brightness, volume, and a convenient snooze function.

### Key Features:

- **Projection Function:** Projects time onto a wall or ceiling with adjustable angle and brightness, up to 5 meters.
- **Dynamic RGB Display:** Features 11 color options for the main time display, including 4 dynamic RGB changes and 7 static colors, with 6 levels of brightness adjustment.
- **Ambient Night Light:** Integrated LED night light with 10 color modes (7 individual colors + 3 dynamic RGB changes) and 6 adjustable brightness levels.
- **Adjustable Alarm Volume:** Offers 6 volume levels ranging from 55dB to 95dB.
- **Snooze Function:** Allows for 5 to 60 minutes of extra sleep, with an easy-to-access button.
- **Mirror Surface:** The display surface can also function as a mirror.
- **Dual USB Charging Ports:** Equipped with USB and Type-C ports to charge two devices simultaneously.

### Product Components:



Figure 2.1: Front view of the ThreeH H-AE20Black alarm clock, highlighting the large LED display and mirror surface.



Figure 2.2: Side and rear view illustrating the dual USB charging ports (Output 1, Output 2, Input) and control buttons for alarm and volume.

### 3. SETUP

#### 3.1 Power Connection

1. Connect the provided USB cable to the 'INPUT' port on the side of the alarm clock.
2. Plug the other end of the USB cable into a standard USB power adapter (not included) or a powered USB port.
3. The display will illuminate, indicating the clock is powered on.

The included CR5 battery serves as a backup for time settings during power outages and does not power the main display or functions.

### 4. OPERATING INSTRUCTIONS

#### 4.1 Setting the Time

1. Press and hold the 'TIME SET' button (usually labeled with a clock icon or 'SET') for 3 seconds to

enter time setting mode.

2. The hour digits will flash. Use the '+' or '-' buttons to adjust the hour.
3. Press 'TIME SET' again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the '+' or '-' buttons to adjust the minutes.
5. Press 'TIME SET' one more time to confirm the minutes and exit time setting mode.

## 4.2 Setting the Alarm

1. Press and hold the 'ALARM' button (usually labeled 'AL' or with an alarm icon) for 3 seconds to enter alarm setting mode.
2. The alarm hour digits will flash. Use the '+' or '-' buttons to adjust the alarm hour.
3. Press 'ALARM' again to confirm the alarm hour and move to alarm minute setting. The alarm minute digits will flash.
4. Use the '+' or '-' buttons to adjust the alarm minutes.
5. Press 'ALARM' again to confirm the alarm minutes.
6. The display will show an alarm icon, indicating the alarm is active. To deactivate, press the 'ALARM' button once to toggle it off.



Figure 4.1: Illustration of the alarm display and the snooze button location.

## 4.3 Using the Snooze Function

1. When the alarm sounds, press the large 'SNOOZE' button located on the top of the clock.
2. The alarm will pause and sound again after the set snooze interval (default is typically 9 minutes, but can be adjusted from 5 to 60 minutes in settings).
3. To stop the alarm completely, press any other button on the clock, or let it ring for its full duration.

## 4.4 Adjusting Display Brightness and Color

1. Press the 'DIMMER' button (or a button labeled with a sun icon) to cycle through 6 levels of display brightness.
2. To change the display color, press the 'COLOR' button (or a button labeled with a color palette icon). Cycle through 7 static colors and 4 dynamic RGB color-changing modes.



### Full Range 0-100% Dimmer



Figure 4.2: The main display brightness can be adjusted from 0% to 100% across multiple levels.

## Dynamic RGB Display

7 regular color and 4 dynamic RGB changing color

Random Color



RGB Left to Right Flowing



RGB Downward Top Flowing



RGB Changing



White- Red -Yellow- Green - Light Blue-Blue-Purple



Figure 4.3: Examples of the 7 regular and 4 dynamic RGB color options for the digital time display.

### 4.5 Using the Projection Function

1. Press the 'PROJECTION' button (or a button labeled with a projection icon) to turn the time projection on or off.
2. To adjust the projection brightness, press the 'PROJECTION' button repeatedly to cycle through 3 brightness levels.
3. To rotate the projected image, long-press the 'PROJECTION' button. The image can be rotated up to 180 degrees for optimal viewing on a wall or ceiling.



Figure 4.4: The projection feature allows for 3 brightness levels and 180-degree rotation for clear viewing.

## 4.6 Adjusting Ambient Night Light

1. Press the 'LIGHT' button (or a button labeled with a light bulb icon) to turn the ambient night light on or off.
2. Press the 'LIGHT' button repeatedly to cycle through 10 color modes (7 individual colors and 3 dynamic RGB changes).
3. To adjust the brightness of the ambient light, use the '+' or '-' buttons while the ambient light is active. There are 6 brightness levels.



## Bottom Atmosphere Light

10 color Modes & 5-Level Brightness Adjustable



Figure 4.5: The base of the clock features an ambient light with 10 color modes and adjustable brightness.

### 4.7 Adjusting Alarm Volume

1. Press the 'VOL' button (or a button labeled with a speaker icon) to cycle through the 6 available alarm volume levels (55dB, 65dB, 75dB, 85dB, 95dB).
2. Select the volume level that best suits your preference.



Figure 4.6: Visual representation of the 6 adjustable volume levels for the alarm.

## 4.8 Using USB Charging Ports

1. Connect your device's charging cable to either the 'OUTPUT 1' (USB-A) or 'OUTPUT 2' (USB-C) port on the side of the alarm clock.
2. Ensure the alarm clock is powered on for the charging ports to function.
3. These ports are designed for convenient charging of small electronic devices like smartphones or earbuds.

## 5. MAINTENANCE

### 5.1 Cleaning

- To clean the clock, gently wipe the surface with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or electronic components.
- Ensure the clock is unplugged before cleaning.

### 5.2 General Care

- Avoid placing the clock in direct sunlight or near heat sources.
- Keep the clock away from water or high humidity environments.
- Do not disassemble the clock; this will void any warranty and may cause damage.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock display is off or flickering.	No power or unstable power connection.	Ensure the USB cable is securely connected and the power adapter is working. Try a different USB port or adapter.
Alarm does not sound.	Alarm not set or volume too low.	Verify alarm is activated (alarm icon visible). Increase alarm volume using the 'VOL' button.
Projection is unclear or not visible.	Projection brightness too low, incorrect angle, or too far from surface.	Adjust projection brightness. Long-press the 'PROJECTION' button to rotate the image. Ensure the clock is within 5 meters of the projection surface.
USB charging ports not working.	Clock not powered or device cable issue.	Ensure the clock is powered on. Try a different charging cable or device.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	H-AE20Black
Color	Black
Dimensions (L x W x H)	9.7 x 3.81 x 4 cm
Weight	250 grams
Material	Plastic
Power Source	USB Cable (DC 5V)
Backup Battery	1 x CR5 (included)
Projection Distance	Up to 5 meters
Alarm Volume Range	55dB - 95dB (6 levels)
Snooze Duration	5-60 minutes (adjustable)

## 8. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation provided at the time of purchase or contact your retailer. If you encounter any issues or require technical assistance, please contact ThreeH customer support through the retailer's platform or the official ThreeH website.