

[Manuals.plus](#) /

› [Easyfone](#) /

› Easyfone Prime-A1 Pro 4G Flip Phone User Manual

Easyfone Prime-A1 Pro

Easyfone Prime-A1 Pro 4G Flip Phone User Manual

Model: Prime-A1 Pro

Brand: Easyfone

1. INTRODUCTION

Welcome to the user manual for your new Easyfone Prime-A1 Pro 4G Flip Phone. This phone is designed with ease of use in mind, featuring large buttons, a clear display, and essential functions for reliable communication. It is particularly suited for users who prefer simplicity and accessibility in their mobile device.

This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your phone, ensuring you get the most out of its features. Please read this manual carefully before using your device.



The Easyfone Prime-A1 Pro 4G flip phone, featuring a compact design and an external display for quick information.

2. PACKAGE CONTENTS

Before you begin, please check the package contents to ensure all items are present:

- 1 x Easyfone Prime-A1 Pro 4G Flip Phone
- 1 x Charging Station
- 1 x EU Standard Charger

- 1 x Charging/Data Cable
- 1 x User Manual



The complete package includes the Easyfone Prime-A1 Pro phone, a convenient charging station, an EU standard charger, a charging/data cable, and a comprehensive user manual.

3. SETUP GUIDE

3.1. Inserting SIM Card and Battery

To begin using your phone, you need to insert a compatible SIM card (not included) and the battery.

1. Carefully remove the back cover of the phone.
2. Locate the SIM card slot. Insert your 4G compatible SIM card into the designated slot, ensuring the gold contacts face downwards and the cut corner is aligned correctly.
3. Insert the provided Lithium Metal battery into the battery compartment, aligning the contacts.
4. Replace the back cover until it clicks securely into place.

3.2. Initial Charging

It is recommended to fully charge the phone before first use.

- Connect the charging cable to the EU standard charger.
- Plug the charger into a power outlet.
- You can charge the phone either directly via the cable or by placing it in the charging station. Ensure the phone is correctly seated in the charging station for proper contact.
- The battery indicator on the screen will show charging progress. A full charge typically takes a few hours.



The phone comes with a 1500 mAh battery and a user-friendly charging station, ensuring extended standby time and convenient recharging.

3.3. Powering On/Off

- **To Power On:** Press and hold the Power/End Call button (red button) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear on the screen. Select 'Power Off' and confirm.

4. OPERATING INSTRUCTIONS

4.1. Making and Receiving Calls

- **Making a Call:** Enter the phone number using the large keypad buttons and press the Call button (green button).

- **Receiving a Call:** Simply open the flip phone to answer an incoming call. To end a call, close the flip or press the End Call button.

HD IPS Screen Display Easy to Read



The phone features a vibrant 2.4-inch HD IPS main screen and a convenient 1.44-inch external display, both offering clear and easy-to-read text and icons.

4.2. Using Large Buttons and Display

The Easyfone Prime-A1 Pro is designed with oversized, backlit buttons for easy dialing and navigation. The large font and icon display on both the main 2.4-inch HD screen and the 1.44-inch external screen ensure readability for all users.

Silicone Keyboard with Big Buttons



The phone features a silicone keyboard with large, tactile buttons, designed for easy and accurate dialing, especially for users with visual or motor challenges.

4.3. SOS Emergency Function

For emergencies, the phone includes a dedicated SOS button. Pressing and holding this button will automatically dial pre-set emergency contacts and send them an SMS message with your location, providing quick assistance when needed.



The dedicated SOS button allows users to quickly alert pre-selected emergency contacts with a call, message, and location information, providing peace of mind.

4.4. Photo Speed Dial

Assign your most important contacts to speed dial buttons (2-9) with their photos. This allows for quick and easy dialing by simply pressing the assigned number and seeing the contact's picture.

4.5. Hearing Aid Compatibility (HAC)

The Easyfone Prime-A1 Pro is designed to be compatible with hearing aids (HAC M4/T4 rating), ensuring clear audio for users with hearing devices. The powerful loudspeaker further enhances call clarity.



Designed with a loud and clear receiver and a powerful loudspeaker, the Easyfone Prime-A1 Pro ensures conversations are easily heard, and is compatible with hearing aids (HAC M4/T4).

4.6. Blocking Unwanted Calls

The phone features a call blocking function, allowing you to easily add unwanted numbers (such as scam calls, sales calls, or unknown numbers) to a blacklist with a simple button press. This helps to prevent nuisance calls.

Your browser does not support the video tag.

This video demonstrates key features of the Easyfone Prime-A1 Pro, including the external screen, flip-to-answer functionality, hearing aid compatibility, photo speed dial, and the ability to block unwanted calls.

4.7. Other Features

- **FM Radio:** Enjoy your favorite radio stations on the go.
- **Messaging:** Send and receive SMS text messages.
- **Alarm Clock:** Set alarms for reminders.

5. MAINTENANCE

5.1. Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture, disassemble, or short-circuit the battery.
- Use only the original charger and charging station provided with the phone.
- If the phone will not be used for an extended period, charge it to about 50% and store it in a cool, dry place.

5.2. Cleaning Your Device

- Use a soft, dry, lint-free cloth to clean the phone's surface.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture into openings.

5.3. Storage

Store your phone in a dry place away from direct sunlight, extreme temperatures, and humidity. Keep it away from dust and dirt.

6. TROUBLESHOOTING

If you encounter any issues with your Easyfone Prime-A1 Pro, please refer to the table below for common problems and their solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Phone does not power on	Low battery, faulty battery/charger	Charge the battery fully. Ensure the charger and cable are working correctly.

Problem	Possible Cause	Solution
Cannot make/receive calls	No SIM card, poor network signal, SIM card not activated	Ensure SIM is inserted correctly. Move to an area with better signal. Contact your service provider to verify SIM activation.
Poor call quality	Weak signal, interference, incorrect volume settings	Move to an open area. Adjust call volume. Check HAC settings if applicable.
Battery drains quickly	Frequent use, background features, old battery	Reduce usage of power-intensive features. Ensure no unnecessary applications are running. Consider battery replacement if the battery is old.
Screen is unresponsive or blank	Software glitch, physical damage	Restart the phone. If the issue persists after a restart, contact customer support.

7. SPECIFICATIONS

Below are the technical specifications for the Easyfone Prime-A1 Pro 4G Flip Phone:

Feature	Detail
Brand	Easyfone
Model Number	Prime-A1 Pro
Color	Red
Product Type	Flip Phone
Operating System	Nucleus OS
Main Screen Size	2.4 Inches
External Screen Size	1.44 Inches
Main Screen Resolution	320 x 240
Connectivity	4G LTE Cellular
RAM Size	64 MB
Memory Storage Capacity	1 GB
Battery Type	Lithium Metal
Battery Capacity	1500 mAh
Special Features	Charging station, Camera, Hearing aid compatible, SOS, Photo speed dial
Wireless Carrier	All carriers (Unlocked)

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The Easyfone Prime-A1 Pro comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact Easyfone customer support. Refer to the contact information provided on the product packaging or the official Easyfone website.

When contacting support, please have your product model number (Prime-A1 Pro) and purchase details ready.

© 2024 Easyfone. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CL4FGCN2>

More documents and user manuals: <https://manuals.plus/>