

Micodus MV720

Micodus MV720 GPS Tracker User Manual

Model: MV720

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Micodus MV720 GPS Tracker. The MV720 is a compact and efficient vehicle tracking device designed for real-time location monitoring, security, and remote control functionalities. Please read this manual thoroughly before using the device to ensure proper setup and optimal performance.

2. PRODUCT OVERVIEW

The Micodus MV720 is a discreet GPS tracker often designed to resemble a standard vehicle relay, making it ideal for covert installation. It integrates advanced GPS and cellular technologies to provide accurate positioning and communication capabilities.



Figure 2.1: The Micodus MV720 GPS Tracker, designed to look like a vehicle relay, shown with a SIM card package.



Figure 2.2: The MV720 tracker positioned beside a smartphone, illustrating its integration with the mobile tracking application.



Figure 2.3: A detailed view of the MV720's internal circuit board, highlighting its compact design and components.

3. SPECIFICATIONS

The following table outlines the technical specifications for the Micodus MV720 GPS Tracker (typical for MV7xx series):

Category	Parameter	Value
Device Information	Model	MV720 (GPS08)
	Weight	40g
	Dimensions	79mm(L) x 33mm(W) x 16mm(H)
	Battery	Built-in 60 mAh 3.7V polymer battery
Working Parameters	Working Voltage	9-95V DC
	Working Current	12V/average 35mA
	Sleep Current	12V/average 10mA
	Working Temperature	-20°C ~ 75°C
Cellular Specifications	SIM Card	Nano SIM
	Cellular Antenna	Built-in, FPC
	Working Frequency	GSM/2G: 850/900/1800/1900MHz
	4G LTE-FDD	B1/B2/B3/B4/B5/B7/B8/B28/B66
	GNSS	GPS+BDS
	GPS Frequency	L1: 1575.42±1.023MHz
	BDS Frequency	B1:1561.098±2.046MHz
	Sensitivity	-162 dBm

GNSS Specifications Category	Parameter	Value
	Satellite Channels	32
	Hot/Cold Start	<1s, <32s @ Open Sky
	Accuracy	<10m (1σ)
External Interface	ACC Detection	1
	Cut Off Fuel/Power	Standard
	SOS (optional)	1
	Open door Alarm (optional)	1
	Microphone	1

4. SETUP AND INSTALLATION

Proper installation is crucial for the MV720's performance. It is recommended to have the device installed by a qualified professional.

4.1 SIM Card Installation

1. Ensure the device is powered off.
2. Locate the SIM card slot on the device. The MV720 uses a Nano SIM card.
3. Insert the Nano SIM card into the slot with the correct orientation until it clicks into place.
4. Ensure the SIM card has an active data plan and is capable of 2G/4G communication.

4.2 Wiring Diagram

The MV720 is designed to be wired into your vehicle's electrical system. The following diagram illustrates the standard wiring connections:



Figure 4.1: Wiring diagram for the MV720 GPS Tracker, showing connections to battery, ignition, and fuel pump relay.

4.3 Connection Points

- **Red Wire:** Connect to the positive terminal of the vehicle's battery (constant 9-95V DC power).
- **Black Wire:** Connect to the negative terminal of the vehicle's battery or a reliable ground point.
- **Orange Wire (ACC):** Connect to the vehicle's ignition (ACC) wire. This allows the tracker to detect ignition status.
- **Yellow Wire (Relay Control):** Connect to the control wire of the fuel pump relay. This enables remote fuel cut-off functionality.
- **Blue/Green Wires (Relay Output):** These are the output wires from the relay integrated into the tracker, typically used to interrupt the fuel pump circuit.

Warning: Incorrect wiring can damage the device or the vehicle's electrical system. Consult a professional for installation if you are unsure.

5. OPERATING INSTRUCTIONS


The Micodus MV720 GPS Tracker is primarily operated through a dedicated mobile application or web platform.

5.1 Mobile Application / Web Platform

1. Download the official Micodus tracking application from your smartphone's app store (iOS/Android) or access the web platform via a browser.
2. Register an account and add your device using its unique ID number (usually found on the device or packaging).
3. Once added, you can view the real-time location of your vehicle, historical routes, and device status.

5.2 Key Features

- **Real-time Tracking:** Monitor your vehicle's live location on a map.
- **Historical Route Playback:** Review past travel routes and stops.
- **Geo-fence Alarm:** Set up virtual boundaries (geo-fences) on the map. You will receive an alert if the vehicle enters or exits these predefined areas. This is useful for monitoring specific zones like home, work, or restricted areas.



Geo-valla

Al configurar una o varias áreas específicas (hogar, empresa), el dispositivo sale o entra en esta área, recibiremos un mensaje de alarma.

Figure 5.1: The mobile application interface demonstrating the geo-fence and movement alarm settings, allowing users to define and monitor specific areas.

- **Remote Fuel/Power Cut-off:** In case of theft or unauthorized use, you can remotely cut off the vehicle's fuel supply or power via the app, preventing it from being driven further. This feature should be used with caution and only when the vehicle is stationary to avoid accidents.

Control remoto

Podemos controlar de forma remota nuestro dispositivo, y cuando alguien quiere robar un automóvil, podemos desconectar el circuito de aceite y el circuito por forma remota.



Figure 5.2: The mobile application displaying the remote fuel cut-off function, a security feature to disable the vehicle's engine remotely.

- **Vibration Alarm:** Receive alerts if the vehicle experiences unusual vibrations, indicating potential tampering or impact.
- **Speed Alarm:** Set a maximum speed limit, and receive notifications if the vehicle exceeds it.
- **ACC Detection:** Monitor when the vehicle's ignition is turned on or off.

6. MAINTENANCE

The Micodus MV720 GPS Tracker is designed for low maintenance. Follow these general guidelines to ensure its longevity:

- **Keep Dry:** Avoid exposing the device to water or excessive moisture.
- **Temperature:** Operate within the specified temperature range (-20°C to 75°C). Extreme temperatures can affect performance and battery life.
- **Cleanliness:** Keep the device free from dust and debris. Use a soft, dry cloth for cleaning.
- **Firmware Updates:** Periodically check the official Micodus website or app for any available firmware updates to ensure optimal performance and access to new features.
- **SIM Card:** Ensure the SIM card is always active and has sufficient data balance for continuous operation.

7. TROUBLESHOOTING

If you encounter issues with your Micodus MV720, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not showing online	No power, SIM card issue, poor network signal	Check power connection. Ensure SIM card is correctly inserted and active. Move to an area with better cellular coverage.
Inaccurate GPS location	Poor GPS signal, device obstructed	Ensure the device has a clear view of the sky. Avoid installing in enclosed metal areas.
Cannot send commands (e.g., fuel cut-off)	No network, incorrect wiring, device offline	Verify device is online. Check wiring connections, especially the yellow wire for relay control.
No historical data	Device was offline, data plan expired	Ensure continuous power and active data plan. Check device status regularly.
App not connecting to device	Incorrect device ID, server issues, app version outdated	Double-check device ID. Try restarting the app or your phone. Update the app to the latest version. Contact support if issues persist.

If the problem persists after trying these solutions, please contact Micodus customer support for further assistance.

8. WARRANTY AND SUPPORT

Micodus products typically come with a standard manufacturer's warranty. Please refer to your purchase documentation or the official Micodus website for specific warranty terms and conditions.

8.1 Customer Support

For technical support, troubleshooting assistance, or warranty claims, please contact Micodus customer service through their official website or the contact information provided with your product packaging. When contacting support, please have your device's model number (MV720) and unique ID readily available.

© 2025 Micodus. All rights reserved.

Documents - Micodus – MV720



[MiCODUS MV720 Tracker User Manual V2.0](#)

User manual for the MiCODUS MV720 Tracker, providing setup instructions, specifications, troubleshooting, and SMS commands.
lang:en score:63 filesize: 4.79 M page_count: 10 document date: 2022-03-17



[\[pdf\] User Manual Specifications](#)

MV720 _ppp MV720 User Manual V2.0 SZCS 123456 DOMAIN d micodus net 7700 MiCODUS server domain Port Google Maps Link G123456 or where V A In
MV720 User Manual V2.0 Learn how to set up your new Autopmall Tracker Copy right 2022 Aut opmall A ll Rights Reserved 1. Main
lang:en score:45 filesize: 597.21 K page_count: 10 document date: 2022-10-22



[\[pdf\] User Manual Specifications Dimension Guide Guide](#)

MV720 _DownloadMiCODUS MV720 Relay GPS Tracker 9 90V Cut Off Fuel Mini FoMV720 User Guide 2 0cdn shopify s files 1 0615 7254 6653 v 1710236493
R MV720 User Manual V2.0 Learn how to set up your new MiCODUS Tracker Copyright 2022 MiCODUS All Rights Reserved 1. Mai
lang:en score:44 filesize: 4.79 M page_count: 10 document date: 2022-03-17



[\[pdf\] User Manual Quick Start Guide Installation Guide Guide](#)

Sms Vibx Install Manual Pdf SMS VIBX Vibration Sound Masking Speaker User Guide Soft dB b27ec652cf mv720 quick setup guide micodus uploadfiles files b2 3
...
lang:en score:32 filesize: 4.9 M page_count: 1 document date: 2020-11-05

MICODUS

MICODUS 2G Device Firmware Upgrade

Upgrade Overview

(1) Purpose of Upgrade

Since the V10 Upgrade, we received an increase in device failures. Preliminary investigation has confirmed that the issue stems from the Micr-Voice Service Router (MVS) power supply. The V10 Upgrade has a power supply that is not able to handle the increased power requirements of the MVS. This has led to a failure in the MVS, which in turn causes the device to fail.

(2) Applicable Models and Firmware Versions

This document applies to the following Micodus 2G device models:

MV70, MV710, MV720, MV730, and MV740. The MV70 is not affected by this issue. The MV70's power supply is able to handle the increased power requirements of the MVS. The MV70's power supply is not affected by this issue.

(3) Functional Advantages and Differences After the Upgrade

1. Function Compatibility Retention

- Local Upgrade (Smart Net Configuration) Only the configuration data will be updated during the configuration time. After the configuration is completed, the device will automatically return to the previous configuration. This will not affect the device's power consumption, and will not affect the device's performance.
- Programmable Upgrade (Smart Net Application) The device will automatically update the device's software to the latest version. This will not affect the device's power consumption, and will not affect the device's performance.

2. Core Performance Optimization

After the upgrade, the CPU's operating performance of the device is significantly improved.

[Micodus 2G Device Firmware Upgrade Guide](#)

This guide provides step-by-step instructions for upgrading the firmware of Micodus 2G devices (models MV710, MV720, MV730, MV740).
lang:en score:28 filesize: 2.72 M page_count: 12 document date: 2025-08-25



[\[pdf\] Quick Start Guide Installation Guide Guide](#)

MV720 QUICK SETUP GUIDE Micodus Title Created Date 6 24 2020 4 28 21 PM 1a066f6f1a mv720 quick setup guide micodus uploadfiles files 1a 8 lug 2022 –
...

lang:en score:24 filesize: 8.1 M page_count: 1 document date: 2020-06-24



[\[pdf\] Quick Start Guide Guide](#)

MV720 3 SIM Card Installation Wiring Micodus No need to set APN Included 1MB free data for quick activated contracts MV720 Quick Setup Guide Learn how to use the device
...

lang:en score:24 filesize: 7.56 M page_count: 1 document date: 2020-04-13



[\[pdf\] Quick Start Guide Installation Guide](#)

MV720 QUICK SETUP GUIDE Micodus Title Created Date 6 24 2020 4 28 21 PM 1a066f6f1a mv720 quick setup guide micodus uploadfiles files 1a 8 lug 2022 –
...

lang:en score:24 filesize: 8.1 M page_count: 1 document date: 2020-06-24

[\[pdf\] Quick Start Guide Guide](#)

MV720 3 SIM Card Installation Wiring Micodus No need to set APN Included 1MB free data for quick activated contracts MV720 Quick Setup Guide Learn how to use the device
...

lang:en score:24 filesize: 7.56 M page_count: 1 document date: 2020-04-13



[\[pdf\] Quick Start Guide Installation Guide](#)


MV720 QUICK SETUP GUIDE Micodus Title Created Date 6 24 2020 4 28 21 PM 1a066f6f1a mv720 quick setup guide micodus uploadfiles files 1a 8 lug 2022 –
...

lang:en score:24 filesize: 8.1 M page_count: 1 document date: 2020-06-24

[\[pdf\] Quick Start Guide Guide](#)

MV720 3 SIM Card Installation Wiring Micodus No need to set APN Included 1MB free data for quick activated contracts MV720 Quick Setup Guide Learn how to use the device
...

lang:en score:24 filesize: 7.56 M page_count: 1 document date: 2020-04-13



[\[pdf\] Quick Start Guide Installation Guide](#)


MV720 QUICK SETUP GUIDE Micodus Title Created Date 6 24 2020 4 28 21 PM 1a066f6f1a mv720 quick setup guide micodus uploadfiles files 1a 8 lug 2022 –
...

lang:en score:24 filesize: 8.1 M page_count: 1 document date: 2020-06-24

[\[pdf\] Quick Start Guide Guide](#)

MV720 3 SIM Card Installation Wiring Micodus No need to set APN Included 1MB free data for quick activated contracts MV720 Quick Setup Guide Learn how to use the device
...

lang:en score:24 filesize: 7.56 M page_count: 1 document date: 2020-04-13



[\[pdf\] Catalog](#)

Untitled 4537679c27 mv720 catalog micodus uploadfiles files 45 |||

...

lang:en score:17 filesize: 1.79 M page_count: 1 document date: 2020-06-22

[pdf]

MiCOD MiC...

lang:en score:17 filesize: 2.04 M page_count: 1 document date: 2019-12-03

[pdf]

MICODUS prom st Если нет Spionlink пожалуйста купите карту которая поддерживает GSM и GPRS с достаточным балансом 6 Очень важно подключите 1

10

lang:en score:12 filesize: 705.28 K page_count: 2 document date: 2021-03-21