

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LILYGO](#) /

› [LILYGO T-ETH-Lite ESP32 Development Board User Manual](#)

## LILYGO T-ETH-Lite

# LILYGO T-ETH-Lite ESP32 Development Board User Manual

Model: T-ETH-Lite ESP32

## 1. INTRODUCTION

---

The LILYGO T-ETH-Lite ESP32 is a compact development board designed for projects requiring both Wi-Fi and Ethernet connectivity. It integrates an ESP32-WOVER-E microcontroller, an RTL8201 Ethernet chip, and a TF card slot, making it suitable for various IoT applications, network devices, and embedded systems. This manual provides essential information for setting up, operating, and maintaining your T-ETH-Lite ESP32 board.

## 2. PRODUCT FEATURES

---


- **Microcontroller:** ESP32-WOVER-E
- **Memory:** 16MB Flash, 8MB PSRAM
- **Wireless Connectivity:** Wi-Fi 802.11 b/g/n, Bluetooth BR/EDR V4.2 + BLE
- **Wired Connectivity:** RTL8201 Ethernet
- **Onboard Peripherals:** TF Card Slot
- **Buttons:** Reset, Boot
- **Dimensions:** Approximately 2.32 x 1.1 x 0.43 inches (5.9 x 2.8 x 1.1 cm)
- **Expandability:** Supports POE Shield (sold separately)

## 3. PACKAGE CONTENTS

---

Verify that all items are present in your package. If any components are missing or damaged, please contact your vendor.

- 1 x LILYGO T-ETH-Lite ESP32 Development Board
- 2 x 15-pin Headers
- 1 x 2\*4-pin Header




**Figure 3.1:** The image displays the LILYGO T-ETH-Lite ESP32 board along with two 15-pin headers and one 2x4-pin header, which are typically included in the package for connectivity.

## 4. HARDWARE OVERVIEW

The T-ETH-Lite ESP32 board features a compact design with essential components for network-enabled embedded projects. Below are diagrams illustrating the front, back, and pinout configurations of the board.

### 4.1 Board Layout



**Figure 4.1:** Front view of the LILYGO T-ETH-Lite ESP32 development board, showing the ESP32-W01 module, Ethernet chip, and various pin headers.





Figure 4.2: Back view of the LILYGO T-ETH-Lite ESP32 development board, highlighting the TF card slot and additional components.


## 4.2 Dimensions



**Figure 4.3:** This image illustrates the physical dimensions of the LILYGO T-ETH-Lite ESP32 board, with length (L) approximately 5.9 cm, width (W) 2.8 cm, and height (H) 1.1 cm.

### 4.3 Pinout Diagram

Understanding the pinout is crucial for connecting external components and programming the board. The diagram below details the GPIOs, power pins, and other interfaces.



**Figure 4.4:** Detailed pinout diagram for the LILYGO T-ETH-Lite ESP32, showing GPIO assignments, power rails (3V3, 5V), ground (GND), TF card connections (SD\_MISO, SD\_MOSI, SD\_SCLK, SD\_CS), ADC channels, Touch pins, and serial communication pins (TXD, RXD). It also indicates the RTL8201 Ethernet module connections and suggests using a USB to TTL adapter for programming.

## 5. SETUP INSTRUCTIONS

Follow these steps to prepare your LILYGO T-ETH-Lite ESP32 for development.

### 5.1 Hardware Connection

- 1. Attach Pin Headers:** Solder the provided pin headers to the board if not already attached. This allows for easy connection to a breadboard or custom circuitry.
- 2. Power Supply:** Connect a 5V power supply to the 5V IN pin and GND. Alternatively, if using a POE Shield (sold separately), power can be supplied via Ethernet.
- 3. USB-to-TTL Adapter:** The T-ETH-Lite ESP32 does not have an onboard USB-to-serial converter. You will need an external USB-to-TTL adapter for programming. Connect the adapter's TXD to the board's RXD, RXD to TXD, and GND to GND. Ensure the adapter's voltage level matches the ESP32 (3.3V).
- 4. Ethernet Cable:** Connect a standard Ethernet cable to the RJ45 port for wired network access.
- 5. TF Card (Optional):** Insert a formatted TF card into the slot if your application requires data storage.

### 5.2 Software Environment Setup

- 1. Install Arduino IDE or ESP-IDF:** Download and install the Arduino IDE or Espressif IoT Development Framework (ESP-IDF) based on your development preference.
- 2. Install ESP32 Board Support:** For Arduino IDE, add the ESP32 board manager URL in preferences and install the ESP32 boards package. For ESP-IDF, follow the official installation guide.
- 3. Install Drivers:** Ensure drivers for your USB-to-TTL adapter are installed on your computer.
- 4. Clone GitHub Repository:** For example code and libraries specific to the T-ETH-Lite series, clone the official

## 5.3 Uploading Firmware

1. **Select Board:** In your IDE, select the appropriate ESP32 board (e.g., "ESP32 Dev Module").
2. **Select Port:** Choose the serial port corresponding to your USB-to-TTL adapter.
3. **Enter Bootloader Mode:** To upload code, press and hold the **Boot** button on the T-ETH-Lite board, then press the **Reset** button. Release **Reset**, then release **Boot**. The board is now in bootloader mode.
4. **Upload Code:** Compile and upload your sketch or program.

## 6. OPERATING INSTRUCTIONS

---

Once the firmware is uploaded, the T-ETH-Lite ESP32 will execute the programmed logic. For network applications, ensure your code initializes the Ethernet and/or Wi-Fi interfaces correctly.

- **Ethernet Operation:** Your code should initialize the RTL8201 Ethernet controller and obtain an IP address via DHCP or static assignment.
- **Wi-Fi Operation:** Configure your ESP32 code to connect to your desired Wi-Fi network (SSID and password).
- **TF Card Access:** Use the appropriate libraries (e.g., SD.h in Arduino) to read from and write to the TF card.
- **GPIO Control:** Program the GPIO pins as inputs or outputs to interface with sensors, actuators, or other external circuits. Refer to the pinout diagram (Figure 4.4) for available GPIOs.

## 7. MAINTENANCE

---

Proper care ensures the longevity and reliable operation of your development board.

- **Handle with Care:** Avoid dropping the board or subjecting it to physical stress.
- **Static Discharge:** Always handle the board in a static-safe environment to prevent damage to sensitive electronic components.
- **Power Supply:** Use a stable 5V power supply. Incorrect voltage can damage the board.
- **Environmental Conditions:** Operate the board within typical indoor temperature and humidity ranges. Avoid extreme temperatures, moisture, and dust.
- **Cleaning:** If necessary, gently clean the board with a soft, dry brush or compressed air. Avoid liquids.

## 8. TROUBLESHOOTING

---

If you encounter issues, refer to the following common troubleshooting steps.

1. **Board Not Powering On:**
  - Verify the 5V power supply is connected correctly and providing sufficient current.
  - Check for any short circuits on the board.
2. **Failed Firmware Upload:**
  - Ensure the USB-to-TTL adapter is correctly connected (TX to RX, RX to TX, GND to GND).
  - Confirm the correct serial port is selected in your IDE.
  - Make sure the board is in bootloader mode (hold Boot, press Reset, release Reset, release Boot).
  - Check that the USB-to-TTL adapter drivers are installed.
3. **Ethernet Not Connecting:**
  - Verify the Ethernet cable is securely connected to both the board and the network device.
  - Check your code for correct Ethernet initialization and configuration (e.g., DHCP client).

- Ensure your network infrastructure (router, switch) is functioning correctly.

#### 4. Wi-Fi Connection Issues:

- Double-check the Wi-Fi SSID and password in your code.
- Ensure the Wi-Fi network is within range and operating on a 2.4GHz band.
- Verify that your ESP32 code correctly initializes the Wi-Fi module.

#### 5. TF Card Not Detected:

- Ensure the TF card is inserted correctly and fully seated.
- Verify the TF card is formatted to a compatible file system (e.g., FAT32).
- Check your code for correct TF card initialization and pin assignments.

## 9. SPECIFICATIONS

---

Feature	Detail
MCU	ESP32-WOVER-E
Flash Memory	16 MB
PSRAM	8 MB
Wireless Connectivity	Wi-Fi 802.11 b/g/n, Bluetooth BR/EDR V4.2 + BLE
Ethernet Controller	RTL8201
Onboard Peripherals	TF Card Slot
Buttons	Reset, Boot
Product Dimensions (LxWxH)	5.9 x 2.8 x 1.1 cm (2.32 x 1.1 x 0.43 inches)
Operating Voltage	5V (via VIN pin)

## 10. SUPPORT AND RESOURCES

---

For further technical support, code examples, and community discussions, please refer to the official LILYGO GitHub repository and community forums.

- **Official GitHub Repository:** [github.com/Xinyuan-LilyGO/LilyGO-T-ETH-Series](https://github.com/Xinyuan-LilyGO/LilyGO-T-ETH-Series)
- **LILYGO Official Website:** [www.lilygo.cc](http://www.lilygo.cc)