

Topski 8010

Topski Digital Alarm Clock Model 8010 User Manual

INTRODUCTION

Thank you for purchasing the Topski Digital Alarm Clock Model 8010. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.

PRODUCT FEATURES

- **Large LED Display:** A 7-inch LED display with 2.36-inch tall numbers for clear visibility.
- **Adjustable Brightness:** Dimmable display and night light to suit your preference.
- **Dual Alarms:** Set two independent alarms for different wake-up times.
- **Adjustable Alarm Volume:** Three levels of alarm volume, from low to extra loud.
- **Snooze Function:** A large, easy-to-locate snooze button for an additional 9 minutes of sleep.
- **Integrated Night Light:** An adjustable night light for a comforting ambiance.
- **USB Charging Port:** Convenient USB port for charging other devices.
- **Battery Backup:** Requires 2 AAA batteries (not included) to preserve time settings during power outages.

PACKAGE CONTENTS

- Topski Digital Alarm Clock Model 8010
- Power Adapter
- User Manual

SETUP

1. Power Connection

The alarm clock is primarily powered by an electrical outlet. Connect the provided power adapter to the Type-C port on the back of the clock and then plug it into a standard wall outlet.



Image: The alarm clock is shown connected to an AC power outlet, illustrating its primary power source. A smartphone is also shown charging via the clock's USB port.

2. Battery Backup Installation

For battery backup functionality, install 2 AAA batteries (not included) into the battery compartment located on the back of the clock. This ensures that your time settings are preserved in case of a power interruption, though the clock will not function normally on battery power alone.

Battery Backup



2x AAA batteries (not included)

Image: A close-up of the back of the alarm clock, highlighting the battery compartment for 2 AAA batteries.

OPERATING INSTRUCTIONS

1. Setting the Time

1. Press the **SET/12/24** button on the back of the clock to enter time setting mode. The hour digits will begin to flash.
2. Use the **+** and **-** buttons to adjust the hour.
3. Press **SET/12/24** again to confirm the hour and move to minute setting. The minute digits will flash.
4. Use the **+** and **-** buttons to adjust the minutes.
5. Press **SET/12/24** one more time to confirm the minutes and exit time setting mode.

2. 12/24 Hour Format

While in normal time display mode, press the **SET/12/24** button to toggle between 12-hour (AM/PM indicator) and 24-hour formats.



Image: The clock displays both 12-hour and 24-hour time formats, demonstrating the setting option.

3. Setting Alarms (A1 & A2)

The clock supports two independent alarms (A1 and A2).

1. Press the **A1** button (for Alarm 1) or **A2** button (for Alarm 2) on the back of the clock. The alarm hour digits will flash.

2. Use the + and - buttons to adjust the alarm hour.
3. Press the respective alarm button (**A1** or **A2**) again to confirm the hour and move to minute setting. The alarm minute digits will flash.
4. Use the + and - buttons to adjust the alarm minutes.
5. Press the alarm button (**A1** or **A2**) one more time to confirm the minutes and activate the alarm. An alarm icon will appear on the display.
6. To deactivate an alarm, press its respective alarm button (**A1** or **A2**) until the alarm icon disappears from the display.

Dual Alarms & Big Snooze Button

Tap to get 9 min snooze



Image: The clock displays two alarm times (7:35 AM and 8:05 AM), with a hand reaching for the large snooze button on top.

4. Adjusting Alarm Volume

Press the **VOL** button on the back of the clock to cycle through three alarm volume levels: low, medium, and extra loud (up to 100dB).

Extra Loud Alarm



Image: The back of the clock with buttons labeled, illustrating the three alarm volume settings (90dB, 95dB, 100dB).

5. Snooze Function

When an alarm sounds, press the large **SNOOZE** button on the top of the clock to temporarily silence the alarm for 9 minutes. The alarm will sound again after 9 minutes. To turn off the alarm completely, press any other button on the back of the clock.

6. Adjusting Night Light and Display Brightness

The clock features separate controls for the night light and the time display brightness.

- **Night Light:** The night light is located on the top of the clock. Tap the top surface to turn the night light on or off. Use the **DIMMER LIGHT** slider on the side to adjust its brightness from 0-100% or turn it off completely.
- **Display Brightness:** Use the **DIMMER SCREEN** slider on the side to adjust the brightness of the time digits from 0-100% or turn them off completely for those who prefer complete darkness.



Image: The alarm clock on a bedside table, demonstrating the dimmable night light and display, with a slider indicating 0-100% brightness adjustment.

Colorful Night Light Effects

Brightness adjustments



Image: Multiple views of the alarm clock showcasing different colorful night light effects and display colors.

7. USB Charging Port

The clock includes a USB port on the back for charging compatible electronic devices. Simply connect your device's USB charging cable to this port.

MAINTENANCE

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace AAA batteries annually or when the battery backup function is no longer reliable.
- **Storage:** If storing the clock for an extended period, remove the AAA batteries to prevent leakage.

TROUBLESHOOTING

- **Clock not powering on:** Ensure the power adapter is securely connected to both the clock and a working electrical outlet. Check if the outlet is functional.
- **Alarm not sounding:** Verify that the alarm (A1 or A2) is activated (alarm icon visible on display) and

the volume is set to an audible level.

- **Time not saving during power outage:** Ensure 2 new AAA batteries are correctly installed in the battery compartment.
- **Display too bright/dim:** Use the **DIMMER SCREEN** slider on the side of the clock to adjust the display brightness.
- **Night light not working/too bright/dim:** Tap the top surface to toggle the night light. Use the **DIMMER LIGHT** slider on the side to adjust its brightness.

SPECIFICATIONS

Feature	Detail
Brand	Topski
Model Number	8010
Display Type	Digital LED
Product Dimensions	6.6"W x 3.1"H
Item Weight	10.5 ounces
Power Source	Corded Electric (2 AAA batteries for backup)
Material	Acrylonitrile Butadiene Styrene (Plastic)
Special Features	Adjustable Brightness, Adjustable Volume, Large Display, Loud Alarm, Snooze

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Topski website. Keep your purchase receipt as proof of purchase.