

## TAYAMA TSP-1000

# TAYAMA 8-in-1 Multi-Functional Stainless Steel Electric Stew Cooker

Model: TSP-1000

## INTRODUCTION

---

The Tayama TSP-1000 8-in-1 Multi-Functional Stainless Steel Electric Stew Cooker is designed for versatile and convenient cooking. Featuring a computerized control system with an LED indicator, it allows for safe, monitor-free operation. This appliance includes a 10-liter stainless steel inner pot, a ceramic pot, a steaming rack, and a chicken essence lid, providing a wide range of cooking options such as rice, congee, soup, stew, braise, and steam.

Key features include:

- 8 Preset Cooking Functions: Slow Stew, Quick Stew, Steam, Soup, Porridge, Rice, Braise and Herbal Tea.
- Removable food grade stainless steel 304 inner pot (10.0L) for easy cleaning.
- High quality ceramic pot (4.0L) with lids to retain natural flavors and nutrients.
- Adjustable cooking time and delay start preset timer.
- Automatic keep warm function after cooking.
- Easy-to-use computerized control panel with digital display.
- Automatic shut-off function to prevent overheating and dry-boil protection.
- Heat resistant glass lid.



Figure 1: The Tayama 8-in-1 Multi-Functional Electric Stew Cooker, showcasing the main unit, the stainless steel inner pot, the ceramic pot with its lid, and the steaming rack.

## SETUP AND ASSEMBLY

---

Before first use, ensure all packaging materials are removed. Wash the inner pots, lids, and steaming rack thoroughly with warm, soapy water, then rinse and dry completely. The main unit should be wiped clean with a damp cloth.

1. Place the cooker on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources.
2. Ensure proper ventilation around the unit.
3. Insert either the stainless steel inner pot or the ceramic pot into the main unit. Ensure it is seated correctly.
4. Place the appropriate lid on the pot.
5. Plug the power cord into a grounded electrical outlet (120V AC).



Figure 2: Front view of the cooker, highlighting the digital control panel and its various function buttons.

## OPERATING INSTRUCTIONS

The Tayama TSP-1000 features a user-friendly control panel for selecting various cooking functions and settings.



Figure 3: Detailed view of the control panel, showing buttons for Rice, Soup, Congee, Steam, Fast Stew, Slow Stew, Braise, Herbal Tea, Preset, Timer, Keep Warm, and On/Off.

## Basic Operation:

1. Add ingredients to the inner pot. Do not overfill beyond the MAX line.
2. Place the inner pot into the main unit and cover with the lid.
3. Press the **On/Off** button to power on the unit.
4. Select your desired cooking function (e.g., **Rice**, **Soup**, **Steam**). The corresponding indicator light will illuminate.
5. If desired, use the **+** and **-** buttons to adjust cooking time or set a delay timer using the **Preset** or **Timer** functions.
6. The cooker will automatically begin the cooking process.
7. Once cooking is complete, the unit will automatically switch to **Keep Warm** mode.
8. To turn off the unit, press the **On/Off** button again.

## Specific Functions:

- **Rice:** For cooking various types of rice.
- **Soup:** Ideal for preparing broths and soups.
- **Congee:** Perfect for slow-cooked rice porridge.
- **Steam:** Use with the steaming rack for vegetables, dumplings, etc.
- **Fast Stew:** For quicker stewing processes.
- **Slow Stew:** For tender, long-cooked stews.
- **Braise:** For braising meats and vegetables.
- **Herbal Tea:** Specifically designed for brewing herbal teas and tonics.

**Delay Start (Preset):** This function allows you to set a time for the cooking process to begin automatically. Use the **Preset** button and **+/-** buttons to set the desired delay time (up to 9.9 hours).

**Timer:** Use this function to manually adjust the cooking duration for certain programs after selecting them.

**Keep Warm:** The cooker automatically enters this mode after cooking. Press the **Keep Warm** button to manually activate or deactivate this function.

## CARE AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Tayama Electric Stew Cooker.

### Cleaning:

1. Always unplug the cooker from the power outlet and allow it to cool completely before cleaning.

2. The stainless steel inner pot, ceramic pot, lids, and steaming rack are dishwasher safe. Alternatively, wash them with warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. Do not use abrasive cleaners, scouring pads, or steel wool, as these can damage the surfaces.



Figure 4: The removable 10-liter stainless steel inner pot, designed for durability and easy cleaning.



Figure 5: The 4-liter ceramic pot with its lid and the included steaming rack, ideal for preserving flavors.

**Storage:**

Store the cooker in a cool, dry place. Ensure all components are clean and dry before storing. Do not wrap the power cord tightly around the unit.

**TROUBLESHOOTING GUIDE**

If you encounter issues with your Tayama Electric Stew Cooker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooker does not turn on.	Not plugged in; power outage; unit not properly seated.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker. Ensure inner pot is correctly placed.
Food is not cooking properly.	Incorrect function selected; insufficient liquid; lid not sealed.	Verify the correct cooking function is selected. Add appropriate amount of liquid. Ensure lid is securely closed.
Unit automatically shuts off during operation.	Overheating protection activated; dry-boil protection activated.	Unplug the unit and let it cool down. Check for sufficient liquid in the pot. Do not operate without liquid.
Digital display shows an error code.	Internal malfunction.	Unplug the unit, wait a few minutes, then plug it back in. If the error persists, contact customer support.

If the problem persists after trying these solutions, please contact Tayama customer support for assistance.

## PRODUCT SPECIFICATIONS

Feature	Detail
Brand	TAYAMA
Model Number	TSP-1000
Capacity (Stainless Steel Pot)	10 Liters
Capacity (Ceramic Pot)	4 Liters
Color	Stainless steel
Special Feature	Programmable
Wattage	1000 watts
Item Weight	19 Pounds
Control Method	Touch
Controller Type	Standard Control Panel
Operation Mode	Automatic
Dishwasher Safe Parts	Inner pots, lids, steaming rack
Voltage	120 Volts (AC)
Product Dimensions	12 x 12 x 15 inches

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official TAYAMA website. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, you may contact Tayama customer service. Contact details are typically found on the manufacturer's website or in the product packaging.



© 2023 TAYAMA. All rights reserved.  
This manual is for informational purposes only. Product specifications are subject to change without notice.

### Related Documents



