

[manuals.plus](#) /

› [Smartby](#) /

› [Smartby Universal Voice Remote Control for Samsung Smart TVs - Model BN59-01363A User Manual](#)

Smartby BN59-01363A

Smartby Universal Voice Remote Control User Manual

Model: BN59-01363A

Compatible with Samsung Smart TVs

1. INTRODUCTION

This manual provides detailed instructions for the Smartby Universal Voice Remote Control, model BN59-01363A. This remote is designed to be fully compatible with various Samsung Smart TV models, including QLED, UHD, LED, LCD, 4K, and 8K TVs. It features voice control capabilities and dedicated buttons for popular streaming services like Netflix, Prime Video, and Samsung TV Plus.

Please read this manual carefully before using the remote control to ensure proper setup and operation.



Image 1: Front view of the Smartby Universal Voice Remote Control. The remote is black with a sleek design, featuring a circular directional pad, dedicated buttons for streaming services, and a voice control button.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

2.2 Pairing the Remote Control with Your TV

Before using the remote, it must be paired with your Samsung Smart TV. Follow these steps to establish a connection:

1. Ensure your TV is powered on.
2. Point the remote control directly at the front of your Samsung TV.
3. Simultaneously press and hold the **Return** button and the **Play/Pause** button for approximately 5 seconds.
4. Release the buttons when a pairing message appears on your TV screen, indicating successful pairing.

If pairing is unsuccessful, repeat the steps. Ensure there are no obstructions between the remote and the TV.




Image 2: Visual guide for pairing the remote control. It shows the remote and highlights the Return and Play/Pause buttons, indicating they should be pressed simultaneously for 5 seconds to initiate pairing.

3. OPERATING INSTRUCTIONS

3.1 Button Functions

Familiarize yourself with the functions of each button on your remote control:

Power: Press to turn the TV ON or OFF.

Number Button (123): When pressed, a number strip appears on the bottom of the TV screen. Select numbers and then select Done to enter a numeric value.

EXTRA (Four colored dots): While watching content, press to display extra information from the content provider.

Select (Center of directional pad): When pressed while you are watching content, detailed program information appears.

Directional Pad (Up / Down / Left / Right) Moves the focus and changes the values seen on the TV's menu.

Return: Returns to the previous menu. When pressed for 1 second or more, the running function is terminated. When pressed while you are watching a program, the previous channel appears.

Play / Pause: When pressed, the playback controls appear. Using these controls, you can control the media content that is playing.

Smart Hub: Returns to the Home Screen.

Volume (VOL): Move the button up or down to adjust the volume. To mute the sound, press the button. When pressed for 1 second or more, the Accessibility Shortcuts menu appears.

Channel (CH): Move the button up or down to change the channel. To see the Guide screen, press the button.

Netflix Button: Launches the Netflix application.

Prime Video Button: Launches the Prime Video application.

Samsung TV Plus Button: Launches the Samsung TV Plus application.



Function Buttons

- Power:** Press to turn the TV ON or OFF
- Number Button:** When pressed, a number strip appears on the bottom of the screen. Select numbers and then select Done to enter a numeric value.
- EXTRA:** While watching content, press to display extra information from the content provider.
- Select:** When pressed while you are watching content, detailed program information appears.
- Directional pad (up / down / left / right):**
Moves the focus and changes the values seen on the TV's menu.
- Return:** Returns to the previous menu. When pressed for 1 second or more, the running function is terminated. When pressed while you are watching a program, the previous channel appears.
- Play / Pause:** When pressed, the playback controls appear. Using these controls, you can control the media content that is playing.
- Smart Hub:** Returns to the Home Screen.
- VOL (Volume):** Move the button up or down to adjust the volume. To mute the sound, press the button. When pressed for 1 second or more, the Accessibility Shortcuts menu appears.
- CH (Channel):** Move the button up or down to change the channel. To see the Guide screen, press the button.
- 3 Shortcuts:** Launches the app indicated by the button.
NETFLIX
Prime Video
Hulu

Image 3: Diagram illustrating the various function buttons on the remote control, including Power, Number, EXTRA, Select, Direction Pad, Return, Play/Pause, Smart Hub, Volume, Channel, Netflix, Prime Video, and Samsung TV Plus. Each button is labeled with its primary function.

3.2 Voice Control Feature

The remote control includes a voice control feature for convenient operation.

1. Press and hold the **Voice Control Button**.
2. Speak your command clearly into the microphone on the remote.
3. Release the button when you have finished speaking.

Examples of voice commands include "Open Netflix," "Change to Channel 5," or "Search for action movies."







Image 4: The remote control with the voice control button highlighted. This button activates the microphone for voice commands.

4. MAINTENANCE

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Care:**
 - Replace batteries when the remote's performance degrades or it becomes unresponsive.
 - Remove batteries if the remote will not be used for an extended period to prevent leakage.
 - Dispose of used batteries responsibly according to local regulations.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

5. TROUBLESHOOTING

If you encounter issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace the batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote and the TV's infrared receiver.
- **Remote Not Pairing:**
 - Ensure the TV is powered on.
 - Repeat the pairing process as described in Section 2.2.
 - Try moving closer to the TV during the pairing process.
- **Voice Control Not Working:**
 - Ensure the remote is properly paired with the TV.
 - Speak clearly and directly into the microphone.
 - Check your TV's settings to ensure voice control is enabled.
- **Specific Buttons Not Working:**
 - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
 - If only specific app buttons (Netflix, Prime Video) are not working, ensure your TV has an active internet connection and the apps are installed and updated.

If the issue persists after trying these steps, please contact customer support.

6. SPECIFICATIONS

Feature	Detail
Model Number	BN59-01363A
Brand	Smartby
Compatibility	Universal for Samsung Smart TVs (QLED, UHD, LED, LCD, 4K, 8K)
Special Features	Voice Search, Ergonomic Design, Dedicated Streaming Buttons (Netflix, Prime Video, Samsung TV Plus)
Color	Black
Power Source	2 x AAA Batteries (not included)
Product Dimensions	6.5 x 1.5 x 0.75 inches
Item Weight	2.11 ounces

This remote is compatible with a wide range of Samsung TV remote control models, including but not limited to: BN59-01259E, BN59-01259B, BN59-01260A, BN59-01241A, BN59-01265A, BN59-01259D, BN59-01266A, BN59-01242A, BN59-01292A, BN59-01312A, BN59-01199F, BN59-01301A, AA59-00594A, AA59-00666A, AA59-00741A, AA59-00784C, AA59-00666A, BN59-01178W.



Voice Remote Control, BN59-01363A
Remote for All Samsung LED LCD HDTV
UHD QLED Curved 4K 8K Smart TV

Compatible with Samsung TV Remotes: BN59-01259E BN59-01259B BN59-01260A BN59-01241A BN59-01265A BN59-01259D BN59-01266A BN59-01242A BN59-01292A BN59-01312A BN59-01199F BN59-01301A AA59-00594A AA59-00666A AA59-00741A AA59-00784C AA59-00666A BN59-01178W

Image 5: A visual representation of various Samsung remote control models, indicating the broad compatibility of the Smartby BN59-01363A remote.

7. WARRANTY AND SUPPORT

For specific warranty information regarding your Smartby Universal Voice Remote Control, please refer to the documentation provided at the time of purchase or contact the seller directly. Warranty terms may vary depending on the retailer and region.

If you require further assistance or have questions not covered in this manual, please contact Smartby customer support through their official channels or the retailer from whom you purchased the product.